




VCB-X Controller Operator Interface SD Technical Guide

VCB-X Controller Code: SS1051 Version 2.00 & up
VAV/Zone Controller Code: SS1001, SS1005, SS1025
Requires Modular Service Tool SD Code: SS1063
Requires Modular System Manager SD Code: SS1064



IMPORTANT NOTICE

This technical guide provides instructions for using the Modular Service Tool and Modular System Manager SD with the VCB-X & VAV/Zone Controllers only. If you are using a different controller, you can download the applicable SD Technical Guide listed below from our website—orioncontrols.com. The technical guides can also be printed from the SD card.

VCM-X & VCM-X E-BUS Controller - AA-VCMXRNEOISD-TGD

RNE Controller - AA-VCMXRNEOISD-TGD

SA E-BUS Controller - AA-SAOISD-TGD

VCM Controller - AA-VCMOISD-TGD

VAV/CAV and MUA II Controllers - AA-VAVCAVMUAOISD-TGD

SD CARD UPDATING INSTRUCTIONS

The Modular Service Tool and Modular System Manager are equipped with an SD memory card. This SD card can be removed and easily updated through a computer by downloading updates, as they become available, from our website to your computer.

In order to perform any updates, your computer needs an SD card drive or you will need to purchase an SD card adapter.

Download instructions are found in Appendix B on page 82 of this manual.



www.aaon.com

WattMaster Controls, Inc.
8500 NW River Park Drive · Parkville, MO 64152
Toll Free Phone: 866-918-1100
PH: (816) 505-1100 · FAX: (816) 505-1101
E-mail: mail@wattmaster.com
Visit our website at www.orioncontrols.com
WattMaster Form : AA-VCBXOISD-TGD-01Q
Copyright March 2017 WattMaster Controls, Inc.

AAON Part Number: V28170
AAON® is a registered trademark of AAON, Inc., Tulsa, OK.
Neither WattMaster Controls, Inc. nor AAON®
assumes any responsibility for errors or omissions in this
document.
This document is subject to change without notice.

OVERVIEW & SYSTEM CONNECTION.....	4
Modular Service Tool	4
Modular System Manager SD	6
MODULAR SERVICE TOOL SD	10
Display Screens and Data Entry Keys.....	10
Initialization & Setting the Time & Date	11
Setting the Operating Mode & Energy Timer	12
Alarm Search & Override Search	13
Schedules & Holidays.....	14
Schedule Override.....	15
SYSTEM MANAGER SD	16
Display Screens and Data Entry Keys.....	16
Initialization & Setting the Time & Date	17
Setting the Operating Mode.....	18
Changing Passcodes.....	19
Loop Search and System Alarm Search.....	20
Unit Alarm Search & Override Search	21
Schedules & Holidays.....	22
Schedule Override.....	23
PROGRAMMING.....	24
VCB-X Configuration Screen Index	24
Configuring VCB-X Controllers.....	25
VCB-X Setpoint Screen Index	40
Configuring VCB-X Setpoints	41
VCB-X Status Screen Index	56
VCB-X Status Screens	57
VAV/Zone Configuration Screens	66
VAV/Zone Setpoint Screens	69
VAV/Zone Status Screens	73
VAV/Zone Damper Force Modes	75
MiniLink PD Configuration Screens.....	76
MiniLink PD Status Screens	77
TROUBLESHOOTING.....	78
VCB-X Outputs Force.....	78
APPENDIX A - SAVING, LOADING, AND COPYING SETPOINTS	80
APPENDIX B - UPDATING YOUR SD MEMORY CARD	82
APPENDIX C - UPDATING CONTROLLERS & E-BUS MODULE SOFTWARE.....	83
INDEX	85

SYSTEM CONNECTION

Modular Service Tool SD

Modular Service Tool SD

The OE391-12 Modular Service Tool is a system operator interface that provides a direct link to enable the system operator to view the status, configure, and adjust the setpoints of the VAV/CAV, MUA, VCB-X, VCM, VCM-X, VCM-X E-BUS, RNE, SA E-BUS or VAV/Zone Controller on the control system communications loop. However, this manual only applies to VCB-X and VAV/Zone Controllers. See note in the inside front cover for the list of manuals that pertain to other controllers.

The Modular Service Tool is housed in an attractive black plastic enclosure. The display area is covered with a clear plastic bezel for protection of the display screen. The Modular Service Tool has a 4-line-by-20-character display panel with adjustable contrast control and a 27-key membrane keypad for data selection and entry. All keypad operations are simple and straight forward, utilizing non-cryptic plain English language messages. Menu-driven programming allows for easy setup and operation without the need for specialized training. The Modular Service Tool is supplied with a programmable 4 Gigabyte SD memory card, (4) AA 1.5 V batteries, a wall mount, a DC power supply, a mini-Din communication cable, and an E-BUS communication cable. The mini-Din cable allows you to connect the Modular Service Tool to any Orion controller which has a mini-Din connector socket for programming, monitoring, and troubleshooting purposes.

The Modular Service Tool is also equipped with an EBC E-BUS port and an RS-485 three conductor terminal block port. The E-BUS port and included E-BUS cable are used for updating E-BUS Module software (described in Appendix C). The RS-485 port is used for hard-wiring to older controllers that do not have a mini-DIN connector socket.

The Modular Service Tool is designed to be hand-carried. Its rugged plastic housing provides superior protection for the electronic components housed inside. The Modular Service Tool is a top-quality service tool that will stand up to the demands of the typical job site environment for many years.




Figure 1: Modular Service Tool SD Dimensions

Modular Service Tool

Whether you have a Stand Alone, Interconnected, or Networked VCB-X Control System, the Modular Service Tool always connects to the controller via a prefabricated cable that is supplied with the service tool. The Modular Service Tool cable is terminated on both ends with a mini-DIN connector. Attach one end to the Modular Service Tool and the other end to the mini-DIN connector on the controller. If this is an Interconnected System, all controllers that are interconnected with communications cable can be programmed from any controller on the loop. If this is a Networked System, all controllers on the entire Networked System can be programmed from one controller.

Be sure that the Modular Service Tool has fresh batteries installed or that it is connected to a power source using the supplied power pack before attempting any programming of the controller. See **Figure 2** for connection details.




Figure 2: Modular Service Tool SD

Modular System Manager SD

Modular System Manager SD




Figure 3: Modular System Manager SD Dimensions

The OE392-12 Modular System Manager SD provides a direct link to enable you to view the status and adjust the setpoints of the VCM-X, VCM-X E-BUS, VCB-X, RNE, SA E-BUS, VCM, VAV/CAV, MUA II or VAV/Zone Controller on the control system communications loop. The System Manager SD is housed in a beige-colored plastic enclosure. The System Manager has a programmable 4 Gigabyte SD card and is equipped with a 4-line-by-20-character backlit display panel and a 24-key membrane keypad for data selection and entry. All keypad operations are simple and straight forward, utilizing non-cryptic plain English language messages. Menu-driven programming allows for easy setup and operation without the need for specialized training. The System Manager also has 2 integral LEDs for user notification of system alarm conditions and override initiations. Protection from unauthorized users is provided by the System Manager's integral multi-level passcode authorization programming.

On a Networked System, the Modular System Manager is connected to the communications and power loop of the system via modular cables that simply plug into the System Manager board and the Power/Comm Distribution Board. This virtually eliminates wiring errors and makes installation fast and easy. When it is to be connected to a Stand-Alone system, a cable with modular connectors on one end and stripped wire ends on the other end is provided to facilitate connecting communications and power to the Modular System Manager from the 24 VAC power source and the HVAC unit controller communication wiring terminals.

The Modular System Manager is designed for wall mounting. Mounting holes are provided to attach the Modular System Manager to a standard handy box. It is recommended that the System Manager be mounted at approximately eye level to allow for ease of programming and reading of the display. The System Manager is typically mounted in the building manager's or superintendent's office or in an equipment room. The attractive enclosure is quite suitable for mounting in any location.

Modular System Manager SD Network Connection

Network Connection

As previously described, when you are connecting the Modular System Manager to a Networked System, the Modular System Manager is connected to the communications and power loop of the system via modular cables. These cables simply plug into the System Manager board and to any device with modular connectors on any local loop on the system. Devices with modular connectors include the Power/Comm Distribution Board, VAV/Zone controller, and MiniLink Polling Device. By using these plug-in connections, wiring errors are virtually eliminated and system installation is fast and easy. See **Figure 4** below for typical connection information. See **Figure 5 on page 8** for typical Power/Comm board wiring and connection information.

When the System Manager is to be connected to a Stand Alone system, a 12-foot cable with modular connectors on one end and stripped wire ends on the other end is provided for this purpose. This is used to facilitate connecting communications and power wiring to the Modular System Manager from a 24 VAC power source and to the HVAC unit controller communication wiring terminals. See **Figure 6 on page 9** for wiring details. If the supplied cable wire is not long enough for your installation, a standard modular cable of the correct length can be purchased through WattMaster and one of the modular connectors can be cut off to allow for the transformer and communication terminal wiring connections. It is recommended that you do not splice the communications wire if at all possible. The transformer should be rated at 6 VA minimum power output.




Figure 4: Modular System Manager SD - Network

SYSTEM CONNECTION

Power/Comm Board Wiring

WARNING!

DO NOT GROUND THE 24V TRANSFORMER THAT IS TO BE USED WITH THE POWER/COMM BOARDS. GROUNDING OF THE TRANSFORMER WILL DAMAGE THE POWER/COMM BOARD AND ALL BOARDS CONNECTED TO IT. A SEPARATE TRANSFORMER MUST BE USED FOR EACH POWER/COMM BOARD. NO EXCEPTIONS. DO NOT CONNECT ANY OTHER DEVICES TO THE TRANSFORMER USED FOR THE POWER/COMM BOARD!

A Power/Comm Cable Can Be Used To Connect With The MiniLink PD Instead Of Using 2 Conductor Twisted Pair With Shield Cable. You Can Also Use A Power/Comm Cable To Connect With Another Power/Comm Board, A System Manager Or A VAV/Zone Controller.

If Desired, Instead Of Using A Power/Comm Cable, You Can Use 2 Conductor Twisted Pair With Shield Cable To Connect To The Power/Comm Board From The Unit Controller, MiniLink PD, Or Another Power/Comm Board.




Figure 5: Typical Power/Comm Board Wiring




Figure 6: Modular System Manager SD - Stand Alone

Modular Service Tool Keys

Operator Interfaces

In order to configure and program the VCB-X Controller, you must have an Operator's Interface or a personal computer with the Prism 2 computer front-end software installed. Two different Operator Interfaces are available for programming of the VCB-X Controls System—the Modular Service Tool SD and/or the System Manager TS. These devices allow you to access the *status* and *setpoints* of any controller on your communications loop. This manual describes the Modular Service Tool SD. If using the System Manager TS II, please see the *System Manager TS II Technical Guide*. If using Prism 2, please see the *Prism 2 Technical Guide*.

The Modular Service Tool allows you to view any input or output status and change any setpoint to fine-tune the operations of the total system. All keypad operations are simple and straightforward, utilizing non-cryptic plain English messages.

Display Screens & Data Entry Keys

See the chart below for a list of the keypad descriptions and functions.

Keypad Description	Key Function
ESC	Use this key to exit from screens or from data entry or to return to the Main Screen from any screen in the system.
ENTER	Use this key to enter a new value.
Clear	If a data entry mistake is made, press this key to clear the data entry field and start over. This key also turns off the power to the Service Tool when on the Main Screen
Minus	If a setpoint with a negative value is required, press this key for the minus sign.
DEC	Press this key when entering data that requires a decimal point.
← →	Use these keys to change values in the Configuration Screens as prompted.
↑ ↓	Use these keys to step backward or forward through the screens.

Table 1: Keypad Descriptions

Mode Selection Buttons

The Modular Service Tool is provided with “Mode Selection Buttons.” These buttons give you instant access to the specific mode desired without having to scroll through several menu screens to get there.

Button Description	Mode Selection Buttons
STATUS	Pressing this button takes you directly to the controller “Status” screens.
SETPOINTS	Pressing this button takes you directly to the controller “Setpoints” screens.
SCHEDULES	Pressing this button takes you directly to the controller “Schedules” screens.
OVERRIDES	Pressing this button takes you directly to the controller “Overrides” screen. See the “Override Button” section on page 21 for a description of this function. See Note 1 below.
ALARMS	Pressing this button takes you directly to the controller “Alarms” screen. See the “Alarms Button” section on page 20 for a description of this function.
CONFIGURATION	Pressing this button takes you directly to the controller “Configuration” screens.
BALANCE-TEST	Pressing this button takes you directly to the controller “Balance-Test” screens.
Notes: (1) The Modular Service Tool will only search the Overrides one loop at a time. You must enter the Loop number and the MiniLink PD unit ID (60).	

Table 2: Button Descriptions

Initialization & Setting the Time & Date

Modular Service Tool Initialization

Modular Service Tool Initialization Screen and Setup Screens

After connecting the Service Tool to the controller with the supplied cable, press **<ON>**. The *Initialization Screen* will appear followed by the *Setup Screens* as shown below. If there is no SD card installed, the second screen will display, "No SD Card Connected! Powering Down!"

```

      Initializing
    Service Tool vX.XX
  WattMaster Controls
  
```

```

    1) Set Time & Date
    2) Communications
    NEXT) More Options
    ESC) Exit Menu
  
```

```

    3) Energy Saving
    4) Update Software
    NEXT) More Options
    ESC) Exit Menu
  
```

NOTE: Once you press **<ESC>** while at the *Setup Screens* shown above, you can access them again by pressing **<NEXT>** or cycling power.

Setting The Time & Date

The Modular Service Tool is equipped with a real time clock chip allowing it to maintain the correct time. Once you have programmed the correct time and date, the information is broadcast globally to all controllers on the entire system.

NOTE: If you are in a time zone that has daylight savings, you will need to manually adjust the time twice a year.

Programming the Time

From the *Setup Screen* shown below, press **<1>** on your keypad to access the *Set Time & Date Screens*. (You may have to press **<NEXT>** to access this screen).

```

    1) Set Time & Date
    2) Communications
    NEXT) More Options
    ESC) Exit Menu
  
```

Although the times are displayed on the *Main Screen* in a standard 12-hour format, you must program them using the 24-hour military format. If you configured the VCB-X Controller to use its own Internal Schedules, the Occupied/Unoccupied modes are calculated on the basis of the current real time clock reading.

The two screens that follow will appear. To scroll through the fields, press **<↓>** or **<ENTER>**. In order to save a new value, you must press **<ENTER>**.

```

      Program Time/Date
    Day (Sunday=0):  X
    Enter Hr. (0-23): XX
    Enter Minutes   : XX
  
```

Day - Enter the Day of the Week (0 to 6)
Sunday = 0

Hours (Hr) - Enter Hours in 24-Hour Military Format
(1700 = 5:00 PM)

Minutes - Enter the Minutes
(0 to 59)

Programming the Date

To scroll through the fields, press **<↓>** or **<ENTER>**. In order to save a new value, you must press **<ENTER>**.

```

      Program Time/Date
    Month (1-12):  XX
    Day (1-31):   XX
    Year (00-99):  XX
  
```

Month - Enter the Month (1 to 12)

Day - Enter the Day of the Month (1 to 31)

Year - Enter the current Year with two digits (00 to 99)

When you have finished programming the time and date, press **<ESC>** to return to the *Setup Screen* shown below.

```

    1) Set Time & Date
    2) Communications
    NEXT) More Options
    ESC) Exit Menu
  
```

Setting the Operating Mode and Energy Saving Timer

Setting the Operating Mode

The Operating Mode is displayed on the last line of the *Main Screen* as shown below. The factory default setting for the Service Tool is **LS (Low Speed) Stand Alone Mode**. **LS Stand Alone Mode** is the correct configuration for the VCB-X Controller when in Stand Alone Mode.

```
Service Tool SD vX.XX
01/16/15 02:21 PM
LS Stand Alone
No Communication
```

If you are using this Service Tool on a communications loop and have an installed MiniLink PD or CommLink, you will need to change the setting to **LS (Low Speed) Network Mode**.

If you are using a VCB-X Controller that is set for high speed, you will need to change the setting to **HS (High Speed) Stand Alone Mode** or **HS (High Speed) Network Mode**.

If your display indicates a different mode than the one you need, press **<2>** at the *Setup Screen* shown below. You may have to press **<NEXT>** to access this screen.

```
1) Set Time & Date
2) Communications
NEXT) More Options
ESC) Exit Menu
```

The *Communications Screen* will appear as shown below.

```
Stand Alone Mode
Lo Speed Connection
Use Left/Right Arrow
To Change Selections
```

Press **<←>** or **<→>** to select the proper mode of operation.

When you have made your selection, press **<ENTER>**. The following screen will appear.

```
You Have Changed The
System Mode
Press Any Key To
Continue
```

Press any key to continue. The *Setup Screen* will appear as shown below:

```
1) Set Time & Date
2) Communications
NEXT) More Options
ESC) Exit Menu
```

Setting the Energy Saving Timer

The Modular Service Tool has a built-in timer that can be programmed to shut the Service Tool off after a specified period of time if no buttons are pressed. This is a very useful feature if you are powering the Service Tool from the internal batteries.

To set the Energy Saving Timer, press **<NEXT>** at the first *Setup Screen* and **<3>** at the second *Setup Screen* shown below. (You may have to press **<NEXT>** to access these screens).

```
1) Set Time & Date
2) Communications
NEXT) More Options
ESC) Exit Menu
```

```
3) Energy Saving
4) Update Software
NEXT) More Options
ESC) Exit Menu
```

The *Energy Saving Screen* will appear as shown below:

```
Energy Saving
Automatic Power Down
Minutes: xx
Press ESC to Exit
```

Enter the number of minutes you want the Service Tool to stay active before it automatically powers down and press **<ENTER>**. To cancel the automatic power down, enter **<99>** and press **<ENTER>**. After you have entered a number between 1 and 99 minutes, press **<ESC>** to exit the screen.

The *Setup Screen* will appear again as shown below:

```
1) Set Time & Date
2) Communications
NEXT) More Options
ESC) Exit Menu
```

Modular Service Tool Alarm Search

NOTE: When you *press* the **<ALARMS>** button on the Modular Service Tool, it will search only the unit ID that you have entered; therefore, you must search each unit individually to access all alarms for that controller.

To search for alarms, *press* **<ALARMS>** while on any screen but the *Main Screen*. The *Unit Selection Screen* will be displayed.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the Unit ID of the controller the Service Tool is connected to and *press* **<ENTER>**. Once communication is established, “No Communication” will be replaced with “Press Down.” Then *press* **<↓>**.

NOTE: If “No Communication” remains, it indicates a communication failure to the controller.

One of the following screens will appear:

VCB-X V.XXX
NO ALARMS

VCB-X V.XXX
ALARMS PRESENT
SCROLL DOWN TO VIEW

Press **<↓>** to scroll through all the alarms for the controller that the Modular Service Tool is connected to.

To clear any alarms that are found, you must fix the problem indicated in the alarm. Once the problem is fixed, the alarm will clear from the screen the next time the unit is polled.

Modular Service Tool Override Search

When a space sensor with override option is used with any VAV/Zone or Unit Controller, the Modular Service Tool can determine and report any controllers that are currently operating in an override condition on a specific Loop by entering a Loop ID number and then doing a search.

NOTE: When you *press* the **<OVERRIDES>** button on the Modular Service Tool, it will search only the Loop number that you enter; therefore, you must search each loop individually to access all overrides.

To access the *Overrides Screen*, *press* **<OVERRIDES>** from the Modular Service Tool’s keypad. A screen will appear asking you to enter the unit ID.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the Unit ID for the MiniLink PD (MLPD) of the loop you wish to search and *press* **<ENTER>**. The MLPD is always address 60 on each loop. So the unit ID of any particular MLPD would be the loop number followed by 60. In the example above, Loop 1, address 60 has been entered. Once communication is established, “No Communication” will be replaced with “Press Down.” Then *press* **<↓>**.

NOTE: If “No Communication” remains, it indicates a communication failure to the controller.

Once communications are successful, one of the following screens will appear:

VCB-X V.XXX
NO OVERRIDES

VCB-X V.XXX
OVERRIDES PRESENT
SCROLL DOWN TO VIEW

After the Service Tool completes its search, it will post a message to tell you if there are overrides present. If there are overrides, *press* **<↓>** and all units on the loop will be listed showing ‘Override: Yes or No.’ *Press* **<OVERRIDES>** again to access overrides on a different loop. Enter the Unit ID of the MLPD of that loop.

Schedules and Holidays

Scheduling

You can access the Unit Controller Scheduling Screens by pressing **<SCHEDULES>**. The *Unit Selection Screen* will be displayed.

```
Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication
```

Enter the Unit ID of the controller the Service Tool is connected to and press **<ENTER>**. Once communication is established, "No Communication" will be replaced with "Press Down." Then press **<↓>**.

NOTE: If "No Communication" remains, it indicates a communication failure to the controller.

Press the **<↓>** button and then press **<ENTER>** to access the scheduling function you wish to view.

```
Schedule Menu
Schedule Override
Week Schedules
Holidays
```

Week Schedules

Event #1

```
VCB-X Schd
Sunday Event #1
Start Time...: XXXX
Stop Time...: XXXX
```

Event #2

```
VCB-X Schd
Sunday Event #2
Start Time...: XXXX
Stop Time...: XXXX
```

If you are using the internal scheduling capability of the Unit Controller, set the schedule hours and holiday periods from the menu shown above. You can also force the unit to operate continuously in occupied or unoccupied mode by selecting the Schedule Override menu item and entering the desired command.

If you are using an external contact closure to signal the occupied mode, you must access the *Week Schedule Screens* and set all start and stop times to zero to prevent the internal schedule from turning the equipment on when you don't want it to operate.

The screens will step through the *Start Time* and then the *Stop Time* for each day of the week. You can quit at any point in the process by pressing **<ESC>**. There are two Start/Stop events available per day, so the screen will show which event is being programmed. If you need only one event, keep Event #2's times set at ZERO.

All times are in 24-hour military format, so 5:00 PM would be entered as 1700.

If both the Start and Stop Times are ZERO, the schedule is in a continuous OFF mode. (**Also, use for Remote Forced Occupied applications using the Forced Occupied Binary Input.**)

If both the Start and Stop Times are 2359, the schedule is in a continuous ON mode.

NOTE: The second line displays which day of the week is currently being programmed. The day of the week automatically increments as you exit the Event #2 screen for the day and continue to the next day's Event #1 screen.

CAUTION: The controller ships with all schedules set to zero so that the controller will not attempt to heat or cool before you have configured the system.

Holiday Start/Stop Day Selection

```
VCB-X Hldy
Holiday # 1
Start Mon/Day.: XXXX
[ July 4th = 704 ]
```

```
VCB-X Hldy
Holiday # 1
Stop Mon/Day.: XXXX
[ July 5th = 705 ]
```

The screens will step through the fourteen possible holidays, one period at a time. Line 2 shows which holiday is currently being programmed. Since a holiday period can encompass more than one day, you need to program the day the holiday starts and the day the holiday ends. If your holiday only lasts one day, simply set both the Start Day and the Stop Day to the same value. Remember to combine the month and day into a single four-digit value.

EXAMPLE: 704 = July 4th (NOTE: Leading zero not required)
1225 = December 25th

Holiday Scheduling and Schedule Override

Holiday Start/Stop Times

VCB-X Hldy
Holiday Schedule
Start Event #1: XXXX
Stop Event #1: XXXX

VCB-X Hldy
Holiday Schedule
Start Event #2: XXXX
Stop Event #2: XXXX

The fourteen holidays all use the same Start and Stop times which you program on this screen and the next. You must enter the time in 24-hour military format, the same as a regular week schedule.

Normally, the holidays will operate in an unoccupied mode or a reduced schedule mode. There are two start/stop events available on holidays to match the standard schedule number of events.

Schedule Override

VCB-X Ovrdr
Schedule Override
Enter Override...: X
[0=Auto 1=ON 2=OFF]

If you want to force the unit to operate in a continuous Occupied or Unoccupied mode, select this menu item to activate the desired method. If a Schedule Override is active, all other methods of schedule control are ignored (Push-Button, Internal, and Remote).

As you can see on the last line of the display, enter **<1>** to run continuously in the *Occupied Mode* or **<2>** to run continuously in the *Unoccupied Mode*. To restore normal schedule operations, enter **<0>**.

This override remains in effect until canceled and does not time-out like the Output Overrides do after 10 minutes of no communications.

NOTE: Do not use the Force OFF mode in place of setting all the week schedules to ZERO if you are using a Remote Signal for your scheduling since the Override has priority over the Remote Signal.

System Manager SD Keys and Buttons

Operator Interfaces

In order to configure and program the Orion System controllers, you must have an Operator's Interface or a personal computer with the Prism 2 computer front-end software installed. Three different Operator Interfaces are available for programming of the Orion Controls System—the Modular Service Tool SD, the Modular System Manager SD, and/or the System Manager TS II. These devices allow you to access the status and setpoints of the controllers on your communications loop. This manual describes the Modular System Manager SD. If using the Modular Service Tool SD, please see the *Modular Service Tool SD Quick Start Guide*. If using the System Manager TS II, please see the *System Manager TS II Technical Guide*. If using Prism 2, please see the *Prism 2 Technical Guide*.

The Modular System Manager SD allows you to view any input or output status and change any setpoint to fine-tune the operations of the total system. All keypad operations are simple and straightforward, utilizing non-cryptic plain English messages.

Display Screens & Data Entry Keys

See the chart below for a list of the keypad descriptions and functions.

Keypad Description	Key Function
	Modular System Manager SD
ESC	Use this key to exit from screens or from data entry or to return to the Main Screen from any screen in the system.
ENTER	Use this key to enter a new value.
Clear	If a data entry mistake is made, press this key to clear the data entry field and start over.
Minus	If a setpoint with a negative value is required, press this key for the minus sign.
DEC	Press this key when entering data that requires a decimal point.
← →	Use these keys to change values in the Configuration Screens as prompted.
↑ ↓	Use these keys to step backward or forward through the screens.

Table 3: Keypad Descriptions

Mode Selection Buttons

The Modular System Manager is provided with “Mode Selection Buttons.” These buttons give you instant access to the specific mode desired without having to scroll through several menu screens to get there.

Button Description	Modular System Manager SD
STATUS	Pressing this button takes you directly to the controller “Status” screens.
SETPOINTS	Pressing this button takes you directly to the controller “Setpoints” screens and “Configuration” menu.
SCHEDULES	Pressing this button takes you directly to the controller “Schedules” screens.
OVERRIDES	Pressing this button takes you directly to the controller “Overrides” screen. See the “Override Button” section on page 21 for a description of this function. See Notes 1 & 2 below.
ALARMS	Pressing this button takes you directly to the controller “Alarms” screen. See the “Alarms Button” section on page 20 for a description of this function. See Notes 1 & 2 below.

Notes:

(1) This button only functions when the system is configured for “Network Mode” or “Multiple MGRS Mode.” It will not function in “Stand Alone Mode.”

(2) The “Search for Units” function must be performed on the System Manager upon initial system setup before this function will be available. See the “Network Mode & Multiple Managers Loop Search” on **page 20** of this manual for complete instructions on performing a loop search.

Table 4: Button Descriptions

Initialization & Setting the Time & Date

System Manager SD Initialization

System Manager SD Initialization Screen and Setup Screens

After connecting the System Manager to the controller with the supplied cable, press **<ON>**. The *Initialization Screen* will appear followed by the *Setup Screens* as shown below. If there is no SD card installed, the second screen will display, "No SD Card Connected! Powering Down!"

NOTE: After exiting these screens, you can access them again by pressing **<ESC>** and then **<↔>** or by cycling power.

```

INITIALIZING
System Manager SD
vX.XX
WattMaster Controls
    
```

```

1) Set Time & Date
2) Communications
NEXT) More Options
ESC) Exit Menu
    
```

```

3) Change Passcodes
4) Loop Search
NEXT) More Options
ESC) Exit Menu
    
```

```

5) Alarm Search

NEXT) More Options
ESC) Exit Menu
    
```

Setting The Time & Date

The System Manager SD is equipped with a real time clock chip allowing it to maintain the correct time. Once you have programmed the correct time and date, the information is broadcast globally to all controllers on the entire system.

NOTE: A Level 1 or Level 2 User can set the time and date.

NOTE: If you are in a time zone that has daylight savings, you will need to manually adjust the time twice a year.

Programming the Time

From the *Setup Screen* shown below, press **<1>** on your keypad to access the *Set Time & Date Screens*.

```

1) Set Time & Date
2) Communications
NEXT) More Options
ESC) Exit Menu
    
```

Although the times are displayed on the *Main Screen* in a standard 12-hour format, you must program them using the 24-hour military format. If you configured the Unit Controller to use its own Internal Schedules, the Occupied/Unoccupied modes are calculated on the basis of the current real time clock reading.

The two screens that follow will appear. To scroll through the fields, press **<↓>** or **<ENTER>**. In order to save a new value, you must press **<ENTER>**.

```

Program Time/Date
Day   (Sunday=0):  X
Enter Hr. (0-23): XX
Enter Minutes   : XX
    
```

Day - Enter the Day of the Week (0 to 6)
Sunday = 0

Hours (Hr) - Enter the Hour (0-23) in
24-Hour Military Format
(13 = 1:00 PM)

Minutes - Enter the Minutes
(0 to 59)

Programming the Date

To scroll through the fields, press **<↓>** or **<ENTER>**. In order to save a new value, you must press **<ENTER>**.

```

Program Time/Date
Month   (1-12):  XX
Day     (1-31):  XX
Year    (0-99):  XX
    
```

Month - Enter the Month (1 to 12)

Day - Enter the Day of the Month (1 to 31)

Year - Enter the current Year (0 to 99)

When you have finished programming the time and date, press **<ESC>** to return to the *Setup Screen*.

Setting the Operating Mode

Setting the Operating Mode

The Operating Mode is displayed on the last line of the *Main Screen* as shown below. The factory default setting for the System Manager is **LS (Low Speed) Stand Alone Mode**.

```
System Manager SD
01/16/15 02:21 PM
LS Stand Alone
No Communication
```

The System Manager must be configured for the correct mode of operation for your system. There are 5 modes of operation available for the Orion System—**LS (Low Speed) Stand-Alone, HS (High Speed) Stand-Alone, LS (Low Speed) Network, HS (High Speed) Network, and LS (Low Speed) & HS (High Speed) Multiple MGRS**.

If you are using this System Manager on a communications loop that doesn't have a MiniLink PD or CommLink connected to it and you have a single System Manager on your system, then you need to operate in **LS (Low Speed) Stand-Alone Mode**. If you are using a VCB-X Controller or GPC-XP Controller that is set for high speed, and you don't have a MiniLink PD or CommLink connected to the loop, then you will need to change the setting to **HS (High Speed) Stand Alone Mode**.

If you are using the System Manager on a communications loop and have an installed MiniLink PD or CommLink, you will need to change the setting to **LS (Low Speed) Network Mode**. If you are using a VCB-X Controller or GPC-XP Controller that is set for high speed, and are using a MiniLink PD or CommLink, then you will need to change the setting to **HS (High Speed) Network Mode**.

If you are using this System Manager on a communications loop, have a MiniLink PD or CommLink installed, and have multiple System Managers, then you need to operate in **Multiple MGRS Mode**.

If your display indicates a different mode than the one you need, *press <2>* at the *Setup Screen* shown below. You will have to cycle power to get to this screen or by *pressing <ESC> and <PREV>*.

```
1) Set Time & Date
2) Communications
NEXT) More Options
ESC) Exit Menu
```

The *Passcode Clearance Screen* will appear as shown below.

```
THIS ACTION REQUIRES
A SPECIAL HIGH LEVEL
PASSCODE CLEARANCE
Enter: XXXXXXXX
```

Enter the seven digit passcode **<2337377>** to access the next screen.

You will then see the screen below displayed.

```
Stand Alone Mode
Lo Speed Connection
Use Left/Right Arrow
To Change Selections
```

Press **<←>** or **<→>** if you need to change the mode of operation to **LS (Low Speed) Stand-Alone, HS (High Speed) Stand-Alone, LS (Low Speed) Network, HS (High Speed) Network, LS (Low Speed) Multiple Manager or HS (High Speed) Multiple Manager** and then press **<ENTER>** to save your selection. If you are not using Multiple Manager Mode, *press <ESC>* at the screen below and continue scrolling right and left.

```
Multiple Manager
Unit Address: 0

Press ESC to Exit
```

For **Multiple MGRS Mode**, enter the address at which you want this particular System Manager to be set.

When multiple System Managers are used on a local loop, each must be set with a unique address different from any other device on that loop. You must perform this same operation again for each System Manager installed. If you want one of these System Managers to be able to indicate alarms and overrides for the entire system, you must *select* either **LS** or **HS Network Mode** on that particular System Manager.

Once you have the correct number per the display above displayed, *press <ENTER>*. The following screen will appear telling you that you have changed the system mode:

```
You Have Changed The
System Manager Mode
Press Any Key To
Continue
```

Press any key on the keyboard to exit this screen.

System Manager Passcodes

Changing the mode of operation, updating software, changing schedules, and changing setpoints and configurations require passcode clearance. The screen below will appear if this action requires passcode clearance.

```
THIS ACTION REQUIRES
PASSCODE CLEARANCE
Enter Passcode: XXXX
```

The System Manager has three levels of user access. All users can view Status Screens. Level 1 users are limited to changing the Time and Date and Operating Schedules. Level 2 users have complete system access. Any status or setpoint field can be read or reset from the System Manager.

These two levels of passcodes are programmable by any Level 2 user. The default Level 1 passcode is "1111" and the default Level 2 passcode is "2222."

If you wish to change either Level 1 or Level 2 passcodes, please see the instructions that follow.

From the *Main Status Screen*, press **<ESC>** and then press **<PREV>**. The following screen will appear:

```
1) Set Time & Date
2) Communications
NEXT) More Options
ESC) Exit Menu
```

Press **<→>** for the Next Menu. The following screen will be displayed:

```
3) Change Passcodes
4) Loop Search
NEXT) More Options
ESC) Exit Menu
```

Press **<3>** for Change Passcodes. The following screen will be displayed:

```
THIS ACTION REQUIRES
PASSCODE CLEARANCE
Enter Passcode: XXXX
```

Passcodes can only be changed by a Level 2 user. *Enter* the passcode and *press* **<ENTER>**. The following screen will appear:

```
Enter New Passcode
Level 1.....: XXXX
Level 2.....: XXXX
[Must Be 4 Digits]
```

This screen allows you to enter new Level 1 and/or Level 2 passcodes. Passcodes must always be four digits in length, so the usable range of numbers is 1000 to 9999.

CAUTION: If you change the Level 2 passcode and cannot remember what it is, you will be locked out of your system!

Loop Search and System Alarm Search

Network Mode & Multiple Managers Loop Search

When the System Manager is configured for Network Mode, a loop search must initially be performed for the System Manager to recognize alarms or overrides. Also, when you have a system that has multiple System Managers and you have one of the System Managers set to (63) Network Mode for alarm and override indication, you must also perform a loop search for that System Manager. This allows the System Manager to be aware of all alarms and overrides for all local loops on the entire system.

To access the *Loop Search Screen*, from the *Setup Screen*, press **<ESC>** and then press **<PREV>**.

```
1) Set Time & Date
2) Communications
NEXT) More Options
ESC) Exit Menu
```

Press **<↵>** for Next Menu. The following screen will be displayed:

```
3) Change Passcodes
4) Loop Search
NEXT) More Options
ESC) Exit Menu
```

Press **<4>** for Loop Search. The following screen will be displayed:

```
Loop Search
Current Loop = XX
Loops Found = XX
Searching
```

The System Manager will now proceed to search all loops to find the MiniLink PDs that are connected to the system. The screen will display the current loop being searched and the number of loops currently found.

Once the search is completed, the following screen will be displayed:

```
Loop Search
Finished
Loops Found = XX
Press ESC to Exit
```

The screen will display the number of loops found on your system. The information will be saved into the System Manager's memory. No further loop searches will be required unless you add an additional MiniLink PD to the Network System.

System Alarm Search

The System Manager can be used to search for all active alarms on the system. You must configure the MiniLink PD to allow for "Alarm Polling" for each controller you want polled for alarms. See the MiniLink PD programming section on **page 76** of this manual for setting information.

This option will alert you of the number of alarms present on individual units, but will not tell you what type of alarm are present. You will have to perform an individual unit alarm search for detailed alarm information.

To access the *Alarm Search Screen*, from the *Setup Screen*, press **<ESC>** and then press **<PREV>**.

```
1) Set Time & Date
2) Communications
NEXT) More Options
ESC) Exit Menu
```

Press **<↵>** for Next Menu. The following screen will be displayed:

```
3) Change Passcodes
4) Loop Search
NEXT) More Options
ESC) Exit Menu
```

Press **<↵>** for Next Menu. The following screen will be displayed:

```
5) Alarm Search
NEXT) More Options
ESC) Exit Menu
```

Press **<5>** for Alarm Search. The entire system is searched from this point. The following screen will be displayed:

```
Alarm Screen

SEARCHING!
```

Once the Alarm Search is complete, one of the following screens will display:

```
Alarm Screen

XX ALARMS ON UNIT XX
```

Unit Alarm Search and Override Search

Alarm Screen

NO ALARMS DETECTED

To check controllers individually for alarms, use the **<ALARMS>** button on the Main Display.

Unit Alarm Search

The System Manager can be used to search for all active alarms one controller at a time.

Press **<ALARMS>**. The *Unit Selection Screen* below will be displayed.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the Unit ID of the controller you wish to search and press **<ENTER>**. Once communication is established, "No Communication" will be replaced with "Press Down." Then press **<↓>**.

NOTE: If "No Communication" remains, it indicates a communication failure to the controller.

The following screen will appear. The System Manager will search for any active alarms on the unit and one of the following screens will appear:

CONTROLLER V.XXX

NO ALARMS

CONTROLLER V.XXX

ALARMS PRESENT
SCROLL DOWN TO VIEW

Press **<↓>** to scroll through all the alarms for the controller that the Modular Service Tool is connected to.

To clear any alarms that are found, you must fix the problem indicated in the alarm. Once the problem is fixed, the alarm will clear from the screen the next time the unit is polled.

System Manager Override Search

NOTE: In order for the Override Search to work, a Loop Search must be performed first. See **page 20** for details.

When a space sensor with override option is used with any VAV/Zone Controller or Unit Controller, the System Manager can determine and report any controllers that are currently operating in an override condition. This function requires that a MiniLink PD is installed on each loop where the controllers may be located. The MiniLink PD must be configured to allow for "Alarm Polling" for each controller that Override Polling Enabled is desired for this function to work. See the MiniLink PD programming section on **page 76** of this manual for setting information.

To access the *Space Sensor Overrides Screen*, press **<OVERRIDES>**. The following screen will appear.

Overrides Screen

SEARCHING!

After the System Manager completes its search, it will list the first unit on the system that is currently in the override mode. Press the **<↓>** button to scroll through all units that are in the Override Mode.

Overrides Screen
Loop = 1 Unit = 59
OVERRIDE FOUND

Schedules and Holidays

Scheduling

You can access the Controller Scheduling Screens by pressing **<SCHEDULES>**. The screen below will appear because Scheduling requires passcode clearance. A Level 1 or 2 passcode can change schedules.

```
THIS ACTION REQUIRES  
PASSCODE CLEARANCE  
Enter Passcode: XXXX
```

If the correct passcode was entered, the *Unit Selection Screen* will be displayed.

```
Enter Unit Address  
Then Press Enter  
Selected Unit#: XXXX  
No Communication
```

Enter the Unit ID of the controller you wish to change schedules for and press **<ENTER>**. Once communication is established, "No Communication" will be replaced with "Press Down." Then press **<↓>**.

NOTE: If "No Communication" remains, it indicates a communication failure to the controller.

The *Unit Schedule Menu* will be displayed.

```
Schedule Menu  
Schedule Override  
Week Schedules  
Holiday Schedules
```

Press the **<↓>** button until the cursor is on the desired option and then press **<ENTER>**.

Week Schedules

From the *Unit Schedule Menu*, select Week Schedules. The following two screens will appear in order:

Event #1

```
Schd  
Sunday      Event #1  
Start Time..: XXXX  
Stop Time...: XXXX
```

Event #2

```
Schd  
Sunday      Event #2  
Start Time..: XXXX  
Stop Time...: XXXX
```

If you are using the internal scheduling capability of the Controller, set the schedule hours and holiday periods from the menu shown above. You can also force the unit to operate continuously in occupied or unoccupied mode by selecting the Schedule Override menu item and entering the desired command.

If you are using an external contact closure to signal the occupied mode, you must access the *Week Schedule Screens* and set all start and stop times to zero to prevent the internal schedule from turning the equipment on when you don't want it to operate.

The screens will step through the *Start Time* and then the *Stop Time* for each day of the week. You can quit at any point in the process by pressing **<ESC>**. There are two Start/Stop events available per day, so the screen will show which event is being programmed. If you need only one event, keep Event #2's times set at ZERO.

All times are in 24-hour military format, so 5:00 PM would be entered as 1700.

If both the Start and Stop Times are ZERO, the schedule is in a continuous OFF mode. (**Use for Remote Signal Contact.**)

If both the Start and Stop Times are 2359, the schedule is in a continuous ON mode.

NOTE: The second line displays which day of the week is currently being programmed. The day of the week automatically increments as you exit the Event #2 screen for the day and continue to the next day's Event #1 screen.

CAUTION: The controller ships with all schedules set to zero so that the controller will not attempt to heat or cool before you have configured the system.

Holiday Scheduling and Schedule Override

Holiday Start/Stop Day Selection

From the *Unit Schedule Menu*, select Holiday Schedules. The following four screens will appear in order:

```

      Hldy
    Holiday #  1
  Start Mon/Day.: XXXX
    [ July 4th = 704 ]
  
```

```

      Hldy
    Holiday #  1
  Stop Mon/Day.: XXXX
    [ July 5th = 705 ]
  
```

The screens will step through the fourteen possible holidays, one period at a time. Line 2 shows which holiday is currently being programmed. Since a holiday period can encompass more than one day, you need to program the day the holiday starts and the day the holiday ends. If your holiday only lasts one day, simply set both the Start Day and the Stop Day to the same value. Remember to combine the *month and day* into a single four-digit value.

EXAMPLE: 704 = July 4th
 (NOTE: Leading zero not required)
 1225 = December 25th

Holiday Start/Stop Times

```

      Hldy
    Holiday Schedule
  Start Event #1: XXXX
  Stop  Event #1: XXXX
  
```

```

      Hldy
    Holiday Schedule
  Start Event #2: XXXX
  Stop  Event #2: XXXX
  
```

The fourteen holidays all use the same Start and Stop times which you program on this screen and the next. You must enter the time in 24-hour military format, the same as a regular week schedule.

Normally, the holidays will operate in an unoccupied mode or a reduced schedule mode. There are two start/stop events available on holidays to match the standard schedule number of events.

Schedule Override

From the *Unit Schedule Menu*, select Schedule Override. The following screen will appear:

```

      Ovr
    Schedule Override
  Enter Override...: X
    [0=Auto 1=ON  2=OFF]
  
```

If you want to force the unit to operate in a continuous Occupied or Unoccupied mode, select this menu item to activate the desired method. If a Schedule Override is active, all other methods of schedule control are ignored (Push-Button, Internal, and Remote).

As you can see on the last line of the display, enter **<1>** to run continuously in the *Occupied Mode* or **<2>** to run continuously in the *Unoccupied Mode*. To restore normal schedule operations, enter **<0>**.

This override remains in effect until canceled and does not time-out like the Output Overrides do after 10 minutes of no communications.

NOTE: Do not use the Force OFF mode in place of setting all the week schedules to ZERO if you are using a Remote Signal for your scheduling since the Override has priority over the Remote Signal.

VCB-X Configuration Screen Index

VCB-X Configuration Screen Index

The available Configuration Screens for the VCB-X Controller are listed on the next few pages by sequential screen number. When each VCB-X Controller is configured for the first time, it is best to start with screen #1 and proceed to each screen in numerical order until you have viewed all available Configuration Screens. This ensures that you have seen all the available VCB-X Controller configuration possibilities and have the opportunity to change or accept the defaults for each screen.

Once the unit is configured and you decide to change one of the screen options, it is helpful to know what screen number contains the configuration you wish to change. With this in mind, the following is a list of all the VCB-X Configuration Screens in numerical order with a brief listing of the configuration feature available on each screen.

Screen #1	Sensor Scaling (Fahrenheit / Celsius)	Screen #35	Building Pressure Control Rate & Max Increment
Screen #2	EM1 Expansion Module Installed	Screen #36	Exhaust Fan Output
Screen #3	EM2 Expansion Module Installed	Screen #37	Heat Pump Config
Screen #4	MHGRV-X and MODGAS-X Installed	Screen #38	WSHP Glycol Percentage
Screen #5	12 Relay E-BUS Expansion Module Installed	Screen #39	Aux Heat Type
Screen #6	Preheat-X Controller Installed	Screen #40	Dehumidification Control
Screen #7	HVAC Mode Enable Source	Screen #41	Humidity Control Sensor Type
Screen #8	HVAC Mode Set By Remote Contact	Screen #42	Suction Pressure Sensor Installed
Screen #9	SAT Reset Source	Screen #43	E-BUS Space and Humidity Sensor Installed
Screen #10	Reset Rate Interval	Screen #44	Reheat Control
Screen #11	Return Sensor Type	Screen #45	Defrost Coil Switch
Screen #12	Static Pressure Control	Screen #46	Head Pressure Control
Screen #13	Static/Fan Control Rate & Max Increment	Screen #47	Condenser Fan Min/Max
Screen #14	Fan Voltage Output - Min/Max	Screen #48	Has Water Side Condenser
Screen #15	Supply Fan Cycle Mode	Screen #49	Type of Airflow Station
Screen #16	Fan Proving	Screen #50	Monitor Outdoor Air Airflow
Screen #17	Fan Starting Delay	Screen #51	Control Outdoor Air Airflow
Screen #18	Purge Mode Delay	Screen #52	Outdoor Airflow Duct Size
Screen #19	Heat Type	Screen #53	Monitor Supply Air Airflow
Screen #20	Modulating Heat Output Signal - Min/Max	Screen #54	Supply Airflow Duct Size
Screen #21	Cool Type	Screen #55	Monitor Return Air Airflow
Screen #22	Digital Compressor For Mod Cool	Screen #56	Return Airflow Duct Size
Screen #23	Modulating Cooling Output Signal - Min/Max	Screen #57	Monitor Exhaust Airflow
Screen #24	Mech Heat/Cool Alarm Delay	Screen #58	Exhaust Airflow Duct Size
Screen #25	Economizer Control Type	Screen #59	Morning Warm Up Type
Screen #26	Title 24 Economizer	Screen #60	AHU Uses Schedule Number
Screen #27	Economizer in Unoccupied Mode	Screen #61	Daylight Adjustment Start/Stop Date
Screen #28	Outdoor Air Sensor Installed	Screen #62	Trend Log Rate
Screen #29	E-BUS Outdoor Air/RH Sensor	Screen #63	Emergency Shutdown
Screen #30	Economizer Enable Source	Screen #64	Dirty Filter
Screen #31	Economizer Control Loop Rate/Proportional Window	Screen #65	Broadcast Outdoor Air Temperature
Screen #32	Economizer Voltage Output - Min/Max	Screen #66	Broadcast Outdoor RH
Screen #33	CO ₂ Sensor Installed	Screen #67	Broadcast Building Pressure
Screen #34	Building Pressure Control	Screen #68	Broadcast to Boxes
		Screen #69	Cool Stage Up and Down Delays
		Screen #70	Cool Stage Min Run and Min Off Delays
		Screen #71	Heat Stage Up and Down Delays
		Screen #72	Heat Stage Min Run and Min Off Delays
		Screen #73	Heat Pump Delays - Aux/Emergency Heat
		Screen #74	Heat/Cool Changeover Delay
		Screen #75	Return Air Bypass Control
		Screen #76	Morning Cool Down
		Screen #77-81	VCB-X Relay Configuration Screens
		Screen #82-86	EM1 Relay Configuration Screens
		Screen #87-99	12 Relay Configuration Screens

Configuration Screens

In order to correctly set up the VCB-X Controller, you must first configure several parameters in regard to the type of HVAC unit and system you have installed. Most of these values and operating parameters are only set once at the initial system setup and are never changed.

Modular Service Tool Instructions

No matter what screen or menu you're in, press **<CONFIGURATION>**. The *Unit Selection Screen* will appear, shown below, requesting that you enter the unit ID number.

```
Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication
```

Enter the correct unit ID number of the VCB-X Controller you want to configure and then press **<ENTER>**. Once communication is established, "No Communication" will be replaced with "Press Down." Then press **<↓>**. You will then see *Unit Configuration Screen #1*. Press **<ENTER>** to save entered data and press **<↓>** to scroll through the screens.

NOTE: If "No Communication" remains, it indicates a communication failure to the controller.

System Manager SD Instructions

From any Main screen, press **<SETPOINTS>**. The screen below will appear because this option requires passcode clearance. Only a Level 2 passcode can change setpoints.

```
THIS ACTION REQUIRES
PASSCODE CLEARANCE
Enter Passcode: XXXX
```

If the correct passcode was entered, the *Unit Selection Screen* will be displayed.

```
Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication
```

Enter the Unit ID of the controller you wish to change schedules for and press **<ENTER>**. Once communication is established, "No Communication" will be replaced with "Press Down." Then press **<↓>**.

NOTE: If "No Communication" remains, it indicates a communication failure to the controller.

The following screen will be displayed:

```
Change Setpoints
Configure Unit
Save/Copy/Restore
```

Scroll down to the 'Configure Unit' option and press **<ENTER>**. This will take you to the first Configuration Screen shown below.

Configuration Screen #1 - Sensor Scaling

```
VCBX Cnfg ID 101
Sensor Scaling
Fahrenheit
Use < Or > To Change
```

Options are Fahrenheit or Celsius. If you make a change to this screen, the last line will display the following: UNIT RESTARTING XX. The screen will display the countdown of 20 and then the last line will display the prompt *Press Enter to Cont.* **Default is Fahrenheit.**

Configuration Screen #2 - EM1 Expansion Module Installed

```
VCBX Cnfg ID 101
EM1 Installed: NO
Use < Or > To Change
```

If you have expansion module EM1 installed, this configuration option should be configured as YES. **Default is NO.** If your unit utilizes the following, an EM1 Module is required:

- VAV Capabilities
- Building Pressure
- Head Pressure Control
- Return Air Temperature
- Remote Forced Occupied
- Water Source Heat Pump Monitoring
- Modulating Chilled Water
- Water Temperature
- Hood On/Off
- Proof of Flow
- Condenser Control

VCB-X CONFIGURATION

VCB-X Configuration Screens

Configuration Screen #3 - EM2 Expansion Module Installed

VCBX Cnfg ID 101
EM2 Installed: NO
Use < Or > To Change

If you have expansion module EM2 installed, this configuration option should be configured as YES. **Default is NO.** If your unit utilizes the following, an EM2 Module is required:

- Remote SAT Reset
- Remote Forced Cooling
- Return Air Bypass Control
- Remote Forced Heating
- Remote Forced Dehumidification

Configuration Screen #4 - MHGRV-X & MODGAS-X Installed

VCBX Cnfg ID 101
MHGRV Installed: NO
MODGS Installed: NO
Use < Or > To Change

If you have an MHGRV-X Controller installed, the first configuration option should be configured as YES. If you have a MODGAS-X Controller installed, the second configuration option should be configured as YES. **Defaults are NO.**

Configuration Screen #5 - 12 Relay E-BUS Expansion Module Installed

VCBX Cnfg ID 101
12RLY Installed: NO
Use < Or > To Change

If you have a 12 Relay E-BUS Expansion Module installed, this configuration option should be configured as YES. **Default is NO.**

Configuration Screen #6 - PREHEAT-X Controller Installed

VCBX Cnfg ID 101
Preheat-X
Installed: NO
Use < Or > To Change

If you have a PREHEAT-X Controller installed, this configuration option should be configured as YES. **Default is NO.**

Configuration Screen #7 - HVAC Mode Enable Source

VCBX Cnfg ID 101
HVAC Source
Single Zone VAV
Use < Or > To Change

This selection will determine which sensor will determine the mode of operation of the unit and how it will operate. If selecting HVAC Source Set by Remote Contact as YES in the next screen, you should select Outdoor Air as the HVAC Source in this screen. If you will be using a BACnet command to determine the HVAC mode, then you can leave the selection on this screen at the default. **Default is Single Zone VAV.** Available options are:

- **Single Zone VAV**—Recirculating unit using the Space Temperature Sensor to determine the mode of operation. Heating and Cooling are controlled to a Leaving Air Setpoint. Space Temperature resets the Supply Fan VFD speed to maintain the Space Temperature. Modulating Heating and Cooling must be used for this operation. Can be configured for CAV Heating using staged Heat.
- **Space Temperature**—Typical recirculating unit using a Space Temperature Sensor to determine the Heating, Cooling, and Vent Modes of operation.
- **Outdoor Air**—This is for a 100% Outdoor Air Unit (MUA) using the Outdoor Air Temperature Sensor to determine the Heating, Cooling, and Vent Modes of operation. Dehumidification utilizes an Outdoor Air Dewpoint Setpoint. Also use this configuration if the next screen will be configured for Modes Set By Remote Contact.
- **Supply Air**—This is for a standard Cooling Only VAV unit with optional Morning Warm Up. In the Occupied Mode, the unit will be in the Cooling Mode controlling to the Cooling Supply Air Setpoint.
- **Supply Air/Tempering**—This selection is for VAV “cooling only” applications where because of cold outdoor temperatures, heat may need to be added in order to maintain the “Cooling” Supply Air Setpoint. This application requires outdoor Cooling and Heating Setpoints configured using the Hood On Enable Setpoints, to initiate Cooling and Heating Modes. The Heating Supply Air Setpoint should be set at least 2°F below the Cooling Supply Air Setpoint. See the Sequence of Operations for details.
- **Return Air**—Optional recirculating unit configuration using the Return Temperature Sensor to determine the Heating, Cooling, and Vent Modes of operation.
- **Space Temperature with High % OA**—If it is preferable to use Space conditions (instead of Outside Air) to control a 100% or high percentage outdoor air unit, this option allows tempering of the outdoor air in the Space Vent Mode of operation to prevent dumping of hot or cold air into the space. See the Sequence of Operations for details.
NOTE: If this option is selected, the Economizer must be set to **Standard Economizer**.

VCB-X Configuration Screens

Configuration Screen #8 - HVAC Mode Set By Remote Contact

```
VCBX Cnfg ID 101
HVAC Mode Set By
Remote Contact: NO
Use < Or > To Change
```

If you have an EM2 Expansion Module, this option allows separate 24 VAC wet contact closures on that module to force the unit into Heating, Cooling, and Dehumidification modes. If this option is selected, it applies to all three modes, and all three modes will only be initiated by these contact closures. **If this is configured for YES, set the previous screen to Outdoor Air.** See the VCB-X Remote Contact Control section of the Sequence of Operations in the *VCB-X Controller Field Technical Guide* for more details. **Default is NO.**

Configuration Screen #9 - SAT Reset Source

```
VCBX Cnfg ID 101
SAT Reset Source
No Reset
Use < Or > To Change
```

This configuration option is not available if Single Zone VAV was selected as the HVAC source. The Supply Air Setpoint can be “automatically” adjusted based on a selected reset source. This screen allows you to choose this source. **Default is No Reset.** The available selections are as follows:

- **No Reset**—No SAT Setpoint Reset will occur. The SAT Setpoints remain fixed.
- **Space Temperature**—The SAT Setpoints will be adjusted based on the Space Temperature.
- **Outdoor Temperature**—The SAT Setpoints will be adjusted based on the Outdoor Air Temperature.
- **Return Air Temperature**—The SAT Setpoints will be adjusted based on the Return Air Temperature.
- **Fan VFD Signal**—The SAT Setpoints will be adjusted based on the VFD Signal. This is good for Adjusting the Setpoints based on the building’s load by looking at the VFD speed.
- **Remote Voltage**—The SAT Setpoints will be adjusted based on the Remote Supply Air Temperature Voltage Reset Signal.

If the HVAC Source was set Single Zone VAV in Configuration Screen #5, then line 3 on this screen will read No SAT Rst Allowed and the line 4 will be blank.

Configuration Screen #10 - Reset Rate Interval

```
VCBX Cnfg ID 101
Reset Interval
Rate...: 30 s
[1-255 Seconds]
```

If you selected a Reset Source in Screen #6, *enter* a value in seconds between 1-255. This value determines how fast the Supply Air Temperature Setpoint is adjusted as the Reset Source changes. **Default is 30 seconds.**

Configuration Screen #11 - Return Sensor Type

```
VCBX Cnfg ID 101
Return Sensor Type
NONE
Use < Or > To Change
```

If this unit has a Return Air Sensor installed, *select* RETURN AIR if it is a temperature sensor only. Select RETURN AIR WITH RH if it is a combination communicating temperature and humidity sensor. **Default is NONE.**

Configuration Screen #12 - Static Pressure Control

```
VCBX Cnfg ID 101
Static Pr Control
Fan VFD / SZ VAV
Use < Or > To Change
```

This configuration option is available if expansion module EM1 is installed and configured or if using SZ VAV operation. **Default is Fan VFD/SZ VAV.** The options are:

- **None**—This unit is not controlling Duct Static Pressure.
- **Fan VFD / SZ VAV**—This unit has a Supply Fan VFD that modulates to control the Duct Static Pressure or this is a Single Zone VAV application.
- **Bypass Damper**—This unit uses a Bypass Damper to control the Duct Static Pressure.

Configuration Screen #13 - Static/Fan Control Rate & Max Increment

```
VCBX Cnfg ID 101
Static/Fan Control
Rate...: 10 s
Max Increment: 5%
```

This value determines the time interval between changes to the Supply Fan Speed or the Bypass Damper Position during duct static pressure control. It also determines the time interval between changes to the Fan Speed during Single Zone VAV Reset of the Supply Fan VFD Speed. **Default is 10 seconds.** The Maximum Increment is the maximum amount the Static Control can change per control rate period. **Default is 5%.**

Description	Minimum	Default	Maximum
Static/Fan Control Rate	1 sec	10 sec	30 sec
Max Increment	1%	5%	30%

VCB-X CONFIGURATION

VCB-X Configuration Screens

Configuration Screen #14 - Fan Voltage Output

VCBX Cnfg ID 101
Fan Voltage Output
Min Volts: 0.0
Max Volts: 10.0

Enter a value between 0.0 and 10.0 VDC for the main fan's minimum and maximum output voltage. The *Duct Static Pressure Output Status Screen* will display 0% to 100%, but the output will range from the minimum value set on this screen to the maximum value set on this screen.

The VCB-X will reverse the logic of the output signal when a Zoning Bypass Damper is used. **Defaults are 0 VDC Min and 10 VDC Max.**

Description	Minimum	Default	Maximum
Minimum Fan Voltage	0	0	10
Maximum Fan Voltage	0	10	10

Configuration Screen #15 - Fan Cycle Mode

VCBX Cnfg ID 101
Fan Cycle Mode
NO
Use < Or > To Change

Select YES if you want the HVAC unit's Supply Fan to only run during Heating or Cooling Mode. If you want the HVAC unit's Supply Fan to run continuously while in the Occupied Mode, regardless of the Heating or Cooling Mode, select NO. **Default is NO.**

Configuration Screen #16 - Fan Proving

VCBX Cnfg ID 101
Fan Proving
NO
Use < Or > To Change

Select YES if the unit is equipped with a Proof of Flow Switch and it is connected to the VCB-X. If selected as YES and the Proof of Flow Switch is open, only the Supply Fan Relay will be active. If any other relays such as Heating Stages or Cooling Stages are active, they will be deactivated when the Proof of Flow Switch input is lost. **Default is NO.**

Configuration Screen #17 - Fan Starting Delay

VCBX Cnfg ID 101
Fan Starting
Delay: -1 s
[-1 = Unit Addr x 5]

Enter the number of seconds you want the fan to delay starting. This is the Supply Fan Starting Delay initiated whenever the VCB-X initiates Supply Fan operation upon going occupied or after power-up. This is useful when you are using multiple VCB-X-controlled HVAC units and want to be sure that all the units do not start at exactly the same time when the Occupied schedule occurs. Each VCB-X should be set with staggered Fan Starting Delay Setpoint values. When the -1 value is used, it multiplies each VCB-X Controller's address by 5 and uses this value in seconds as the Fan Starting Delay. This provides a staggered start for each VCB-X Controller on the system without having to individually set each VCB-X Controller for its own time delay. For a MUA unit, this should be set to a minimum of 60 seconds to let the OA Damper open. **Default is -1 second.**

Description	Minimum	Default	Maximum
Fan Start Delay Timer	-1 Sec	-1 Sec	240 Sec

Configuration Screen #18 - Purge Mode Delay

VCBX Cnfg ID 101
Purge Mode
Delay: 10 Sec
[0 - 900 Seconds]

Enter the number of seconds you want the unit to stay in Purge Mode before going into Occupied Mode. In Purge Mode, the fan runs with the Outdoor Air Damper closed and all Cooling and Heating is de-energized. For a MUA unit, this should be set to 0 seconds to prevent a Purge Mode (which is a damper closed operation). **Default is 10 seconds.**

Description	Minimum	Default	Maximum
Purge Mode Delay	0 sec	10 sec	900 sec

Configuration Screen #19 - Heat Type

VCBX Cnfg ID 101
Heat Type
No Heat
Use < Or > To Change

Default is No Heat. Available options are:

- **No Heat**—The unit has no Heat.
- **Staged Only**—On/Off Hot Water or fixed stage(s) of Heat.
- **Mod Heat Only**—Only fully modulating forms of Heat which would be Modulating Hot Water or Steam Heat or Modulating SCR Electric Heat. Does not include Modulating Gas using the AAON® MODGAS-X Controller.

VCB-X Configuration Screens

- **Mod Heat Then Staged**—Fully modulating Heat as the 1st form of Heat and Stage(s) of Heat as the 2nd form of Heat.
- **Mod Gas Heat Only**—Only Modulating Gas Heat controlled by the AAON® MODGAS-X Controller.
- **Mod Gas Then Staged**—ModGas Heat as the 1st form of Heat and Stage(s) of Heat as the 2nd form of Heat.

See the *VCB-X Controller Field Technical Guide* for a more detailed description of these operations.

NOTE: This screen does not apply to Heat Pump Units. For Heat Pump Units, use *Configuration Screen #39 - Auxiliary Heating* for configuration.

Configuration Screen #20 - Modulating Heat Output Signal

VCBX Cnfg ID 101
Mod Heat Volt Output
Min Pos Volts: 0.0
Max Pos Volts: 10.0

Enter a value between 0.0 and 10.0 VDC for the Modulating Heat minimum and maximum output voltage. When performing reverse acting heating, the minimum position volts will be the highest value. **Defaults are 0 VDC Min and 10 VDC Max.**

Description	Minimum	Default	Maximum
Minimum Position Volts	0	0	10
Maximum Position Volts	0	10	10

Configuration Screen #21 - Cool Type

VCBX Cnfg ID 101
Cool Type
No Cooling
Use < Or > To Change

Default is No Cooling. Available options are:

- **No Cooling**—The unit has no Cooling.
- **Staged Only**—On/Off Chilled Water or fixed stage(s) DX Cooling only.
- **Mod Only**—Modulating Chilled Water or Digital Scroll Compressors.
- **Mod Then Staged**—Digital Scroll Compressor(s) as the 1st form of Cooling and fixed stage(s) of Cooling as the 2nd form of Cooling.

Configuration Screen #22 - Digital Compressor For Modulating Cooling

VCBX Cnfg ID 101
Digital Comp For
Mod Cool: NO
Use < Or > To Change

Select YES if your HVAC unit is using a Digital Compressor. If Modulating Cooling is selected on the previous screen, this value will automatically change to YES. **Default is NO.**

Configuration Screen #23 - Modulating Cooling Output Signal

VCBX Cnfg ID 101
Mod Cool Volt Output
Min Pos Volts: 0.0
Max Pos Volts: 10.0

Enter a value between 0.0 and 10.0 VDC for the Modulating Cooling minimum and maximum output voltage. When performing reverse acting cooling, the minimum position volts will be the highest value. This configuration only applies to Chilled Water applications. **Defaults are 0 VDC Min and 10 VDC Max.**

Description	Minimum	Default	Maximum
Minimum Position Volts	0	0	10
Maximum Position Volts	0	10	10

Configuration Screen #24 - Mechanical Heat/Cool Alarm Delay

VCBX Cnfg ID 101
Mech Heat/Cool
Alarm Delay: 15 Min

Enter a time delay between 0-240 minutes for a delay in the time that it takes an alarm to be generated. When Heating or Cooling Mode is initiated and staging is activated, if the Supply Air Temperature does not rise or fall 5°F within this time period, a Mechanical Heating or Cooling failure alarm will be generated. The Alarm is for Status Reporting only. The HVAC unit will continue to run. This alarm does not apply if Modulating Cooling or Heating are configured. **Default is 15 Minutes.**

Description	Minimum	Default	Maximum
Mechanical Heat/Cool Failure Alarm Delay	0 Min	15 Min	240 Min

VCB-X CONFIGURATION

VCB-X Configuration Screens

Configuration Screen #25 - Economizer Control Type

VCBX Cnfg ID 101
Econo Control Type
No Economizer
Use < Or > To Change

Default is No Economizer. Available options are:

- **No Economizer**
- **Standard Economizer**
- **IAQ Economizer (Economizer with CO₂ Override)**

Select Standard Economizer if the HVAC Mode Enable Source is set to Space Temperature with High Percentage OA.

Configuration Screen #26 - Title 24 Economizer

VCBX Cnfg ID 101
Title 24
Economizer: NO
Use < Or > To Change

If this unit has Title 24 Economizer operation, this option should be configured as YES. **Default is NO.**

Configuration Screen #27 - Economizer in Unoccupied Mode

VCBX Cnfg ID 101
Econo Control In
Unoc Mode: NO
Use < Or > To Change

Select YES for the Economizer to operate in the Unoccupied Cooling Mode. **Default is NO.**

- **NO**—You want the Economizer to always remain fully Closed in the Unoccupied mode.
- **YES**—You want to use the Economizer as necessary during Unoccupied Night Setback cooling calls. It will be utilized just as it would be in the Occupied mode with the same outdoor enable temperature. If not being used for Night Setback Free Cooling, the Economizer will be closed.

Configuration Screen #28 - Outdoor Air Sensor

VCBX Cnfg ID 101
Outdoor Air Sensor
Installed: YES
Use < Or > To Change

If this unit has any type of an Outdoor Air Sensor installed, this option should be configured as YES. **Default is YES.**

Configuration Screen #29 - E-BUS Outdoor Air/RH Sensor

VCBX Cnfg ID 101
E-Bus OAT/RH
Sensor: NO
Use < Or > To Change

If the Outdoor Air Sensor installed is an E-BUS Outdoor Air Temperature and Humidity Sensor, *press <0>* to select YES. **Default is NO.**

Configuration Screen #30 - Economizer Enable Source

VCBX Cnfg ID 101
Economizer Enable Source
Drybulb
Use < Or > To Change

This configuration option is available if the unit was configured for Economizer Control. **Default is Drybulb.** Available options are:

- **Drybulb**—If the Outdoor Air Drybulb temperature is below the Economizer Enable Setpoint, the Economizer can be used as the first stage of cooling.
- **Wetbulb (OA RH Sensor needed)**—If the Outside Air Wetbulb temperature is below the Economizer Enable Setpoint, the Economizer can be used as the first stage of cooling.
- **Dewpoint (OA RH Sensor needed)**—If the Outdoor Air Dewpoint temperature is below the Economizer Enable Setpoint, the Economizer can be used as the first stage of cooling.

Configuration Screen #31 - Economizer Control Loop Rate & Proportional Window

VCBX Cnfg ID 101
Economizer Control
Rate: 10 s
Prop Window: 10.0°F

The Economizer Control rate is the time period between changes to the Economizer position. **Default is 10 seconds.** The Economizer Control Proportional Window is the control range of the Modulating Signal above and below the Active Supply Air Temperature Setpoint. The size of the Proportional Window will determine how much of a signal change the controller will make per Time Period for every 1°F the Supply Air Temperature is from setpoint. The maximum signal change per time period is 10% which occurs when the Supply Air Temperature is the full Proportional Window amount from setpoint. So, with a 5° Proportional Window, if the Supply Air Temperature is 5° or more from setpoint, the

VCB-X Configuration Screens

signal change will be 10% per time period. At 4° difference, the signal change will be 8% per time period. By the time the difference is 1°, the signal change will be 2% per time period. With a Proportional Window of 2°, if you are 2° or more from setpoint, the amount of signal change will be 10% per time period, and at 1° from setpoint the change would be 5% per time period. So, a larger proportional window allows for finer tuning of the control signal to prevent overshooting. **Default is 10.0°F/5.55°C.**

Description	Minimum	Default	Maximum
Economizer Control Rate	1 sec	10 sec	30 sec
Proportional Window	1.0°F 0.10°C	10.0°F 5.55°C	30.0°F 16.6°C

Configuration Screen #32 - Economizer Voltage Output

VCBX Cnfg ID 101
Econo Voltage Output
Min Volts: 2.0 VDC
Max Volts: 10.0 VDC

Enter a value between 0.0 and 10.0 VDC for the Economizer minimum and maximum output voltage. **Defaults are 2 VDC Min and 10 VDC Max.**

Description	Minimum	Default	Maximum
Min Economizer Voltage	0	2	10
Max Economizer Voltage	0	10	10

Configuration Screen #33 - CO₂ Sensor Installed

VCBX Cnfg ID 101
Co2 Sensor Installed
None
Use < Or > To Change

Select **Digital E-BUS** if you have an E-BUS CO₂ Sensor installed. Select **Receive Broadcast** if the CO₂ Sensor is attached to a separate device that will broadcast the reading, e.g., GPC-XP Controller. **Default is None.**

Configuration Screen #34 - Building Pressure Control

VCBX Cnfg ID 101
Building Pr. Control
None
Use < Or > To Change

Building Pressure Control is available if expansion module EM1 has been installed and configured. **Default is None.** Available options are:

- **None**—No Building Pressure Control by this controller.
- **On/Off Exh Relay**—If an On/Off Exhaust Fan is being used, select this option and configure a relay output as Exhaust Fan. If the building pressure rises above setpoint, this relay will energize. This is Direct-Acting control.
- **Modulating Exh**—If the building pressure rises above setpoint, a modulating signal will be used to control an exhaust fan VFD or a modulating damper to maintain setpoint. A relay configured as Exhaust Fan can be used to enable this device so that the modulating signal can control it. This is Direct Acting control.
- **OA Damper**—Select if reverse acting Building Pressure Control using the Outdoor Air Damper is required. If the building pressure falls below setpoint, the OA Damper (Economizer) signal will be used to modulate the OA Damper to maintain setpoint. This is Reverse Acting control.
- **Supply Fan**—Contact WattMaster Factory regarding this reverse acting Building Control option. This should not be used in most applications. This is Reverse Acting control.

Configuration Screen #35 - Building Pressure Control Rate & Max Increment

VCBX Cnfg ID 101
Building Pr. Control
Rate: 10 Sec
Max Increment: 5%

The Building Pressure Control Rate is the time period between changes to the Building Pressure Control signal. **Default is 10 seconds.** The Maximum Increment is the maximum amount the Building Pressure Control can change per control rate period. **Default is 5%.**

Description	Minimum	Default	Maximum
Building Pressure Control Rate	1 sec	10 sec	30 sec
Max Increment	1%	5%	30%

VCB-X CONFIGURATION

VCB-X Configuration Screens

Configuration Screen #36 - Exhaust Fan Output

VCBX Cnfg ID 101
Exh Fan Volts
Min Volts: 0 VDC
Max Volts: 10 VDC

This configuration option is available if expansion module EM1 has been installed and configured and if Modulating Building Pressure Control was configured on a previous screen. The following will set the output voltage range for both Direct and Reverse Acting Building Pressure Control. **Defaults are 0 VDC Min Volts and 10 VDC Max Volts.** Available options are:

- **Min Volts**—Voltage at which the signal to exhaust fan, exhaust damper, or OA damper will be at 0% for either Direct or Reverse Acting Building Pressure control.
- **Max Volts**—Voltage at which the signal to exhaust fan, exhaust damper, or OA damper will be at 100% for either Direct or Reverse Acting Building Pressure control.

Description	Minimum	Default	Maximum
Minimum Position Volts	0	0	10
Maximum Position Volts	0	10	10

Configuration Screen #37 - Heat Pump Config

VCBX Cnfg ID 101
Heat Pump Config
No Heat Pump
Use < Or > To Change

Default is No Heat Pump. Available options are:

- **No Heat Pump**—Unit is not a Heat Pump.
- **Air/Air Fail to Heat**—Heat Pump unit activates its Reversing Valve during Cooling operation.
- **Air/Air Fail to Cool**—Heat Pump unit activates its Reversing Valve during Heating operation.
- **WSHP Fail to Heat**—Water Source Heat Pump unit activates its Reversing Valve during Cooling operation.
- **WSHP Fail to Cool**—Water Source Heat Pump unit activates its Reversing Valve during Heating operation.

Configuration Screen #38 - WSHP Glycol Percentage

VCBX Cnfg ID 101
WSHP Glycol
Percentage: 0%
Use < Or > To Change

If this is a Water Source Heat Pump Unit, this screen allows you to configure the percentage of glycol in your unit. Options are 0% to 40% in 5% increments. **Default is 0%.**

Configuration Screen #39 - Aux Heat Type Value

VCBX Cnfg ID 101
Aux Heat Type
No Aux Heat
Use < Or > To Change

If this is a Heat Pump, choose the appropriate Aux Heat option. **Default is No Aux Heat.** Available options are:

- **No Aux Heat**—This unit does not have Heat Pump Auxiliary Heat.
- **Staged Only**—This unit has a stage(s) of Auxiliary Heat. Multiple relays can be configured as Aux Heat in which case the relays will stage up as required.
- **Modulating Only**—This unit has a form of modulating heat being used as Auxiliary Heat. ModGas cannot be used as the modulating heat source.
- **Mod Then Staged**—This unit has modulating heat that will be used as the 1st form of Auxiliary Heat followed by a stage(s) of Aux Heat.
- **ModGas Only**—This unit has Modgas which will be used as Auxiliary Heat.

Configuration Screen #40 - Dehumidification Control

VCBX Cnfg ID 101
Dehum. Control:
None
Use < Or > To Change

If using Dehumidification choose the appropriate Dehumidification option. **Default is None.** Available options are:

- **None**—The unit does not have a Dehumidification Mode.
- **Only Occupied Vent**—The unit can only enter Dehumidification during the Occupied Vent Mode (when there is no call for Cooling or Heating).
- **Only Vent Anytime**—The unit can only enter Dehumidification during the Vent Mode (when there is no call for Cooling or Heating) in both the Occupied and Unoccupied operation.

VCB-X Configuration Screens

- **All Modes Occupied**—This is Occupied Mode Dehumidification Priority. The unit can enter Dehumidification during Cooling, Heating, or Vent Modes, but only while in Occupied operation.
- **All Modes Anytime**—This is Occupied and Unoccupied Dehumidification Priority. The unit can enter Dehumidification during Cooling, Heating, or Vent Modes while in Occupied or Unoccupied operation.

For units controlled by space humidity sensors, Dehumidification is initiated based on an Indoor Humidity Setpoint. For 100% OA units (MUA), Occupied Dehumidification is initiated based on an Outdoor Air Dewpoint Setpoint. For MUA units, Unoccupied Dehumidification can only occur if the unit is configured for Night Setback recirculating operation and has a Space Humidity sensor and a Space Humidity Setpoint.

Configuration Screen #41 - Humidity Control Sensor Type

VCBX Cnfg ID 101
Humidity Control
Sensor: Space
Use < Or > To Change

Select Space, Return, or Outdoor if an E-BUS Humidity Sensor is installed. Can receive a Space Humidity broadcast from a GPC-XP if value in *Configuration Screen #43* is selected as NO. **Default is Space.**

Configuration Screen #42 - Suction Pressure Sensor Installed

VCBX Cnfg ID 101
Suction Pr Sensor
Installed: NO
Use < Or > To Change

Select YES if you have a Suction Pressure Sensor Installed. **Default is NO.**

Configuration Screen #43 - E-BUS Space & Humidity Sensor Installed

VCBX Cnfg ID 101
E-BUS SPC/RH Sensor
Installed: NO
Use < Or > To Change

Select YES if you have an E-BUS Space and Humidity Sensor installed. Set this to NO if receiving a Space Humidity Broadcast from a GPC-XP Controller. **Default is NO.**

Configuration Screen #44 - Reheat Type

VCBX Cnfg ID 101
Reheat Control
None
Use < Or > To Change

This configuration option is available if expansion module EM1 has been installed and configured and if Dehumidification has been configured. If you need Reheat in the Dehumidification mode, this screen allows you to configure what kind of reheat will be used.

The output(s) will be staged or modulated to maintain the Active Supply Air Setpoint. **Default is None.** Select the type of reheat that will be used during dehumidification.

- **None**—No reheat.
- **On/Off HGR Relay**—Single On/Off Reheat stage (Reheat Relay).
- **Mod HGR**—Modulating Hot Gas Reheat (MHGR)
- **Unit Heat**—Using the unit's heat as Reheat when Hot Gas Reheat is not available.
- **Mod HGR then Unit Heat**—Using MHGR as the 1st form of Reheat, supplemented by unit Heat if necessary.
- **On/Off HGR then Unit Heat**—Using "Reheat Relay" stage as the 1st form of Reheat, supplemented by unit Heat if necessary.

Configuration Screen #45 - Defrost Coil Switch

VCBX Cnfg ID 101
Defrost Coil Switch
NO
Use < Or > To Change

Select YES if a Defrost Coil Temperature Switch is installed and is connected to the Defrost Coil Temperature Switch binary input. If this switch closes, it will initiate a Defrost Mode. **Default is NO.**

Configuration Screen #46 - Head Pressure Control

VCBX Cnfg ID 101
Head Pr. Control:
NO
Use < Or > To Change

This configuration option is available if expansion module EM1 has been installed and configured and if Head Pressure Control is required. **Default is NO.**

VCB-X CONFIGURATION

VCB-X Configuration Screens

Configuration Screen #47 - Condenser Fan Outputs

VCBX Cnfg ID 101
Cond Fan Max: 100%
Cond Fan Min: 15%

If using Head Pressure control, you can set the Max and Min signal percentages on this screen. The EM1 Expansion Module must be installed and configured.

Description	Minimum	Default	Maximum
Condenser Fan Max	0	100	100
Condenser Fan Min	0	15	100

Configuration Screen #48 - Has Water Side Condenser

VCBX Cnfg ID 101
Has Water Side Cond.
NO
Use < Or > To Change

This configuration option is available if expansion module EM1 has been installed and configured and if using a Water Side Condenser. Select NO if the unit is configured as Water Source Heat Pump. **Default is NO.**

Configuration Screen #49 - Type of Airflow Station

VCBX Cnfg ID 101
Airflow
Station: Paragon
Use < Or > To Change

Select the type of Airflow Monitoring Station you are using, if any. Selections are Paragon or Ebtron. Choose Ebtron if using Greentrol. **Default is Paragon.**

Configuration Screen #50 - Monitor Outdoor Air Airflow

VCBX Cnfg ID 101
Monitor OA Airflow
NO
Use < Or > To Change

Select YES if you have an Airflow Monitoring station measuring the CFM of the Outdoor Air airflow stream of this unit. **Default is NO.**

Configuration Screen #51 - Control Outdoor Air CFM

VCBX Cnfg ID 101
Control Outdoor Air
CFM: NO
Use < Or > To Change

Select YES if you have an Airflow Monitoring station and are controlling the Outdoor Air Damper to an airflow (CFM) Setpoint. **Default is NO.**

Configuration Screen #52 - Outdoor Airflow Duct Size

VCBX Cnfg ID 101
Outdoor Airflow Duct
Size: 000.00
[In Square Feet]

For the controller to properly calculate the Outdoor Air CFM, you need to *enter* the area in square feet of the Outdoor Air duct/damper. When measuring the Outdoor Air duct damper area, be sure to measure the inside dimensions of the damper. The duct size needs to be accurate to two decimal places. The more accurate the measurements, the more accurate the CFM reading will be. **Default is 0.**

Description	Minimum	Default	Maximum
Outdoor Air Airflow Duct Size	0	0	200.00

Configuration Screen #53 - Monitor Supply Air Airflow

VCBX Cnfg ID 101
Monitor SA Airflow
NO
Use < Or > To Change

Select YES if you have an Airflow Monitoring station measuring the CFM of the Supply Air airflow stream of this unit. **Default is NO.**

Configuration Screen #54 - Supply Airflow Duct Size

VCBX Cnfg ID 101
Supply Airflow Duct
Size: 000.00
[In Square Feet]

For the controller to properly calculate the Supply Air CFM, you need to *enter* the area in square feet of the Supply Air duct/damper. When measuring the Supply Air duct damper area, be sure to measure the inside dimensions of the damper. The duct size needs to be accurate to two decimal places. The more accurate the measurements, the more accurate the CFM reading will be. **Default is 0.**

VCB-X Configuration Screens

Description	Minimum	Default	Maximum
Supply Air Airflow Duct Size	0	0	200.00

Configuration Screen #55 - Monitor Return Air Airflow

VCBX Cnfg ID 102
Monitor RA Airflow
NO
Use < Or > To Change

Select YES if you have an Airflow Monitoring station measuring the CFM of the Return Air airflow stream of this unit. **Default is NO.**

Configuration Screen #56 - Return Airflow Duct Size

VCBX Cnfg ID 101
Return Airflow Duct
Size: 000.00
[In Square Feet]

For the controller to properly calculate the Return Air CFM, you need to *enter* the area in square feet of the Return Air duct/damper. When measuring the Return Air duct damper area, be sure to measure the inside dimensions of the damper. The duct size needs to be accurate to two decimal places. The more accurate the measurements, the more accurate the CFM reading will be. **Default is 0.**

Description	Minimum	Default	Maximum
Return Air Airflow Duct Size	0	0	200.00

Configuration Screen #57 - Monitor Exhaust Airflow

VCBX Cnfg ID 101
Monitor Exh Airflow
NO
Use < Or > To Change

Select YES if you have an Airflow Monitoring station measuring the CFM of the Exhaust Air airflow stream of this unit. **Default is NO.**

Configuration Screen #58 - Exhaust Airflow Duct Size

VCBX Cnfg ID 101
Exhaust Airflow Duct
Size: 000.00
[In Square Feet]

For the controller to properly calculate the Exhaust Air CFM, you need to *enter* the inside area in square feet of the Exhaust Air duct/damper. When measuring the Exhaust Air damper area, be sure to measure the inside dimensions of the damper. The duct size needs to be accurate to two decimal places. The more accurate the measurements, the more accurate the CFM reading will be. **Default is 0.**

Description	Minimum	Default	Maximum
Exhaust Airflow Duct Size	0	0	200.00

Configuration Screen #59 - Morning Warm Up

VCBX Cnfg ID 101
Morning Warm Up
None
Use < Or > To Change

You can choose between the following Morning Warm Up options. **Default is None.** Available options are:

- **None**— There is no Morning Warm Up required.
- **Stand Alone**—The VCB-X Controller is not communicating to Orion VAV Box controls, but a Morning Warm Up Relay can be configured to signal boxes by others to open.
- **Bcast Fixed to Boxes**—The VCB-X Controller is communicating to Orion VAV Boxes and will broadcast a command to the boxes to go to a Fixed Percentage Position or Airflow while in Morning Warm Up. This fixed position is configured in the VAV Box Controller.
- **Bcast Max to Boxes**—The VCB-X Controller is communicating to Orion VAV Boxes and will broadcast a command to the boxes to go to a Maximum Percentage Position or Airflow while in Morning Warm Up. This maximum position is configured in the VAV Box Controller.

Configuration Screen #60 - AHU Uses Schedule Number

VCBX Cnfg ID 101
AHU Uses Schedule
Number: 0
['0' For Internal]

The VCB-X has an internal schedule. If you want the VCB-X to use its own internal schedule, *enter* <0> for Internal.

VCB-X CONFIGURATION

VCB-X Configuration Screens

External Schedules are available by using one of the GPC-X family of General Purpose Controllers. Depending on which generation of GPC-X Controller you have, you may have up to 5 or up to 8 schedules available to use. To use the schedules on one of these controllers, enter the number of the schedule on that controller (either 1 through 5 or 1 through 8) you will be using. **Default is 0.**

Description	Minimum	Default	Maximum
AHU Uses Schedule	0	0	8

Configuration Screen #61 - Daylight Savings Adjustment

VCBX Cnfg ID 101
Daylight Adjustment
Start Date: 0000
Stop Date: 0000

If you are in a time zone that does not have daylight savings time or do not want to use this feature, leave these fields blank. Otherwise, *enter* the starting date for Daylight Savings time in the Start Date field and the ending date in the Stop Date field. For example, March 11 = 0311 (DDMM). **Default is 0000.**

Description	Minimum	Default	Maximum
Start Date	0	0	1231
Stop Date	0	0	1231

NOTE: The U.S. government has the authority to determine the switch-over dates each year. Currently, the time changes the second Sunday in March and then switches back the first Sunday in November.

Configuration Screen #62 - Trend Log Rate

VCBX Cnfg ID 101
Trend Log
Rate: 15 Min

An internal Trend Log is constantly updated at a rate equal to this value. Trend Logs can only be accessed with Prism 2 software. **Default is 15 minutes.**

Description	Minimum	Default	Maximum
Trend Log Rate	1 Min	15 Min	120 Min

Configuration Screen #63 - Emergency Shutdown

VCBX Cnfg ID 101
Emergency Shutdown
NO
Use < Or > To Change

Select YES if a Smoke Detector/Firestat or other Emergency Shutdown input is connected to the Emergency Shutdown binary input. If a Shutdown condition occurs and the 24V signal is removed from this input, the Supply Fan and Heating and Cooling Relay Outputs will be de-energized and an alarm will be generated. **Default is NO.**

Configuration Screen #64 - Dirty Filter

VCBX Cnfg ID 101
Dirty Filter
NO
Use < Or > To Change

Select YES if a Dirty Filter switch is connected to the Dirty Filter binary input. If the Dirty Filter input is active, an alarm will be generated. **Default is NO.**

Configuration Screen #65 - Broadcast OA Temp

VCBX Cnfg ID 101
Broadcast OA Temp
NO
Use < Or > To Change

The VCB-X can broadcast its Outdoor Air Temperature Reading to other HVAC units if they are not equipped with their own Outdoor Air Temperature sensors. A network communications device (MiniLink PD or CommLink) is needed in order for this feature to operate. *Select* YES for Broadcast Outdoor Temperature. **Default is NO.**

Configuration Screen #66 - Broadcast OA RH

VCBX Cnfg ID 101
Broadcast OA RH
NO
Use < Or > To Change

The VCB-X can broadcast its Outdoor Air Humidity Reading to other HVAC units if they are not equipped with their own Outdoor Air RH sensors. A network communications device (MiniLink PD or CommLink) is needed in order for this feature to operate. *Select* YES for Broadcast Outdoor RH. **Default is NO.**

VCB-X Configuration Screens

Configuration Screen #67 - Broadcast Building Pressure

VCBX Cnfg ID 101
Broadcast Build. Pr.
NO
Use < Or > To Change

The VCB-X can broadcast Building Pressure from this unit to any other unit requiring this value. *Select YES for Broadcast Building Pressure. Default is NO.*

Configuration Screen #68 - Broadcast to Boxes

VCBX Cnfg ID 101
Broadcast to Boxes
NO
Use < Or > To Change

The VCB-X can broadcast all applicable information and commands to the VAV Boxes. *Select YES for Broadcast to Boxes. Default is NO.*

Configuration Screen #69-#72 - Cool/Heat Stage Delays

VCBX Cnfg ID 101
Cool Stage Delays
Stage Up...: 3 Min
Stage Down: 1 Min

VCBX Cnfg ID 101
Cool Stage Delays
Min Run...: 5 Min
Min Off...: 3 Min

VCBX Cnfg ID 101
Heat Stage Delays
Stage Up...: 3 Min
Stage Down: 1 Min

VCBX Cnfg ID 101
Heat Stage Delays
Min Run...: 5 Min
Min Off...: 1 Min

Both the Heating Stages and the DX Cooling Stages utilize **Staging Up** and **Down** Delay Periods between stages and **Minimum Run** Times and **Off** Times.

See the *VCB-X Controller Technical Guide* for information on how these Delays and Run Times are used.

Description	Minimum	Default	Maximum
Cooling Stage Up	3 Min	3 Min	15 Min
Cooling Stage Down	1 Min	1 Min	15 Min
Cooling Min Run Time	5 Min	5 Min	15 Min
Cooling Min Off Time	3 Min	3 Min	15 Min
Heating Stage Up	3 Min	3 Min	15 Min
Heating Stage Down	1 Min	1 Min	15 Min
Heating Min Run Time	2 Min	5 Min	15 Min
Heating Min Off Time	1 Min	1 Min	15 Min

Configuration Screen #73 - Heat Pump Delays - Aux Heat

VCBX Cnfg ID 101
Heat Pump Delays
Aux Heat...: 3 Min
[1 - 60 Minutes]

If your VCB-X is configured to operate as a Heat Pump, the Heat Pump Auxiliary Heating Delay Setpoint can be configured to provide a time delay period before Auxiliary Heating Stages can be activated once activation of the Compressor Heating Stages have been initiated. **Default is 3 minutes.**

Description	Minimum	Default	Maximum
Aux Heat Delay	0 Min	3 Min	60 Min

Configuration Screen #74 - Heat/Cool Changeover Delay

VCBX Cnfg ID 101
Heat Cool Changeover
Delay: 5 Min

Enter the time in minutes for the time delay when the unit changes over from a call to heating to a call to cooling and vice versa. **Default is 5 minutes.**

Description	Minimum	Default	Maximum
Heat/Cool Changeover Delay	0 Min	5 Min	20 Min

VCB-X Configuration Screens

Configuration Screen #75 - Return Air Bypass Control

VCBX Cnfg ID 101
Return Air Bypass
Control: No
Use < Or > To Change

Select Yes if your HVAC unit requires Return Air Bypass Control for Dehumidification Reheat. **Default is No.** You must have the EM2 Expansion Module installed and configured for this feature.

Configuration Screen #76 - Morning Cool-Down Type

VCBX Cnfg ID 101
Morning Cool-Down
None
Use < Or > To Change

You can choose between the following Morning Cool-Down options. **Default is None.** Available options are:

- **None**—There is no Cool-Down required.
- **Stand Alone**—The VCB-X Controller is not communicating to Orion VAV Box controls, but a Cool-Down Relay can be configured to signal boxes by others to open.
- **Bcast Fixed to Boxes**—The VCB-X Controller is communicating to Orion VAV Boxes and will broadcast a command to the boxes to go to a Fixed Percentage Position or Airflow while in Cool-Down. This fixed position is configured in the VAV Box Controller.
- **Bcast Max to Boxes**—The VCB-X Controller is communicating to Orion VAV Boxes and will broadcast a command to the boxes to go to a Maximum Percentage Position or Airflow while in Cool-Down. This maximum position is configured in the VAV Box Controller.

Configuration Screens #77-81 - VCB-X Relay Configuration Screens

VCBX Cnfg ID 101
On-Board Relay (2-6)
Not Used
Use < Or > To Change

Relay #1 is not configurable as it is reserved for the Supply Air Fan. Relays #2-#6 are configurable for the following options (See **Table 5** for Relay descriptions):

- Not Used (Default)
- Cooling Stage
- Condenser #1
- HP Water Valve
- HP Reversing Valve
- HP Emergency Heat
- Mod Cool Enable
- Reheat
- Low Ambient
- Economizer
- Occupied Mode
- Alarm Active
- Digital Compressor
- Heating Stage
- Condenser #2
- HP Compressor
- HP Aux Heat
- Mod Heat Enable
- Warmup / Cooldown
- Preheat
- Exhaust Fan
- Heat Wheel
- Override Mode

Relays #2 through #6 can be individually configured. Only forms of Heating and Cooling can be configured with multiple relays for staging. If any other option is selected more than once, it will simply activate redundant relays, but no multiple staging will occur. **Default is Not Used.**

Configuration Screens #82-86 - EM1 Relay Configuration Screens

VCBX Cnfg ID 101
EM1 Relay (1-5)
Not Used
Use < Or > To Change

EM1 Relays #1-#5 are configurable for the following options (See **Table 5** for Relay descriptions):

- Not Used (Default)
- Cooling Stage
- Condenser #1
- HP Water Valve
- HP Reversing Valve
- HP Emergency Heat
- Mod Cool Enable
- Reheat
- Low Ambient
- Economizer
- Occupied Mode
- Alarm Active
- Digital Compressor
- Heating Stage
- Condenser #2
- HP Compressor
- HP Aux Heat
- Mod Heat Enable
- Warmup / Cooldown
- Preheat
- Exhaust Fan
- Heat Wheel
- Override Mode

VCB-X Configuration Screens

Relays #1 through #5 can be individually configured. Only forms of Heating and Cooling can be configured with multiple relays for staging. If any other option is selected more than once, it will simply activate redundant relays, but no multiple staging will occur. **Default is Not Used.**

Configuration Screens #87-99 - E-BUS 12 Relay Configuration Screens

```
VCBX Cnfg ID 101
12 Rly Bd (1-12)
Not Used
Use < 0r > To Change
```

The E-BUS 12 Relay Expansion Board Relays #1-#12 are configurable for the following options (See **Table 5** for Relay descriptions):

- Not Used (Default)
- Cooling Stage
- Digital Compressor
- Heating Stage

- Condenser #1
- HP Water Valve
- HP Reversing Valve
- HP Emergency Heat
- Mod Cool Enable
- Reheat
- Low Ambient
- Economizer
- Occupied Mode
- Alarm Active
- Condenser #2
- HP Compressor
- HP Aux Heat
- Mod Heat Enable
- Warmup / Cooldown
- Preheat
- Exhaust Fan
- Heat Wheel
- Override Mode

Relays #1 through #12 can be individually configured. Only forms of Heating and Cooling can be configured with multiple relays for staging. If any other option is selected more than once, it will simply activate redundant relays, but no multiple staging will occur. **Default is Not Used.**

No.	Relay Description	Details
1	Digital Compressor	Configured for a Digital Compressor.
2	Cooling Stage	Configured for each fixed stage of cooling (except heat pump compressor).
3	Heating Stage	Configured for each fixed stage of heating.
4-5	Condenser #1 Condenser #2	Configured for Condenser Fan/Valve operation. This relay(s) will be active anytime the respective compressors are active, except if the unit is in Heat Pump Defrost Mode.
6	Heat Pump Water Valve	On a Water Source Heat Pump, this relay will be active anytime compressors are active.
7	Heat Pump Compressor	Configured for a Fixed Heat Pump Compressor stage.
8	Reversing Valve	Configured for the Reversing Valve of a heat pump unit.
9	Aux Heat	Configured for a fixed stage of Aux Heat in a heat pump unit.
10	Emergency Heat	Configured for a fixed stage Emergency Heat in a heat pump unit.
11	Mod Heat Enable	Configure if a 0-10 VDC Modulating Heat source needs a relay to enable it.
12	Mod Cool Enable	Configure if a 0-10 VDC Modulating Cool source needs a relay to enable it.
13	Morning Warm-Up/ Cool-Down (VAV Boxes)	Configure (1) Relay for Morning Warm-Up/Cool-Down when Non-Orion VAV/Zone Controllers are used.
14	Reheat	Configure (1) Relay for On/Off Reheat when used.
15	Pre-Heat	Configure for Pre-Heat operation.
16	Low Ambient	Configure for Low Ambient operation.
17	Exhaust Fan	Configure (1) Relay for enabling exhaust fan when Building Pressure Control is used.
18	Economizer Active	If configured, this relay will energize if unit is in Economizer mode and the damper has moved 5% above its Economizer Minimum Setpoint position.
19	Heat Wheel	Configure (1) Relay that turns heat wheel on when in Occupied operation and turns heat wheel off when in Economizer Mode.
20	Occupied Active	If configured, this relay will energize whenever the unit is in the Occupied Mode.
21	Override Active	If configured, this relay will energize anytime the space sensor Push-button override is active.
22	Alarm Active	If configured, this relay will energize anytime a VCB-X alarm is active.

Table 5: User-Configurable Relay Outputs

VCB-X Setpoint Screens

Setpoint Screen Index

The available Setpoint Screens for the VCB-X Controller are listed on the next few pages by sequential screen number. When each VCB-X Controller is configured for the first time, it is best to start with screen #1 and proceed to each Setpoint Screen in numerical order until you have viewed all available Setpoint Screens. This ensures that you have seen all of the available VCB-X Controller Setpoint possibilities and have the opportunity to change or accept the defaults for each screen. Once the unit Setpoints are configured and you decide to change one of the screen options, it is helpful to know what screen number contains the configuration you wish to change. With this in mind, the following is a list of all the VCB-X Setpoint Screens in numerical order with a brief listing of the Setpoint feature available on each screen:

Screen #1	Occupied HVAC Cool/Heat	Screen #25	Mod Heat Proportional Window and Time Period
Screen #2	Hood On HVAC Setpoints	Screen #26	Mod Cool Proportional Window and Time Period
Screen #3	Unoccupied Offsets	Screen #27	Head Pressure Setpoints - Cooling and Reheat
Screen #4	Mode Deadband Setpoint	Screen #28	Economizer Enable Setpoint
Screen #5	Space Sensor Slide Adjust	Screen #29	Economizer Minimum Damper Position
Screen #6	Calibrate Slide Adjust at Up Position	Screen #30	Maximum Economizer Position in Heat Mode
Screen #7	Calibrate Slide Adjust at Middle Position	Screen #31	Min Outdoor Airflow Setpoint and Deadband
Screen #8	Calibrate Slide Adjust at Down Position	Screen #32	Economizer Maximum Position in High CO ₂
Screen #9	Space Sensor Push-Button Override Duration	Screen #33	CO ₂ Setpoints Min/Max
Screen #10	Controlling Sensor High Alarm Offset	Screen #34	CO ₂ Altitude Setpoint
Screen #11	Controlling Sensor Low Alarm Offset	Screen #35	Building Pressure Setpoint and Deadband
Screen #12	Outdoor Dewpoint Setpoint	Screen #36	OAT Lockouts - Comp Cool/Comp Heat
Screen #13	Indoor RH Setpoints	Screen #37	OAT Lockouts Heat
Screen #14	Coil (Saturation) Temperature Setpoints	Screen #38	Supply Air Cutoffs - Cooling/Heating
Screen #15	Static Pressure Setpoint and Deadband	Screen #39	Hot Water Valve Protection Position
Screen #16	VFD Speed Limits - Min Cool/Min Vent	Screen #40	Preheat Relay Setpoint
Screen #17	VFD Speed Limits - Min/Max Heat	Screen #41	Low Ambient Setpoint
Screen #18	Supply Air Cooling Setpoint and High Reset Limit	Screen #42	Heat Pump Defrost Interval
Screen #19	Cool Reset Source Setpoints - If High Space, then SAT	Screen #43	Adaptive Defrost Interval Adjustment
Screen #20	Cool Reset Source Setpoints - Low Space/High Reset/VFD	Screen #44	Heat Wheel Defrost
Screen #21	Supply Air Heating Setpoint and High Reset Limit	Screen #45	Morning Warm Up Max Length and Target Temp
Screen #22	High Reset Source Setpoints - High Space/SAT/VFD	Screen #46	Space Sensor Calibration - Current and Offset
Screen #23	High Reset Source Setpoints - Low Space/High Reset/VFD	Screen #47	RAT Sensor Calibration - Current and Offset
Screen #24	Stage Off Window Cooling/Heating	Screen #48	SAT Sensor Calibration - Current and Offset
		Screen #49	Coil Sensor Calibration - Current and Offset
		Screen #50	OAT Sensor Calibration - Current and Offset
		Screen #51	CO ₂ Sensor Calibration - Current and Offset
		Screen #52	Leaving Water Temperature Sensor Calibration - Current and Offset
		Screen #53	SZ VAV Integral Constant
		Screen #54	Return Air Bypass Damper Factor Setpoint
		Screen #55	Warm-Up Supply Air Temperature Setpoint
		Screen #56	Cool-Down Supply Air Temperature Setpoint
		Screen #57	Preheat-X Setpoints - Cooling & Heating Mode
		Screen #58	Preheat-X Setpoint - Venting Mode

Setpoints - General Procedures

Modular Service Tool Instructions

From any menu screen, *press* **<SETPOINTS>**. The *Unit Selection Screen*, shown below, will appear requesting that you enter the unit ID number.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the correct unit ID number of the VCB-X Controller you want to change Setpoints for and *press* **<ENTER>**. Once communication is established, “No Communication” will be replaced with “Press Down.” Then *press* **<↓>**. You will then see Setpoint Screen #1. *Press* **<ENTER>** to save entered data and *press* **<↓>** to scroll through the screens.

NOTE: If “No Communication” remains, it indicates a communication failure to the controller.

System Manager SD Instructions

From any Main screen, *press* **<SETPOINTS>**. The screen below will appear because this option requires passcode clearance. Only a Level 2 passcode can change setpoints.

THIS ACTION REQUIRES
PASSCODE CLEARANCE
Enter Passcode: XXXX

If the correct passcode was entered, the *Unit Selection Screen* will be displayed.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the Unit ID of the controller you wish to change schedules for and *press* **<ENTER>**. Once communication is established, “No Communication” will be replaced with “Press Down.” Then *press* **<↓>**.

NOTE: If “No Communication” remains, it indicates a communication failure to the controller.

The following screen will be displayed:

Change Setpoints
Configure Unit
Save/Copy/Restore

Scroll to the ‘Change Setpoints’ option and *press* **<ENTER>**. This will take you to the first Setpoints Screen shown below.

Setpoint Screen #1 - Occupied HVAC Cool/Heat Setpoints

VCBX Spts ID 101
Occupied HVAC Spts
Cooling: 75.0°F
Heating: 70.0°F

These Setpoints are used to determine the Heating, Cooling, or Vent Mode of operation in CAV applications using the Space or Return Air Temperature Sensor as the Mode Enable Sensor (HVAC Source) or in Make Up Air (MUA) applications using the Outdoor Air Temperature Sensor as the Mode Enable Sensor (HVAC Source).

Description	Minimum	Default	Maximum
HVAC Mode Setpoints Cooling	1°F (-17.2°C)	75°F (24°C)	110°F (43.3°C)
HVAC Mode Setpoints Heating	1°F (-17.2°C)	70°F (21°C)	110°F (43.3°C)

Setpoint Screen #2 - Hood On HVAC Setpoints - OAT Cool, OAT Heat

VCBX Spts ID 101
Hood On HVAC Spts
OAT Cool: 75.0°F
OAT Heat: 70.0°F

These setpoints are used for three different applications.

CAV/MUA Dual Mode (Hood On/Off)—In CAV (Hood Off) operation, the unit will use the Occupied HVAC Setpoints from Setpoint Screen #1 in reference to a Space or Return Air Temperature Sensor. When exhaust hoods are turned on and the Hood On contact closes, the unit switches from CAV Space Temperature Control to MUA Outdoor Air Temperature control operation (Hood On). At this point the Outdoor Damper modulates to full open, and these Hood On setpoints become the Outdoor Air Temperature Mode Enable Setpoints.

When the exhaust hoods are turned off and the Hood On contact opens, the unit reverts back to Space or Return Air Temperature Control and uses the Occupied HVAC Setpoints from the previous screen.

VCB-X CONFIGURATION

VCB-X Setpoint Screens

Space Temperature Control of High Percentage Outside Air Units—

This option allows for Space Temperature control of 100% Outside Air MUA Units or units with a high percentage of Outdoor Air (normally 50% or greater). For this application you would configure “Space Temperature w/High OA %” for the Controlling Sensor option. The intent of this sequence is to allow Space Temperature control of the unit while preventing the dumping of hot or cold outside air into the space during the Space Vent Mode of operation.

Once the Space Temperature is satisfied, before switching to Vent Mode, the controller compares the Outside Air Temperature to these Hood On HVAC setpoints to determine if a continued demand for heating or cooling is required to prevent dumping. If there is no demand, the VCB-X Controller switches to Vent Mode. If the Outside Air Temperature is greater than the Hood On HVAC Cooling Setpoint or less than the Hood On HVAC Heating Setpoint, plus the Occupied Deadband, the VCB-X Controller will continue mechanical cooling or heating operation and stage it as necessary to maintain the Vent Mode Supply Air Setpoint (Calculated to be halfway between the Mode Enable Setpoints). A call for Heating or Cooling from the Space Sensor will cancel this tempering operation.

Supply Air Tempering—In the VAV Supply Air Tempering application (see the *VCB-X Controller Technical Guide* for full details), the unit will enter the Cooling and Heating Modes based on the outdoor temperature. The outdoor Heating and Cooling Setpoints are configured using the Hood On OAT Cooling and Heating Setpoints on this screen. In this application, the economizer can operate in any mode, if necessary, to achieve the supply air setpoint. Night Setback Heating and Morning Warm Up are both controlled to the Warm Up Supply Air Setpoint.

NOTE: For this Supply Air Tempering application, the Heating Supply Air Setpoint on *Setpoint Screen #21* should be set at least 2°F below the Cooling Supply Air Setpoint.

Description	Minimum	Default	Maximum
Hood On OAT Cool	1°F (-17.2°C)	75°F (24°C)	110°F (43.3°C)
Hood On OAT Heat	1°F (-17.2°C)	70°F (21°C)	110°F (43.3°C)

Setpoint Screen #3 - Unoccupied Offsets - Cooling & Heating

VCBX Spts ID 101
Unoccupied Offsets
Cooling: 30.0°F
Heating: 30.0°F

During the Unoccupied Mode of Operation, these Setpoints spread the HVAC Mode Setpoints out by this user-adjustable amount. Use only positive numbers for these Setpoints. If you do not want Cooling or Heating to operate during the Unoccupied Mode, use the default setting of 30°F for these setpoints.

Description	Minimum	Default	Maximum
Unoccupied Offsets Cooling	0°F (0°C)	30°F (16.6°C)	30°F (16.6°C)
Unoccupied Offsets Heating	0°F (0°C)	30°F (16.6°C)	30°F (16.6°C)

Setpoint Screen #4 - Mode Deadband

VCBX Spts ID 101
Mode Deadband
Setpt: 1.0°F

This Setpoint is added to and subtracted from the HVAC Mode Setpoints to determine when the unit enters and leaves a mode of operation.

Description	Minimum	Default	Maximum
HVAC Mode Select Deadband	1°F (.6°C)	1°F (.6°C)	10°F (5.5°C)

Setpoint Screen #5 - Space Sensor Slide Adjust

VCBX Spts ID 101
Space Sensor
Slide Adj: 0

If the VCB-X has a Space Temperature Sensor with the Slide Adjust option installed, the HVAC Mode Enable Heating and Cooling Setpoints can be offset by the HVAC Mode Sensor Slide Offset Setpoint value. When the Slide Adjust bar is in the middle, no offset will occur. If the Slide Adjust bar is moved all the way to the top of the Sensor, the Heating and Cooling Setpoints will be raised by the Setpoint value you have entered. If the Slide Adjust bar is moved all the way down to the bottom of the Sensor, the Heating and Cooling Setpoints will be lowered by the Setpoint value you have entered.

If the Space Temperature is the SAT Reset Source, then the Slide Adjust will adjust the HVAC Mode Enable Setpoints and the SAT Reset Source Setpoints simultaneously.

Description	Minimum	Default	Maximum
Space Sensor Slide Adjust	0°F (0°C)	0°F (0°C)	10°F (5.5°C)

Setpoint Screens #6, #7 & #8 - Flush Mount Space Sensor Calibrate Slide Adjust

```
VCBX Spts ID 101
Calibrate Slide Adj
Put At Up Pos: XXX
Enter # Shown: XXX
```

The use of this screen is optional and is not required for the sensor to function. Once the slide adjust value is configured on Setpoint Screen #5, this screen is used to calibrate the slider to accurately provide that offset adjustment in the up position. The value on line 3 will change when the slider moves. Once the slider is in the up position, wait for the value on line 3 to stop changing. Once it stops changing, enter this value on line 4.

```
VCBX Spts ID 101
Calibrate Slide Adj
At Middle Pos: XXX
Enter # Shown: XXX
```

This screen is used to calibrate the value for the slider when it is in the middle position. The value on line 3 will change when the slider moves. Once the slider is in the middle position, wait for the value on line 3 to stop changing. Once it stops changing, enter this value on line 4.

```
VCBX Spts ID 101
Calibrate Slide Adj
At Down Pos: XXX
Enter # Shown: XXX
```

This screen is used to calibrate the value for the slider when it is in the down position. The value on line 3 will change when the slider moves. Once the slider is in the down position, wait for the value on line 3 to stop changing. Once it stops changing, enter this value on line 4.

Setpoint Screen #9 - Space Sensor Push-Button Override Duration

```
VCBX Spts ID 101
Space Sensor Push
Button Override
Duration: 2.0Hr
```

If the VCB-X has a Space Temperature Sensor installed and it has the Override Button option, the HVAC unit will initiate Override Mode any time the Override Button is pressed and held for less than 3 seconds. This puts the unit into Occupied operation. The Push-Button Override Duration Setpoint allows you to adjust the amount of time the Override will remain in effect when the Override Button is pressed. To cancel the Override before the Override Duration time period expires, press the Override Button for 5 to 10 seconds.

If using a Digital Space Sensor, pushing the Override Button momentarily will initiate the Override Mode.

Description	Minimum	Default	Maximum
Space Sensor Push-Button Override Duration	0.0 Hr	2.0 Hr	8.0 Hr

Setpoint Screen #10 - Controlling Sensor High Alarm Offset

```
VCBX Spts ID 101
Controlling Sensor
High Alarm Offset
Setpt: 30.0°F
```

If the Temperature of the controlling sensor rises above the Occupied Cooling Setpoint by this amount during the Cooling Mode, the controller will generate a High Control Temp Alarm. The unit must be configured for Space Temperature Control, Return Air Temperature Control, or as a Single Zone VAV unit for this alarm to be generated.

Description	Minimum	Default	Maximum
Controlling Sensor High Alarm Offset	0°F (0°C)	30°F (16.6°C)	50°F (27.7°C)

Setpoint Screen #11 - Controlling Sensor Low Alarm Offset

```
VCBX Spts ID 101
Controlling Sensor
Low Alarm Offset
Setpt: 30.0
```

If the Temperature of the controlling sensor falls below the Occupied Heating Setpoint by this amount during the Heating Mode, the controller will generate a Low Control Temp Alarm. The unit must be configured for Space Temperature Control, Return Air Temperature Control, or as a Single Zone VAV unit for this alarm to be generated.

Description	Minimum	Default	Maximum
Controlling Sensor Low Alarm Offset	0°F (0°C)	30°F (16.6°C)	50°F (27.7°C)

VCB-X CONFIGURATION

VCB-X Setpoint Screens

Setpoint Screen #12 - Outdoor Dewpoint Setpoint

VCBX Spts ID 101
Outdoor Dewpoint
Setpt: 55.0°F

On MUA configured units (100% or high percentage Outdoor Air units), or if this is a unit in Hood On MUA operation, Dehumidification will be initiated if the Outdoor Air Dewpoint rises 2°F above this setpoint. If the humidity falls 2°F below this setpoint, the unit will leave the Dehumidification Mode.

Description	Minimum	Default	Maximum
Outdoor Dewpoint Setpoint	35°F (1.7°C)	55°F (12.8°C)	80°F (26.6°C)

Setpoint Screen #13 - Indoor RH Setpoint Low and High Reset Source

VCBX Spts ID 101
Indoor RH Setpt
Lo Rst Src: 50%
Hi Rst Src: 60%

This screen can be used to set the Space Humidity Setpoint and to set the Space Humidity Reset range used to reset the Suction Coil Temperature Setpoint.

On units where Indoor Humidity is used to initiate Dehumidification (non MUA units), the Low Reset Source (Lo Rst Src) is the Dehumidification Setpoint, and as the Indoor Humidity rises above this setpoint, Dehumidification will be initiated. If the humidity falls 1% below this setpoint, the unit will leave the Dehumidification Mode.

If no reset of the Coil Temperature Setpoint is desired, set the High Reset Source (Hi Rst Src) at the same value as the Low Reset Source. If reset of the Coil Temperature Setpoint is desired, when the Indoor Humidity rises above the Low Reset Source, Dehumidification will be initiated and the Coil Temperature Setpoint will be set at the Coil Temperature High Reset Limit (configured in the next screen).

The High Reset Source (Hi Rst Src) is the Indoor Humidity level at which the Coil Temperature will be reset to the Coil Temperature Low Reset Limit (configured in the next screen). As the Indoor Humidity rises between the Low Reset Source and the High Reset Source, the Coil Temperature Setpoint will be proportionally reset between the Coil Temperature High Reset Limit down to the Coil Temperature Low Reset Limit.

On MUA units where the Outdoor Dewpoint Setpoint is used to initiate Dehumidification, this screen is only used to set the Indoor Humidity values that will reset the Coil Temperature Setpoint. As described above, as the Indoor Humidity rises within the range created by the Low and High Reset Source Setpoints, the Coil Temperature Setpoint will be proportionally reset between the High and Low Coil Temperature Reset Limits.

Description	Minimum	Default	Maximum
Indoor RH Setpoint Low Reset Source	0%	50%	100%
Indoor RH Setpoint High Reset Source	0%	60%	100%

Setpoint Screen #14 - Coil (Saturation) Temperature High and Low Reset Setpoints

VCBX Spts ID 101
Coil Temp Setpt
Hi Rst Lmt: 45°F
Lo Rst Lmt: 40°F

Based on the Indoor Humidity Reset Range configured on the previous screen, the Coil Suction Temperature Setpoint can be reset between the High Reset Limit (Hi Rst Lmt) and Low Reset Limit (Lo Rst Lmt) configured on this screen during the Dehumidification Mode. See the description of this reset function on the previous screen. If the High Reset Limit and the Low Reset Limit are set at the same value, no Coil Temperature Reset will occur.

Description	Minimum	Default	Maximum
Coil Temp Setpoint High Reset Limit	35°F (1.7°C)	45°F (7.2°C)	70°F (21.1°C)
Coil Temp Setpoint Low Reset Limit	35°F (1.7°C)	40°F (4.4°C)	70°F (21.1°C)

Setpoint Screen #15 - Static Pressure Setpoint and Deadband

VCBX Spts ID 101
Static Pressure
Setpt: 1.50
Deadband: 0.10

For VAV units, a Supply Fan VFD or Bypass Damper Actuator is used to maintain the Duct Static Pressure Setpoint. The Static Pressure Output Signal varies to control to the Static Pressure Setpoint. The Duct Static Pressure is maintained at this setpoint anytime the Main Fan is running.

The Duct Static Setpoint accuracy is controlled by this value. No Main Fan VFD changes are made if the static is within this range of this setpoint.

Description	Minimum	Default	Maximum
Static Pressure Spt	0.10" WG	1.50" WG	3.0" WG
Deadband	0.01" WG	0.10" WG	0.50" WG

Setpoint Screen #16 - VFD Speed Minimums Cool/Vent Modes

```
VCBX Spts ID 101
VFD Speed Limits
  Min Cool: 60%
  Min Vent: 60%
```

If this unit is configured for Single Zone VAV operation, the Min Cool Percentage will be the fan speed at which the VFD will start operating at when cooling is initiated. It can then modulate up to 100% as the space temperature rises within the range created by the Low Space (Low Spc) and the High Space (Hi Spc) Setpoints entered in Setpoint Screens #19 and 20. On a standard VAV unit, this will be the lowest fan speed the VFD will operate at in the Cooling Mode as it controls to the Duct Static Pressure Setpoint.

The Min Vent Percentage is the speed at which the fan will operate during the Vent Mode.

Description	Minimum	Default	Maximum
Minimum Cool	0%	30%	100%
Minimum Vent	0%	20%	100%

Setpoint Screen #17 - VFD Speed Limits Min/Max Heat

```
VCBX Spts ID 101
VFD Speed Limits
  Min Heat: 60%
  Max Heat: 100%
```

If this unit is configured for Single Zone VAV operation, and you have a modulating heat source that will allow VAV heating, then the Min Heat Percentage will be the fan speed at which the VFD will start operating at when heating is initiated. It can then modulate up to the Max Heat Percentage as the Space Temperature falls within the range created by the Hi Space setpoint and the Low Space Setpoint created in Setpoint Screens #22 and 23. On a standard VAV unit, these setpoints will be the Min and Max fan speeds the unit will operate at in the Heating Mode as it controls to the Duct Static Pressure Setpoint.

Description	Minimum	Default	Maximum
Minimum Heat	0%	60%	100%
Maximum Heat	0%	100%	100%

Setpoint Screen #18 - Supply Air Cooling Setpoint and High Reset Limit

```
VCBX Spts ID 101
Supply Air Cooling
Setpt.....: 55.0°F
Hi Rst Limit: 55.0°F
```

If no Reset Source has been configured in Configuration Screen #9, then this Setpoint will be the Supply Air Temperature Cooling Setpoint. Line 4 will be not be used. If a Reset Source has been configured in Configuration Screen #9, then Line 4 will be used. Reset is always upward from the SAT setpoint to the Reset Limit setpoint. So, the SAT will be the lowest temperature the Supply Air Setpoint can be reset to and Hi Reset Limit will be the highest temperature the Supply Air Setpoint can be reset to. The Cooling Supply Air Temperature Setpoint will automatically be reset warmer or colder within this range as the Reset Source moves within its range (created in the next two screens).

Description	Minimum	Default	Maximum
SAT Cooling Setpoint	30°F (-1.1°C)	55°F (12.8°C)	80°F (26.6°C)
Cooling Reset Limit	0°F (-17.7°C)	55°F (12.8°C)	100°F (37.7°C)

VCB-X CONFIGURATION

VCB-X Setpoint Screens

Setpoint Screen #19 - Cool Reset Source Setpoints - High Space/SAT/VFD

```
VCBX Spts ID 101
Cool Rst Source Spts
If Hi Spc: 75.0°F
Then SAT: 55
```

If no SAT Reset Source has been configured in Configuration Screen #9 and the unit has not been configured for Single Zone VAV, then this screen will read, “No Cool Rst Config” and will not be used. If the unit has been configured for Single Zone VAV, see the last paragraph for this screen.

If a Reset Source has been configured in Configuration Screen #9, the third line will display “If Hi Spc”, “If Hi OAT”, “If Hi RAT”, or “If Hi VFD” – depending on the Reset option that has been chosen. This screen will then allow you to input the upper limit for the Reset Source on Line 3. Line 4 (Then SAT) will show the corresponding Supply Air Cooling Setpoint that was entered on Setpoint Screen #18.

Please note that the SAT value cannot be changed on this screen; it is simply displayed from what was entered on Setpoint Screen #18. The value on Line 3 corresponds to the value on Line 4. So, if the Space Temperature Sensor has been configured as the Reset Source, then when the Space Temperature is at or above the Hi Spc Temperature Setpoint, the Supply Air Cooling Setpoint will be reset to its lowest value, the SAT Setpoint. Then, as the Space Temperature moves from this high value (Hi Spc) to its low value (Low Spc) configured on Setpoint Screen #20, the Supply Air Cooling Setpoint will be proportionally reset from the SAT Setpoint to the Hi Rst Limit Setpoint. *See Cooling Supply Air Reset examples under Setpoint Screen #20.*

```
VCBX Spts ID 101
SZ VAV Fan Cool Rst
If Hi Spc: 75.0°F
Then VFD: 100%
```

If this is was configured for Single Zone VAV application on Configuration Screen #7, this screen will appear. In the Cooling Mode, the Supply Fan VFD speed will proportionally modulate as the Space Temperature rises within the range set on this screen and the next screen. Upon entering the Cooling Mode, the fan will start at the Min Cooling VFD Speed (entered on Setpoint Screen #16) and modulate up to 100% as the Space Temperature rises from the Low Spc Setpoint (entered on the next screen) to the Hi Spc Setpoint entered on this screen. So, on this screen the Hi Spc Setpoint will correspond to the 100% VFD speed. Please note that the VFD speed is fixed at 100% on this screen and cannot be changed.

See Single Zone VAV Reset example under Setpoint Screen #20.

Description	Minimum	Default	Maximum
If Hi Space	1°F (-17.2°C)	75°F (24°C)	150°F (65.5°C)

Setpoint Screen #20 - Cool Reset Source Setpoints - Low Space/High Reset/VFD

```
VCBX Spts ID 101
Cool Rst Source Spts
If Low Spc: 70.0°F
Then Hi Rst: 55
```

If no SAT Reset Source has been configured in Configuration Screen #9 and the unit has not been configured for Single Zone VAV, then this screen will read, “No Cool Rst Config” and will not be used. If the unit has been configured for Single Zone VAV, see the last paragraph for this screen.

If a Reset Source has been configured in Configuration Screen #9, the third line will display “If Low Spc”, “If Low OAT”, “If Low RAT”, or “If Low VFD” – depending on the Reset option that has been chosen. This screen will then allow you to input the lower limit for the Reset Source on Line 3. Line 4 (Then SAT) will show the corresponding Supply Air Cooling Hi Rst Setpoint that was entered on Setpoint Screen #18.

Please note that the Rst Limit value cannot be changed on this screen; it is simply displayed from what was entered on the Setpoint Screen #18. The value on Line 3 corresponds to the value on Line 4. So, if the Space Temperature Sensor has been configured as the Reset Source, then when the Space Temperature is at or below the Low Spc Setpoint, the Supply Air Cooling Setpoint will be reset to its highest value, the Cooling Hi Rst Value. Then, as the Space Temperature moves from this low value (Low Spc) to its high value (Hi Spc) configured on Setpoint Screen #19, the Supply Air Cooling Setpoint will be proportionally reset from the Hi Rst Limit Setpoint to its SAT Setpoint.

Cooling Supply Air Reset Setpoints Examples:

Space Temperature Cooling Reset of SAT Setpoint:

Space Temp (Hi Spc) = 75°F SAT Stpt (SAT) = 55°F

Space Temp (Low Spc) = 72°F SAT Stpt (Hi Rst) = 65°F

VFD Percentage Cooling Reset of SAT Setpoint:

VFD Percentage (Hi VFD) = 100% SAT Stpt (SAT) = 55°F

VFD Percentage (Low VFD) = 30% SAT Stpt (Hi Rst) = 65°F

```
VCBX Spts ID 101
SZ VAV Fan Cool Rst
If Low Spc: 70.0°F
Then VFD: 30%
```

If this unit was configured for Single Zone VAV application on Configuration Screen #7, this screen will appear. In the Cooling Mode, the Supply Fan VFD speed will proportionally modulate as the Space Temperature rises within the range set on this screen and the previous screen. Upon entering the Cooling Mode, the fan will start at the Min Cooling VFD

Speed (entered on Setpoint Screen #16) and modulate up to 100% as the Space Temperature rises from the Low Spc Setpoint (entered on this screen) to the Hi Spc Setpoint entered on the previous screen. So, on this screen the Low Spc Setpoint should correspond to the VFD Min Cool Setpoint from Setpoint Screen #16. Please note that the VFD speed cannot be changed on this screen; it is simply displayed from what was entered as the Min Cool VFD Speed entered on Setpoint Screen #16.

Single Zone VFD Cooling Reset Examples:

Space Temp (Hi Spc) = 75°F VFD Speed (Then VFD) = 100%

Space Temp (Low Spc) = 72°F VFD Speed (Then VFD) = 30%

Description	Minimum	Default	Maximum
If Low Space	-30°F (-23.3°C)	70°F (21°C)	150°F (65.5°C)

Setpoint Screen #21 - Supply Air Heating Setpoint and High Reset Limit

```
VCBX Spts ID 101
Supply Air Heating
Setpt.....: 120.0
Hi Rst Limit.: 120.0
```

If no Reset Source has been configured in Configuration Screen #9, then this Setpoint will be the Supply Air Temperature Heating Setpoint. Line 4 will not be used. If a Reset Source has been configured in Configuration Screen #9, then Line 4 will be used. Reset is always upward from the SAT setpoint to the Hi Reset Limit setpoint. So, the SAT will be the lowest temperature the Supply Air Setpoint can be reset to and Reset Limit will be the highest temperature the Supply Air Setpoint can be reset to. The Heating Supply Air Temperature Setpoint will automatically be reset warmer or colder within this range as the Reset Source moves within its range (created in the next two screens).

NOTE: For a Supply Air Tempering application, the Heating Supply Air Setpoint should be set at least 2°F below the Cooling Supply Air Setpoint.

Description	Minimum	Default	Maximum
SAT Heating Spt	40°F (4.5°C)	120°F (48°C)	240°F (115.5°C)
Reset Limit Spt	0°F (-17.7°C)	120°F (48°C)	250°F (121.1°C)

Setpoint Screen #22 - Heat Reset Source Setpoints - High Space/SAT/VFD

```
VCBX Spts ID 101
Heat Rst Source Spts
If Hi Spc: 75.0°F
Then SAT: 55
```

If no SAT Reset Source has been configured in Configuration Screen #9 and the unit has not been configured for Single Zone VAV, then this screen will read, “No Heat Rst Config” and will not be used. If the unit has been configured for Single Zone VAV, see the last paragraph for this screen.

If a Reset Source has been configured in Configuration Screen #9, the third line will display “If Hi Spc”, “If Hi OAT”, “If Hi RAT”, or “If Hi VFD” – depending on the Reset option that has been chosen. This screen will then allow you to input the upper limit for the Reset Source on Line 3. Line 4 (Then SAT) will show the corresponding Supply Air Cooling Setpoint that was entered on Setpoint Screen #18. The exception is for “If Hi VFD”. When using VFD Reset in the Heating Mode, the “Hi VFD” value will correspond to the Supply Air Heating “Hi Rst” value entered on Setpoint Screen #18.

Please note that the SAT (or HiRst) value cannot be changed on this screen; it is simply displayed from what was entered on the Setpoint Screen #21. The value on Line 3 corresponds to the value on Line 4. So, if the Space Temperature Sensor has been configured as the Reset Source, then when the Space Temperature is at or above the Hi Spc Temperature Setpoint, the Supply Air Heating Setpoint will be reset to its lowest value, the SAT Setpoint. Then, as the Space Temperature moves from this high value (Hi Spc) to its low value (Low Spc) configured on Setpoint Screen #23, the Supply Air Cooling Setpoint will be proportionally reset from the SAT Setpoint to the Hi Rst Limit Setpoint.

See Heating Supply Air Reset examples under Setpoint Screen #23.

```
VCBX Spts ID 101
SZ VAV Fan Heat Rst
If Hi Spc: 75.0°F
Then VFD: 50%
```

If this unit was configured for Single Zone VAV application on Configuration Screen #7, this screen will appear. In the Heating Mode, the Supply Fan VFD speed will proportionally modulate as the Space Temperature falls within the range set on this screen and the next screen. Upon entering the Heating Mode, the fan will start at the Min Heating VFD Speed (entered on Setpoint Screen #17) and modulate up to the Max Heat VFD Speed (entered on Setpoint Screen #17) as the Space Temperature falls from the Hi Spc Setpoint (entered on this screen) to the Low Spc Setpoint entered on the next screen. So, on this screen the Hi Spc Setpoint would correspond to the Min Heat VFD speed. Please note that the VFD Speed displayed on this screen cannot be changed on this screen; it is simply displayed from what was entered as the Min Heat VFD Speed on Setpoint Screen #17.

See Single Zone VAV Reset example under Setpoint Screen #23.

Description	Minimum	Default	Maximum
If Hi Space	1°F (-17.7°C)	75°F (24°C)	150°F (65.5°C)

VCB-X CONFIGURATION

VCB-X Setpoint Screens

Setpoint Screen #23 - Heat Reset Source Setpoints - Low Space/High Reset/VFD

VCBX Spts ID 101
Heat Rst Source Spts
If Low Spc: 70.0°F
Then Hi Rst: 55°F

If no SAT Reset Source has been configured in Configuration Screen #9 and the unit has not been configured for Single Zone VAV, then this screen will read, “No Heat Rst Config” and will not be used. If the unit has been configured for Single Zone VAV, see the last paragraph for this screen.

If a Reset Source has been configured in Configuration Screen #9, the third line will display “If Low Spc”, “If Low OAT”, “If Low RAT”, or “If Low VFD” – depending on the Reset option that has been chosen. This screen will then allow you to input the lower limit for the Reset Source on Line 3. Line 4 (Then SAT) will show the corresponding Supply Air Cooling Hi Rst Setpoint that was entered on Setpoint Screen #18. The exception is for “If Low VFD”. When using VFD Reset in the Heating Mode, the “Low VFD” value will correspond to the Supply Air Heating “Setpt” value entered on Setpoint Screen #18.

Please note that the Low Rst (or SAT) value cannot be changed on this screen; it is simply displayed from what was entered on the Setpoint Screen #21. The value on Line 3 corresponds to the value on Line 4. So, if the Space Temperature Sensor has been configured as the Reset Source, then when the Space Temperature is at or below the Low Spc Setpoint, the Supply Air Heating Setpoint will be reset to its highest value, the Heating Hi Rst Value. Then, as the Space Temperature moves from this low value (Low Spc) to its high value (Hi Spc) configured on Setpoint Screen #22, the Supply Air Cooling Setpoint will be proportionally reset from the Hi Rst Limit Setpoint to its SAT Setpoint.

Heating Supply Air Reset Examples:

Space Temperature Heating Reset of SAT Setpoint:

Space Temp (Hi Spc) = 71°F SAT Stpt (SAT) = 90°F

Space Temp (Low Spc) = 68°F SAT Stpt (Hi Rst) = 120°F

VFD Percentage Heating Reset of SAT Setpoint:

VFD Percentage (Hi VFD) = 100% SAT Stpt (SAT) = 120°F

VFD Percentage (Low VFD) = 30% SAT Stpt (Hi Rst) = 90°F

VCBX Spts ID 101
SZ VAV Fan Heat Rst
If Low Spc: 70.0°F
Then VFD: 90%

If this unit was configured for Single Zone VAV application on Configuration Screen #7, this screen will appear. In the Heating Mode, the Supply Fan VFD speed will proportionally modulate as the Space Temperature falls within the range set on this screen and the previous screen. Upon entering the Heating Mode, the fan will start at the Min Heating VFD Speed (entered on Setpoint Screen #17) and modulate the Max Heat

VFD Speed (entered on Setpoint Screen #17) as the Space Temperature falls from the Hi Spc Setpoint (entered on the previous screen) to the Low Spc Setpoint entered on this screen. So, on this screen the Low Spc Setpoint should correspond to the VFD Max Heat Setpoint from Setpoint Screen #17. Please note that the VFD Speed Displayed on this screen cannot be changed on this screen; it is simply displayed from what was entered as the Max Heat VFD Speed on Setpoint Screen #17.

Single Zone VFD Heating Reset Example:

Space Temp (Hi Spc) = 71°F VFD Speed (Then VFD) = 50%

Space Temp (Low Spc) = 68°F VFD Speed (Then VFD) = 90%

Description	Minimum	Default	Maximum
If Low Space	-30°F (-34.4°C)	70°F (21°C)	150°F (65.5°C)

Setpoint Screen #24 - Stage Off Window - Cooling/Heating

VCBX Spts ID 101
Stage Off Window
Cooling: 5.0°F
Heating: 5.0°F

When the VCB-X Controller is in Cooling Mode, if the Supply Air Temperature drops below the Active Supply Air Cooling Setpoint minus the Cooling Stage Off Window value, a Cooling Stage will be deactivated after its Minimum Run Time. In the Heating Mode, if the Supply Air Temperature rises above the Active Supply Air Heating Setpoint plus the Heating Stage Off Window value, a Heating stage will be deactivated after its Minimum Run Time.

Description	Minimum	Default	Maximum
Stage Off Window Cooling	1°F (.6°C)	5°F (2.8°C)	30°F (16.6°C)
Stage Off Window Heating	1°F (.6°C)	5°F (2.8°C)	50°F (27.7°C)

Setpoint Screen #25 - Mod Heat Proportional Window and Time Period

VCBX Spts ID 101
Mod Heat
Prop Window: 10.0°F
Time Period: 10.0s

The Modulating Heating Proportional Window is the control range of the Modulating Signal above and below the Active Supply Air Temperature Setpoint. The size of the Proportional Window will determine how much of a signal change the controller will make per Time Period for every 1°F the Supply Air Temperature is from setpoint. The maximum signal change per time period is 10% which occurs when the Supply

Air Temperature is the full Proportional Window amount from setpoint. So, with a 5° Proportional Window, if the Supply Air Temperature is 5° or more from setpoint, the signal change will be 10% per time period. At 4° difference, the signal change will be 8% per time period. By the time the difference is 1°, the signal change will be 2% per time period. With a Proportional Window of 2°, if you are 2° or more from setpoint, the amount of signal change will be 10% per time period, and at 1° from setpoint the change would be 5% per time period. So, a larger proportional window allows for finer tuning of the control signal to prevent overshooting.

The Time Period is the length of time between Modulating Signal adjustments. Short Time Periods may cause hunting of the Modulating Signal.

Description	Minimum	Default	Maximum
Mod Heat Proportional Window	.1°F (.1°C)	10°F (5.5°C)	30°F (16.6°C)
Mod Heat Time Period	5 sec	10 sec	240 sec

Setpoint Screen #26 - Mod Cool Proportional Window and Time Period

VCBX Spts ID 101
Mod Cool
Prop Window: 10.0°F
Time Period: 30.0s

The Modulating Cooling Proportional Window is the control range of the Modulating Signal above and below the Active Supply Air Temperature Setpoint. The size of the Proportional Window will determine how much of a signal change the controller will make per Time Period for every °F the Supply Air Temperature is from setpoint. The maximum signal change per time period is 10% when the Supply Air Temperature is the full Proportional Window amount from setpoint. So, with a 5° Proportional Window, if the Supply Air Temperature is 5° or more from setpoint, the signal change will be 10% per time period. At 4° difference, the signal change will be 8% per time period. By the time the difference is 1°, the signal change will be 2% per time period. With a Proportional Window of 2°, if you are 2° or more from setpoint, the amount of signal change will be 10% per time period, and at 1° from setpoint the change would be 5% per time period. So, a larger proportional window allows for finer tuning of the control signal to prevent overshooting.

The Time Period is the length of time between Modulating Signal adjustments. Short Time Periods may cause hunting of the Modulating Signal.

Description	Minimum	Default	Maximum
Mod Cool Proportional Window	.1°F (.1°C)	10°F (5.5°C)	30°F (16.6°C)
Mod Cool Time Period	5 sec	30 sec	240 sec

Setpoint Screen #27 - Head Pressure Setpoints - Cooling and Reheat

VCBX Spts ID 101
Head Pressure Spts
Cooling: 315PSI
Reheat: 400PSI

If a Head Pressure Transducer is connected to the VCB-X EM1 Module you can control a Condenser Fan or a Condenser Water Valve to maintain these Head Pressure Setpoints in the Cooling and Dehumidification Reheat Modes.

Description	Minimum	Default	Maximum
Cooling Head Pressure Setpoint	240 PSI	315 PSI	420 PSI
Reheat Head Pressure Setpoint	240 PSI	400 PSI	420 PSI

Setpoint Screen #28 - Economizer Enable Setpoint

VCBX Spts ID 101
Economizer Enable
Setpt: 55.0°F

If this unit has been configured for Economizer control and an Outdoor Humidity Sensor is not connected to the VCB-X Controller, if the Outdoor Temperature falls below this setpoint, the Economizer can be used for free cooling. If a combination Outdoor Air Temperature/Humidity Sensor is connected to the VCB-X Controller and the Wetbulb or Dewpoint Temperature falls below this setpoint, the Economizer can be used for free cooling.

Description	Minimum	Default	Maximum
Economizer Enable	-30°F (-34.4°C)	55°F (12.8°C)	80°F (26.6°C)

Setpoint Screen #29 - Economizer Minimum Damper Position

VCBX Spts ID 101
Economizer Min
Damper Pos: 10%

The Economizer (OA Damper) Minimum Position Setpoint is maintained during the Occupied Mode even if the Economizer is disabled due to the OA Temperature being above the Economizer Enable Setpoint.

Description	Minimum	Default	Maximum
Economizer Min Position	0%	10%	100%

VCB-X CONFIGURATION

VCB-X Setpoint Screens

Setpoint Screen #30 - Maximum Economizer Position in Heat Mode

VCBX Spts ID 101
Max Econo Pos in
Heat Mode: 50%

If using Supply Air Tempering, this Setpoint allows you to set the Maximum Position the Outdoor Air Damper will open to while Heating is operating. This takes priority over the Economizer Maximum Position in High CO₂ Setpoint.

Description	Minimum	Default	Maximum
Maximum Economizer Position in Heat Mode	0%	50%	100%

Setpoint Screen #31 - Minimum Outdoor Airflow Setpoint and Deadband

VCBX Spts ID 101
Min. Outdoor Airflow
Setpt.: 2.00 kCFM
Deadband.: 200 CFM

If controlling the Outdoor Air Damper to an airflow setpoint, this screen allows you to set the design Minimum Outdoor Air CFM Setpoint. The Deadband controls the rate of change for the damper signal. As OA CFM moves further from setpoint within this window, the damper makes a larger change.

Description	Minimum	Default	Maximum
Minimum Outdoor Airflow Setpoint	0.10 kCFM	2.00 kCFM	200 kCFM
Deadband	10 CFM	200 CFM	9999 CFM

Setpoint Screen #32 - Economizer Maximum Position in High CO₂ Level

VCBX Spts ID 101
Econo Max Pos In
High Co2.: 50%

This Setpoint allows you to set the Maximum Position the Economizer will open if high CO₂ conditions occur in the space. The Maximum Economizer Position Setpoint is used to limit the amount of Outdoor Air that will be introduced to the HVAC unit in order to ensure the unit is operating within its Heating and Cooling design limitations. As shown in the table that follows, the Minimum setting for this Setpoint is the value previously set for the Economizer Min Position Setpoint.

Description	Minimum	Default	Maximum
Maximum Economizer Position In High CO ₂	Economizer Min Position	50%	100%

Setpoint Screen #33 - CO₂ Setpoints Min/Max

VCBX Spts ID 101
Co2 Setpoints
Min Co2: 900
Max Co2: 1000

The Min CO₂ Setpoint is the threshold CO₂ level at which the Economizer Min Damper Position (Setpoint Screen #29) will begin to be reset higher. The Max CO₂ Setpoint is the CO₂ level at which the Economizer Min Damper Position will be reset to the Econo Max Pos In High CO₂ (Setpoint Screen #32). In between those CO₂ levels, the Economizer Minimum Position will be proportionally reset between the values set in Setpoint Screens #29 and #32.

Description	Minimum	Default	Maximum
Minimum CO ₂ Level	0 PPM	900 PPM	2000 PPM
Maximum CO ₂ Level	0 PPM	1000 PPM	2000 PPM

Setpoint Screen #34 - CO₂ Altitude Setpoint

VCBX Spts ID 101
Altitude
Setpt: 1000ft

Enter the distance above sea level for the installed Carbon Dioxide Sensor. Altitude correction is required for valid readings if you are above 500 feet. High limit = 15,000 feet; Low limit = 0 feet

Description	Minimum	Default	Maximum
Altitude Setpoint	0 Feet	1000 Ft.	15,000 Ft.

Setpoint Screen #35 - Building Pressure

```
VCBX Spts ID 59
Building Pressure
Setpt.....: 0.02"
Deadband.....: 0.01"
```

The VCB-X can maintain Building Static Pressure anytime the Supply Fan is operating. A Building Pressure Transducer must be connected to the VCB-X EM1 Expansion Module. The following are the available control options.

Direct Acting Building Pressure Control

- **On/Off Exhaust Fan**—If an On/Off Exhaust Fan is being used, a relay output must be configured for “Exhaust Fan”. This relay will energize whenever the Building Pressure rises above the Building Pressure Setpoint by the Deadband amount. The relay will de-energize when the Building Pressure falls below the Building Pressure Setpoint by the Deadband amount.
- **Exhaust Fan VFD or Modulating Exhaust Damper**—If configured for Modulating Exhaust, a user-adjustable voltage output (AOUT1 – Building Pressure Output on the VCB-X EM1 Expansion Module) will be used to control this fan or damper. An Exhaust Relay can be configured if necessary to enable the fan or damper. Whenever the Building Pressure rises above the Building Pressure Setpoint by the Deadband amount, the Exhaust Fan Relay will energize and the Modulating Signal will activate to control to the Building Pressure Setpoint. If the Building Pressure falls below the Building Pressure Setpoint by the Deadband amount, the Modulating Signal will modulate towards 0% as it attempts to maintain the Building Pressure Setpoint. The Exhaust Fan Relay remains energized as long as the Modulating Signal is above 0%.

Reverse Acting Building Pressure Control

- **Outdoor Air Damper**—If this option is configured, the VCB-X will use the user-adjustable Economizer/ Outdoor Air Damper output signal (AOUT2 – Economizer Control Signal) to maintain the Building Pressure Setpoint. Whenever the Building Pressure falls below the Building Pressure Setpoint by the Deadband amount, the modulating Economizer Output Signal will modulate the damper open to control to the Building Pressure Setpoint. If the Building Pressure rises above the Building Pressure Setpoint by the Deadband amount, the damper will modulate towards closed as it attempts to maintain the Building Pressure Setpoint. When this option is selected, no Economizer free cooling or CO₂ IAQ operation will be available.

- **Supply Fan VFD** – Contact WattMaster regarding this Reverse Acting Building Pressure Control option. It should not be used in most applications. If this option is selected, the user-adjustable Supply Fan VFD Output (AOUT1 on the VCB-X) will be used to control the Supply Fan VFD to maintain the Building Pressure Setpoint in similar fashion to the Outdoor Air Damper control described above.

Description	Min.	Default	Max.
Building Pressure Spt	-0.20" WG	0.02" WG	0.20" WG
Building Pressure Deadband	0.01" WG	0.01" WG	0.10" WG

Setpoint Screen #36 - OAT Lockouts - Comp Cool/Comp Heat

```
VCBX Spts ID 101
OAT Lockouts
Comp Cool: 50.0°F
Comp Heat: 35.0°F
```

The VCB-X will Lockout Compressor (Mechanical) Cooling and Heat Pump Compressor Heating when the Outdoor Air Temperature is below these Compressor Cool and Heat Lockout Setpoints.

Description	Minimum	Default	Maximum
OAT Lockout Compressor Cooling	-30°F (-34.4°C)	50°F (10°C)	100°F (37.7°C)
OAT Lockout Compressor Heating	-30°F (-34.4°C)	35°F (1.6°C)	100°F (37.7°C)

Setpoint Screen #37 - OAT Lockouts - Heat

```
VCBX Spts ID 101
OAT Lockouts
Heat: 90.0°F
```

The VCB-X will Lockout Mechanical Heating when the Outdoor Air Temperature is above this Setpoint.

Description	Minimum	Default	Maximum
OAT Lockouts Heating	-30°F (34.4°C)	90°F (32.2°C)	150°F (65.5°C)

VCB-X CONFIGURATION

VCB-X Setpoint Screens

Setpoint Screen #38 - Supply Air Cutoffs - Cooling/Heating

VCBX Spts ID 101
Supply Air Cutoffs
Cooling: 40.0°F
Heating: 150.0°F

The VCB-X controller will temporarily disable Heating or Cooling if while in Heating or Cooling Mode the Supply Air Temperature rises above the Hi SAT Cutoff Heating Setpoint or falls below the Lo SAT Cutoff Cooling Setpoint. See the *VCB-X Controller Technical Guide* for detailed information on the Lo and Hi Supply Air Temperature Cutoff sequence of operation.

Description	Minimum	Default	Maximum
Cooling SAT Cutoff	0°F (-17.7°C)	40°F (4.5°C)	100°F (37.7°C)
Heating SAT Cutoff	0°F (-17.7°C)	150°F (65.5°C)	250°F (121.1°C)

Setpoint Screen #39 - Hot Water Valve Protection Position

VCBX Spts ID 101
Hot Water Valve
Protection POS: 0%

If the Supply Fan is on and the Supply Air Temperature (SAT) falls below the Low SAT Cutoff Setpoint for 1 minute, the Hot Water Valve will move to this position. If the SAT rises 5°F above the Low SAT Cutoff, the valve will return to normal operation. If the SAT remains below the Low SAT Cutoff Setpoint for 10 minutes, the unit will shut down and a Low SAT Cutoff Alarm will be generated.

If the Supply Fan is off or during Emergency Shutdown and the Outdoor Air Temperature (OAT) falls below the Low Ambient Setpoint, the Hot Water Valve will move to this position. If the OAT rises back above the Low Ambient Setpoint, the valve will return to its normal position.

If this setpoint is left at the default value of 0%, then the controller will not initiate this protection sequence. **For SCR heat this should be left at 0%.**

Description	Minimum	Default	Maximum
Hot Water Valve Protection Position	0%	0%	100%

Setpoint Screen #40 - Preheat Relay Setpoint

VCBX Spts ID 101
Preheat Relay
Setpt: 30.0°F

For cold climates where freezing temperatures may be experienced, a Pre-Heater relay output can be activated to control a preheat coil based on the Outdoor Air Temperature to prevent freezing of Water Coils. One of the VCB-X Relay Outputs must be configured for the Pre-Heater control. When configured, any time the Outdoor Air Temperature falls below the Preheat Setpoint during Occupied Mode and the HVAC unit's fan is running, the Pre-Heater relay will activate. This setpoint will also be used to enable the Preheater if the PREHEAT-X Controller is being used in conjunction with the VCB-X Controller. IF the PREHEAT-X Controller is being used with the VCB-X Controller, a relay on the VCB-X cannot also be configured as Preheat and energize for Preheat function.

Description	Minimum	Default	Maximum
Preheat Setpoint	-30°F (-34.4°C)	30°F (-1.1°C)	70°F (21.1°C)

Setpoint Screen #41 - Low Ambient Setpoint

VCBX Spts ID 101
Low Ambient
Setpt: 30.0°F

Similar to the Pre-Heat Relay, a Low Ambient Relay can be configured to energize anytime (during Occupied or Unoccupied Mode) the Outdoor Air Temperature falls below this setpoint. The Low Ambient Relay, though, can energize whether the fan is running or not. This could be used to energize a boiler, for instance.

Description	Minimum	Default	Maximum
Low Ambient Setpoint	-30°F (-34.4°C)	30°F (-1.1°C)	70°F (21.1°C)

Setpoint Screen #42 - Heat Pump Defrost Interval

VCBX Spts ID 102
Heat Pump Defrost
Interval: 30 Min

If this is a heat pump unit with a Defrost Coil Temperature Switch installed and configured, a Heat Pump Defrost Mode is available. If the Defrost Coil Temperature Switch closes during Heat Pump Heating operation, the unit will enter the Defrost Mode for 10 minutes or until the Defrost Coil Temperature Switch opens. The Heat Pump Defrost Interval is the length of time that must be met between Defrost Modes. The length of this Defrost Interval can be automatically adjusted by the Adaptive Defrost Interval Adjustment described in Setpoint Screen #43.

Description	Minimum	Default	Maximum
Heat Pump Defrost Interval	10 Min	30 Min	120 Min

Setpoint Screen #43 - Adaptive Defrost Interval Adjustment

VCBX Spts ID 101
Adaptive Defrost
Interval Adj: 0 Min

Once initiated, the Defrost Mode is active until the Defrost Coil Temperature Switch opens or until a 10 minute timer has expired. Enter a value greater than zero to enable the Adaptive Defrost Adjustment of the Heat Pump Defrost Interval (*Setpoint Screen #42*). This adjustment value will be subtracted from the Heat Pump Defrost Interval if the Defrost Mode lasts the entire 10 minutes. A proportion of this adjustment value will be added to the Heat Pump Defrost Interval if the Defrost Mode only lasts between 8 minutes and 0 minutes.

Description	Minimum	Default	Maximum
Adaptive Defrost Adj.	0 Min	0 Min	30 Min

Setpoint Screen #44 - Heat Wheel Defrost Temperature Setpoint

VCBX Spts ID 101
Heat Wheel Defrost
Temp Setpt: 30°F

The unit will go into Heat Wheel Defrost Mode when the Outdoor Air is below this setpoint.

Description	Minimum	Default	Maximum
Heat Wheel Defrost	0°F (0°C)	30°F (-1.1°C)	50°F (10°C)

Setpoint Screen #45 - Morning Warm Up or Cool Down Temp

VCBX Spts ID 102
Morning WarmUp
Max Length.: 60 Min
Target Temp: 70°F

This setpoint is used to initiate both Morning Warm-up and Cool-down. When the VCB-X is configured for Morning Warm-up or Morning Cool-down operation and the controller enters the Occupied Mode, the VCB-X looks at the Return Air Temperature to determine if the unit should initiate Morning Warm-up or Cool-down Mode. If the Return Air Temperature is below the Morning Warm-up Target Temperature by 1°F and the Max Length is greater than "0," the VCB-X controller will initiate Heating. This is considered Morning Warm-up and will run until the Return Air Temperature rises above the Morning Warm-up Target Temperature or until the Max Length Setpoint time expires. If the Return Air Temperature is above the Morning Warm-up Target Temperature by 1°F and the Max

Length is greater than "0," the VCB-X controller will initiate Cooling. This is considered Morning Cool-down and will run until the Return Air Temperature falls below the Morning Warm-up Target Temperature or until the Max Length Setpoint time expires.

Description	Minimum	Default	Maximum
Morning Warm Up Max Length	0 Min	60 Min	240 Min
Morning Warm Up Target Temp	50°F (10°C)	70°F (21°C)	90°F (32.2°C)

Setpoint Screen #46 - Space Sensor Calibration - Current and Offset

VCBX Spts ID 101
Space Sensor Cal
Current: 0.0°F
Offset.: 0.0°F

If the Space Air Temperature Sensor is reading incorrectly, you can use this option to enter an offset temperature to adjust the Sensor's Temperature. Line 3 will display the current Space Air Temperature reading. Enter a positive Sensor Calibration value in Line 4 to raise the Space Temperature Sensor reading or a negative value in Line 4 to lower the Sensor reading.

Description	Minimum	Default	Maximum
Space Sensor Calibration Offset	-100.0°F (-55.5°C)	0.0°F (0°C)	100.0°F (55.5°C)

Setpoint Screen #47 - Return Air Temperature Sensor Calibration - Current and Offset

VCBX Spts ID 101
Return Sensor Cal
Current: 0.0°F
Offset.: 0.0°F

If the Return Air Temperature Sensor is reading incorrectly, you can use this option to enter an offset temperature to adjust the Sensor's Temperature. Line 3 will display the current Return Air Temperature reading. Enter a positive Sensor Calibration value in Line 4 to raise the Return Temperature Sensor reading or a negative value in Line 4 to lower the Sensor reading.

Description	Minimum	Default	Maximum
Return Air Sensor Calibration Offset	-100.0°F (-55.5°C)	0.0°F (0°C)	100.0°F (55.5°C)

VCB-X CONFIGURATION

VCB-X Setpoint Screens

Setpoint Screen #48 - SAT Sensor Calibration - Current and Offset

```
VCBX Spts ID 101
SAT Sensor Cal
Current: 0.0°F
Offset.: 0.0°F
```

If the Supply Air Temperature Sensor is reading incorrectly, you can use this option to enter an offset temperature to adjust the Sensor's Temperature. Line 3 will display the current Supply Air Temperature Sensor reading. Enter a positive Sensor Calibration value in Line 4 to raise the Supply Air Temperature Sensor reading or a negative value in Line 4 to lower the Sensor reading.

Description	Minimum	Default	Maximum
Sensor Calibration SAT	-100.0°F (-55.5°C)	0.0°F (0°C)	100.0°F (55.5°C)

Setpoint Screen #49 - Coil Sensor Calibration - Current and Offset

```
VCBX Spts ID 101
Coil Sensor Cal
Current: 0.0°F
Offset.: 0.0°F
```

If the Coil Temperature Sensor is reading incorrectly, you can use this option to enter an offset temperature to adjust the Sensor's Temperature. Line 3 will display the current Coil Temperature Sensor Reading. Enter a positive Sensor Calibration value in Line 4 to raise the Coil Temperature Sensor reading or a negative value in Line 4 to lower the Sensor reading.

Description	Minimum	Default	Maximum
Coil Sensor Calibration Offset	-100.0°F (-55.5°C)	0.0°F (0°C)	100.0°F (55.5°C)

Setpoint Screen #50 - OAT Sensor Calibration - Current and Offset

```
VCBX Spts ID 101
OAT Sensor Cal
Current: 0.0°F
Offset.: 0.0°F
```

If the Outdoor Air Temperature Sensor is reading incorrectly, you can use this option to enter an offset temperature to adjust the Sensor's Temperature. Line 3 will display the current Outdoor Air Temperature Sensor Reading. Enter a positive Sensor Calibration value in Line 4 to raise the Outdoor Air Temperature Sensor reading or a negative value in Line 4 to lower the Sensor reading.

Description	Minimum	Default	Maximum
OAT Sensor Calibration Offset	-100.0°F (-55.5°C)	0.0°F (0°C)	100.0°F (55.5°C)

Setpoint Screen #51 - CO₂ Sensor Calibration - Current and Offset

```
VCBX Spts ID 101
Co2 Sensor Cal
Current: 0ppm
Offset.: 0ppm
```

If the CO₂ Sensor is reading incorrectly, you can use this option to enter an offset reading to adjust the Sensor's Sensitivity. Line 3 will display the current CO₂ Sensor reading. Enter a positive Sensor Calibration value in Line 4 to increase the CO₂ Sensor reading or a negative value in Line 4 to lower the Sensor reading.

Description	Minimum	Default	Maximum
Sensor Calibration CO ₂	-500.0 PPM	0.0 PPM	500.0 PPM

Setpoint Screen #52 - Leaving Water Temperature Sensor Calibration - Current and Offset

```
VCBX Spts ID 101
Leaving H2O Cal
Current: 0.0°F
Offset.: 0.0°F
```

If the Leaving Water Temperature Sensor is reading incorrectly, you can use this option to enter an offset reading to adjust the Sensor's Sensitivity. Line 3 will display the current Leaving Water Temperature Sensor reading. Enter a positive Sensor Calibration value in Line 4 to increase the Sensor's reading or a negative value in Line 4 to lower the Sensor reading.

Description	Minimum	Default	Maximum
Leaving H2O Temperature Sensor Calibration Offset	-100.0°F (-55.5°C)	0.0°F (0°C)	100.0°F (55.5°C)

Setpoint Screen #53 - SZ VAV Integral Constant

```
VCBX Spts ID 101
SZ VAV Integral
Constant: 0
```

If the SZ VAV Fan Speed Control requires Integral control, enter the Integral constant here.

Description	Minimum	Default	Maximum
SZ VAV Integral Constant	0	0	10

Setpoint Screen #54 - Return Air Bypass Damper Factor Setpoint

VCBX Spts ID 101
Return Air Bypass
Damper Factor
Setpoint: 0%

This setpoint is used when your HVAC unit is configured for Return Air Bypass Damper control. The Return Air Bypass Damper Factor Setpoint is a percentage value that is used to calculate the Return Air Damper position in relation to the Return Air Bypass Damper position. This provides a method for adjusting the airflow through the Return Air Bypass Damper.

Increasing this percentage increases the airflow through the Return Air Bypass Damper by causing the Return Air Damper to move further towards its closed position in relation to the Return Air Bypass Damper moving towards its open position.

Description	Minimum	Default	Maximum
Damper Factor	0%	0%	100%

Setpoint Screen #55 - Warm-Up Supply Air Temperature Setpoint

VCBX Spts ID 101
Warmup Supply Air
Setpoint: 100.0°F

Heating will be controlled to this Supply Air Setpoint during Morning Warm Up and during Night Setback Heating in a Supply Air Temperature application.

Description	Minimum	Default	Maximum
Warm-Up SAT Setpoint	40	100	240

Setpoint Screen #56 - Cool-Down Supply Air Temperature Setpoint

VCBX Spts ID 101
Cooldown Supply Air
Setpoint: 55.0°F

Cooling will be controlled to this Supply Air Setpoint during Morning Cool-Down and during Night Setback Cooling in a Supply Air Temperature application.

Description	Minimum	Default	Maximum
Cool-Down SAT Setpoint	30	55	80

Setpoint Screen #57 - PREHEAT-X Cooling Mode and Heating Mode Setpoints

VCBX Spts ID 101
Preheat-X Spts
Cooling Mode: 40.0°F
Heating Mode: 60.0°F

If using the Preheat-X Controller with the VCB-X, this screen allows you to set the Preheat setpoint you want to control to during the Cooling and the Heating Modes.

Description	Minimum	Default	Maximum
Preheat-X Cooling Mode Setpoint	35.0°F (1.66°C)	40.0°F (4.5°C)	90.0°F (32.2°C)
Preheat-X Heating Mode Setpoint	35.0°F (1.66°C)	60.0°F (15.5°C)	90.0°F (32.2°C)

Setpoint Screen #58 - PREHEAT-X Venting Mode Setpoint

VCBX Spts ID 101
Preheat-X Spts
Venting Mode: 50.0°F

If using the Preheat-X Controller with the VCB-X, this screen allows you to set the Preheat setpoint you want to control to during the Vent Mode.

Description	Minimum	Default	Maximum
Preheat-X Venting Mode Setpoint	35.0°F (1.66°C)	50.0°F (10.0°C)	90.0°F (32.2°C)

VCB-X Status Screens

Status Screens - General Procedures

From any menu screen, press **<STATUS>**. The *Unit Selection Screen*, shown below, will appear requesting that you enter the unit ID number.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the correct unit ID number of the Controller you want to view and press **<ENTER>**. Once communication is established, “No Communication” will be replaced with “Press Down.” Then press **<↓>**. You will then see Setpoint Screen #1. Press **<ENTER>** to save entered data and press **<↓>** to scroll through the screens.

NOTE: If “No Communication” remains, it indicates a communication failure to the controller.

Status Screen Index

The available Status Screens for the VCB-X Controller are listed on the next few pages by sequential screen number. The following is a list of all the VCB-X Status Screens in numerical order with a brief listing of the Status features available on each screen:

Screen #1	Date & Time
Screen #2	Application Type, Schedule Mode & HVAC Mode
Screen #3	Controlling Temperature, Cooling & Heating Setpoints
Screen #4	Space & Return Air Temperature & Slide Adjust
Screen #5	Supply Air Temperature & Active Setpoint
Screen #6	Cooling Enabled Yes/No
Screen #7	Cooling Outputs - Active Stages & Mod Cooling Position
Screen #8	Compressor Discharge Temperature
Screen #9	Heating Enabled Yes/No or HP Heat Enabled, HP Aux Enabled & HP Emergency Heat Enabled
Screen #10	Heating Outputs - Active Stages & Mod Heat Position
Screen #11	MODGAS-X Enabled or Disabled and / MODGAS-X Heating Output Signal
Screen #12	Current Indoor RH & Indoor RH Setpoint
Screen #13	Current Coil Temperature, Current Coil Setpoint, and Suction Pressure
Screen #14	Active Reheat Stages
Screen #15	MHGRV-X Enabled or Disabled and MHGRV-X Reheat Valve Output Signal Percentage

Screen #16	Preheat-X Enabled and Leaving Air Temperature Setpoint
Screen #17	Current Preheat-X Leaving Air Temperature and Entering Air Temperature
Screen #18	Current Preheat-X Modulating Position and Active Stages
Screen #19	Current Outdoor Air Drybulb and Current Outdoor Air Relative Humidity
Screen #20	Current Wetbulb Temperature and Current Calculated Outdoor Air Dewpoint Temperature
Screen #21	Economizer Enabled or Disabled and Current Economizer Open Percentage
Screen #22	Economizer Feedback Percentage for Title 24 Economizer
Screen #23	Economizer in IAQ Mode Yes/No and Economizer Minimum Percentage
Screen #24	Current CO ₂ Level, Minimum Setpoint, and Maximum Setpoint
Screen #25	Outdoor Air CFM and Supply Air CFM
Screen #26	Return Air CFM and Exhaust Air CFM
Screen #27	Current Duct Static Pressure, Current Duct Static Pressure Setpoint and Output Percentage
Screen #28	Current Building Pressure and Setpoint
Screen #29	Building Pressure Exhaust Fan Status and Output Signal Percentage
Screen #30	Current Head Pressure 1 Reading, Head Pressure Setpoint, and Condenser 1 Signal
Screen #31	Current Head Pressure 2 Reading, and Condenser 2 Signal
Screen #32	Leaving Water Temperature, Entering Water Temperature & Current Suction Pressure
Screen #33	WSHP Glycol Percentage and Heating & Cooling Modes Low Suction Setpoints
Screen #34	WSHP Glycol Percentage, Unsafe Suction Setpoint, and Low Leaving Water Temperature
Screen #35	Return Air Damper Signal & Return Air Bypass Damper Signal
Screen #36	Reset Voltage Signal
Screens #37-42	VCB-X Relays
Screens #43-47	VCB-X EM1 Relays
Screens #48-59	12 Relay Expansion Module Relays
Screens #60-90	Alarm Status Screens

Status

The VCB-X Controller Status Screens are accessed by *pressing* the **<STATUS>** button on the Modular Service Tool or Modular System Manager. Once communication is established, “No Communication” will be replaced with “Press Down.” Then *press* **<↓>**. You will then see Setpoint Screen #1. *Press* **<ENTER>** to save entered data and *press* **<↓>** to scroll through the screens.

NOTE: If “No Communication” remains, it indicates a communication failure to the controller.

Status Screen 1 - Date and Time

```
VCB-X    v2.00 ID 101
Controller Date/Time

06/19/11 05:00 PM
```

Line 2 Controller Date/Time

Line 3 MM/DD/YY HH:MM XX
(Month, Day, Year) (Hour, Minutes, AM or PM)

Status Screen 2 - Application Type, Schedule Mode & HVAC Mode

```
VCB-X    v2.00 ID 101
App Type
Schedule Mode
HVAC Mode
```

Line 2 App Type:

Constant Volume	Single Zone VAV
VAV	VAV w/Tempering
Make Up Air	Space w/High OA%

Line 3 Schedule Mode:

Unoccupied	Holiday Occupied
Occupied	Forced Occupied
Override	Forced Unoccupied
Holiday Unoccupied	Remote Occupied

Line 4 HVAC Mode:

Off	Dehum Vent
Vent Mode	Dehum Cool
Cool Mode	Dehum Heat
Heat Mode	Warm Up
Defrost	Cool Down
Remote Cool	Remote Heat
Remote Vent RH	Remote Cool RH
Remote Heat RH	

Status Screen 3 - Controlling Temperature, Cooling & Heating Setpoints

```
VCB-X    v2.00 ID 101
Cont. Temp:  XX.XX
Cool Spt.:  XX.XX
Heat Spt.:  XX.XX
```

Line 2 Controlling Temperature

This is the temperature of the sensor that is configured as the HVAC Source (Mode Enable) Sensor. This can be the Supply Air, Return Air, Outdoor Air, or Space Temperature Sensor.

Line 3 Cooling Setpoint

Based on the current Occupied/Unoccupied Mode of operation. (Reflects any active resets.)

Line 4 Heating Setpoint

Based on the current Occupied/Unoccupied Mode of operation. (Reflects any active resets.)

Status Screen 4 - Space and Return Temperature & Slide Adjust

```
VCB-X    v2.00 ID 101
Space Tmp.:  XXX.XX
Return Tmp:  XXX.XX
Slide Adj.:  XXX.XX
```

Line 2 Space Temperature

If you are using a Space Temperature Sensor, this line will display the current Space Temperature during the Occupied or Unoccupied Mode. If a Space Temperature Sensor is not used, it will display 0°F.

Line 3 Return Air Temperature

If you are using a Return Air Temperature Sensor, this line will display the current Return Air Temperature during the Occupied or Unoccupied Mode. If a Return Air Temperature Sensor is not used, it will display 0°F.

Line 4 Slide Adjust

This is the current value of the Space Temperature offset based on the position of the slide adjust switch on the Space Sensor.

VCB-X Status Screens

Status Screen 5 - Supply Air Temperature & Active Setpoint

```
VCB-X   v2.00 ID 101
Supply Temp: XXX.XX
Active Spt.: XXX.XX
```

Line 2 Current Supply Air Temperature

The Supply Air Temperature is always required. If a Supply Air Temperature Sensor is not installed, the VCB-X Controller will not operate correctly and will display 0°.

Line 3 Current Active Supply Air Setpoint

This is the Supply Air Setpoint for the mode that the unit is currently operating in. If the Supply Air Reset is configured, this is the calculated setpoint based on the current Reset Source conditions.

Status Screen 6 - Cooling Enabled

```
VCB-X   v2.00 ID 101
Cooling Enabled
YES/NO
```

Line 3 Cooling Enabled YES/NO

This line will display YES if Cooling is enabled and NO if the Cooling is not enabled. Cooling is enabled if the Outdoor Air Temperature is above the Compressor Cooling Lockout.

Status Screen 7 - Cooling Outputs - Active Stages and Mod Cool Position

```
VCB-X   v2.00 ID 101
Cooling Outputs
Active Stages: XX
Mod Cool Pos.: XXX%
```

Line 2 Cooling Active Stages

This line will display the number of stages of Cooling that are currently active.

Line 3 Current Modulating Cooling Output Signal Percentage

Indicates the percentage output signal to the Digital Scroll Compressor or a Chilled Water Valve.

Status Screen 8 - Compressor Discharge Temperature

```
VCB-X   v2.00 ID 101
Compressor Discharge
Temp: XXX.XX
```

Line 3 Compressor Discharge Temperature

This line will display the current compressor discharge temperature if your HVAC unit is using a Digital Scroll Compressor. If this temperature rises above 268°F (131.11°C), the digital compressor will be locked out.

Status Screen 9 - Heating Enabled

```
VCB-X   v2.00 ID 101
Heating Enabled
YES/NO
```

If this is *not* a Heat Pump unit, the screen will appear as shown above.

Line 3 Heating Enabled YES/NO

This line will display YES if Heating is enabled and No if Heating is not enabled. Heating is enabled if the Outdoor Air Temperature is below the Heating Lockout.

```
VCB-X   v2.00 ID 101
HP Heat Enabled: YES
HP Aux Enabled: YES
HP Emg Enabled: NO
```

If this is a Heat Pump unit, the screen will appear as shown above.

Line 2 HP Heat Enabled

This line refers to Compressor Heating and will display YES if the Outdoor Air Temperature is above the Compressor Heating Lockout and below the Heating Lockout. Otherwise, it will display NO.

Line 3 HP Aux Enabled

This line refers to Heat Pump Auxiliary Heat and will display YES if the Outdoor Air Temperature is below Heating Lockout. Otherwise, it will display NO.

Line 4 HP Emg Enabled

This line refers to Heat Pump Emergency Heat and will display YES if the Outdoor Air Temperature is below the Compressor Heating Lockout. Otherwise, it will display NO.

VCB-X Status Screens

Status Screen 10 - Heating Outputs - Active Stages and Mod Heat Position

```
VCB-X   v2.00 ID 101
Heating Outputs
Active Stages:  XX
Mod Heat Pos.:  XXX%
```

If this is *not* a Heat Pump unit, the screen above will be shown.

Line 3 Heating Active Stages

This line will display the number of stages of Heating that are currently active.

Line 4 Current Modulating Heating Output Signal Percentage

Indicates the percentage output signal being supplied to a Modulating Heating device when you have configured this option for your HVAC unit.

Status Screen 11 - MODGAS-X Enabled and Output %

```
VCB-X   v2.00 ID 101
MODGAS-X
Enabled...:  YES/NO
Position...:  XXX%
```

Line 3 MODGAS-X Enabled or Disabled

This indicates whether the VCB-X Controller has enabled the MODGAS-X Controller to begin to operate. If you do not have a MODGAS-X Controller connected to the VCB-X Controller, this line will indicate "NO".

Line 4 Current MODGAS-X Heating Output Signal

Indicates the percentage output signal being supplied by the MODGAS-X Controller when you have one connected to the VCB-X Controller.

Status Screen 12 - Indoor RH & Indoor RH Setpoint

```
VCB-X   v2.00 ID 101
Indoor RH:  XXX.X%
RH Spt:     XXX.X%
```

Line 2 Current Indoor Relative Humidity Percentage

If an E-BUS Space Temperature/Humidity Sensor has been installed and configured on the unit, the current Indoor Air Relative Humidity Percentage will appear on this line. If this combination Temperature/Humidity Sensor is not installed, this line will display 0%.

Line 3 Current Indoor Relative Humidity Setpoint Percentage

This is the adjustable Indoor Air Relative Humidity Setpoint Percentage that has been set by the user.

Status Screen 13 - Coil (Saturation) Temp & Setpoint & Suction Pressure

```
VCB-X   v2.00 ID 101
Coil Temp:  XXX.X
Coil Setpt: XXX.X
Suction Pr: XXX PSI
```

Line 2 Coil (Saturation) Temperature

If a Suction Pressure Transducer has been installed and configured on the unit, the calculated Evaporator Coil (Saturation) Temperature will appear on this line. If not, this line will display 0°F.

Line 3 Coil (Saturation) Temperature Setpoint

During DX dehumidification, compressor(s) will be staged/modulated to maintain this Coil Suction Temperature Setpoint. If indoor humidity reset of the Coil Setpoint has been configured, this will be the current calculated setpoint.

Line 4 Suction Pressure

This is the current Suction Pressure.

Status Screen 14 - Active Reheat Stages

```
VCB-X   v2.00 ID 101
Active Reheat
Stages:  X
```

Line 3 Active Reheat Stages - This screen is not currently used.

Status Screen 15 - MHGRV-X Enabled and Output %

```
VCB-X   v2.00 ID 101
MHGRV-X
Enabled:  YES/NO
Position:  XXX%
```

Line 3 MHGRV-X Enabled or Disabled

This indicates whether the VCB-X Controller has enabled the MHGRV-X Controller to begin to operate. If you do not have a MHGRV-X Controller connected to the VCB-X Controller, this line will indicate "NO".

Line 4 Current MHGRV-X Reheat Valve Output Signal Percentage

Indicates the percentage output signal being supplied by the MHGRV-X Controller when you have one connected to the VCB-X Controller.

VCB-X Status Screens

Status Screen 16 - PREHEAT-X Controller Status and Leaving Air Temperature Setpoint

```
VCB-X   v2.00 ID 101
Preheat-X
Enabled: YES/NO
Leaving Air: XX.XX
```

- Line 3 PREHEAT-X Enabled or Disabled**
This indicates whether the VCB-X Controller has enabled the PREHEAT-X Controller to begin to operate. If you do not have a PREHEAT-X Controller connected to the VCB-X Controller, this line will indicate "NO".
- Line 4 Leaving Air Temperature Setpoint**
This is the configured Leaving Air Temperature Setpoint.

Status Screen 17 - PREHEAT-X Controller Current Leaving Air and Entering Air Temperature

```
VCB-X   v2.00 ID 101
Preheat-X Temps
Leaving Air: XX.XX
Entering Air: XX.XX
```

- Line 3 Current PREHEAT-X Leaving Air Temperature**
If a Leaving Air Temperature Sensor(s) has been installed and configured on the PREHEAT-X, this screen will display the current Pre-Heat Leaving Air Temperature. If these conditions do not exist, it will display 0°F.
- Line 4 Current PREHEAT-X Entering Air Temperature**
If an Entering Air Temperature Sensor has been installed and configured on the PREHEAT-X, this screen will display the current Pre-Heat Entering Air Temperature. If these conditions do not exist, it will display 0°F.

Status Screen 18 - PREHEAT-X Controller Modulating Position and Active Stages

```
VCB-X   v2.00 ID 101
Preheat-X Status
Mod Pos.....: XXX%
Active Stages:   X
```

- Line 3 Current PREHEAT-X Modulating Position**
If you do have a PREHEAT-X Controller connected to the VCB-X Controller and are using Modulating Heat, this is the current modulating heat signal.
- Line 4 Current PREHEAT-X Active Stages**
If you have a PREHEAT-X Controller connected to the VCB-X Controller and are using staged heat, this is the number of stages currently active.

Status Screen 19 - OA Drybulb and Humidity

```
VCB-X   v2.00 ID 101
Outdoor Conditions
Drybulb: XXX.XX
Humidity: XXX%
```

- Line 3 Current Outdoor Air Drybulb**
If an E-BUS Outdoor Air Temperature/Humidity Sensor has been installed and configured on the VCB-X, the current Outdoor Air Temperature will display on this line. If the sensor fails, this line will display a temperature that is half way between the Cooling and Heating Lockout Setpoints.
- Line 4 Current Outdoor Air Relative Humidity**
If an E-BUS Outdoor Air Temperature/Humidity Sensor has been installed and configured on the VCB-X, the Outdoor Air Relative Humidity Percentage will appear on this line. If not, this line will display 0%.

Status Screen 20 - OA Wetbulb and Dewpoint

```
VCB-X   v2.00 ID 101
Outdoor Conditions
Wetbulb: XXX.XX
Dewpoint: XXX.XX
```

- Line 3 Current Wetbulb Temperature**
If an E-BUS Outdoor Air Temperature/Humidity Sensor has been installed and configured on the unit, this line will display the calculated Outdoor Air Wetbulb Temperature. If not, it will display 0°F.
- Line 4 Current Calculated Outdoor Air Dewpoint Temperature**
If an E-BUS Outdoor Air Temperature/Humidity Sensor has been installed and configured on the unit, the calculated Outdoor Air Dewpoint Temperature will appear on this line. If not, this screen displays 0°F.

Status Screen 21 - Economizer Enabled and Economizer Position

```
VCB-X   v2.00 ID 101
      Economizer
Enabled:  YES/NO
Position:   XXX%
```

Line 3 Economizer Enabled

This line will display YES if the Economizer is enabled and NO if the Economizer is not enabled. The Economizer is enabled whenever the Economizer Enable Temperature (options: Drybulb, Wetbulb or Dewpoint) is below the Economizer Enable Setpoint.

Line 4 Current Economizer Open Percentage

This shows the percentage signal currently being sent to the Economizer (Outdoor Air Damper), whether the unit is configured for Economizer Control or simply has a Minimum Outdoor Air Damper position configured. If Economizer Control is not configured, it will display 0%.

Status Screen 22 - Title 24 Economizer Feedback

```
VCB-X   v2.00 ID 101
      Economizer
Feedback: XXX%
[ Only For Title 24 ]
```

Line 3 Title 24 Economizer Open Percentage

If configured for Title 24 Economizer operation, this shows the Outdoor Air Damper Feedback Signal percentage. If Title 24 Economizer Control is not configured, it will display 0%.

Status Screen 23 - Economizer in IAQ Mode and Minimum Economizer Position

```
VCB-X   v2.00 ID 101
      Econo in IAQ Mode
      YES/NO
      Econo Min Pos: XXX%
```

Line 3 Economizer in IAQ Mode

This line will display YES if the Economizer (OA) Minimum Damper Position has been overridden based on CO₂ IAQ operation.

Line 4 Economizer Minimum Percentage

This shows the current Economizer (OA) Minimum Damper Position. If the unit is not in IAQ Mode, this will be the regular configured Minimum Damper Position. If the unit is in IAQ Mode, this will show the re-calculated Minimum Damper Position.

Status Screen 24 - CO₂ Level and Setpoints

```
VCB-X   v2.00 ID 101
Co2 Level: XXXX PPM
Min Setpt: XXXX PPM
Max Setpt: XXXX PPM
```

Line 2 Current CO₂ Level

Indicates the CO₂ Level. You must install and configure a CO₂ Sensor to display the CO₂ Level. If a CO₂ Sensor is not installed and configured, this line will display 0 PPM.

Line 3 Minimum CO₂ Setpoint

This is the Minimum CO₂ Setpoint that was configured in *Setpoint Screen #33*.

Line 4 Maximum CO₂ Setpoint

This is the Maximum CO₂ Setpoint that was configured in *Setpoint Screen #33*.

Status Screen 25 - Outdoor Air CFM & Supply Air CFM

```
VCB-X   v2.00 ID 101
Outdoor kCFM: XXX.XX
Supply kCFM: XXX.XX
```

Line 2 Outdoor Air CFM

If an Outdoor Air airflow monitoring station is being used, this is the current CFM reading of that device. K = 1000

Line 3 Supply Air CFM

If a Supply Air airflow monitoring station is being used, this is the current CFM reading of that device. K = 1000

Status Screen 26 - Return Air CFM & Exhaust Air CFM

```
VCB-X   v2.00 ID 101
Return kCFM: XXX.XX
Exhaust kCFM: XXX.XX
```

Line 2 Return Air CFM

If a Return Air airflow monitoring station is being used, this is the current CFM reading of that device. K = 1000

Line 3 Exhaust Air CFM

If an Exhaust Air airflow monitoring station is being used, this is the current CFM reading of that device. K = 1000

VCB-X Status Screens

Status Screen 27 - Duct Static Pressure Setpoint & Output %

```
VCB-X    v2.00 ID 101
Static Pr: X.XX in
Setpt:   X.XX in
Output:   XXX%
```

Line 2 Current Duct Static Pressure

Requires the installation and wiring of a Duct Static Pressure Sensor. If you do not have a Duct Static Pressure Sensor correctly installed and wired to the controller, this line will display "0.0".

Line 3 Duct Static Pressure Setpoint

This is the Duct Static Pressure Setpoint configured in Setpoint Screen #15.

Line 4 Current Duct Static Pressure Output Signal Percentage

Indicates the output signal percentage being supplied to the VFD Supply Fan or Bypass Damper Actuator when you have configured one of these options for your HVAC unit.

If you have not configured Duct Static Pressure Control, this line will display [No Press Out Cnfg].

Status Screen 28 - Building Pressure & Setpoint

```
VCB-X    v2.00 ID 101
Building Pressure
Pressure: XXX in
Setpt:   X.XX in
```

Line 3 Current Building Pressure

Indicates the current Building Pressure. This display requires the installation of a Building Pressure Sensor.

If you don't have a Building Pressure Sensor correctly installed and wired to the controller, this line will display "0.0".

Line 4 Building Pressure Setpoint

This is the Building Static Pressure Setpoint configured in Setpoint Screen #35.

If you have not configured Building Pressure Control, this line will display [No Press Out Cnfg].

Status Screen 29 - Building Pressure Exhaust Fan and Output %

```
VCB-X    v2.00 ID 101
Building Pressure
Exhaust Fan: ON/OFF
Output:   XXX%
```

Line 3 Building Pressure Exhaust Fan Status

Indicates whether the Exhaust Fan Relay is On or Off.

Line 4 Current Building Pressure Output Signal Percentage

Indicates the output signal percentage being supplied to the building pressure control fan or damper. For Direct Acting control, this would be to an Exhaust Fan VFD or a Modulating Exhaust Damper. For Reverse Acting control, this would be to the Outdoor Air Damper.

If you have not configured Building Pressure Control, this line will display [No Press Out Cnfg].

Status Screen 30 - Head Pressure 1 Setpoint and Condenser Fan 1 Signal

```
VCB-X    v2.00 ID 101
Head Pr: XXX PSI
Setpt:   XXX PSI
Cond. Signal: XXX%
```

Line 2 Head Pressure 1

If a Head Pressure Transducer is connected to the VCB-X EM1 Module, this line indicates the current Head Pressure Reading.

Line 3 Head Pressure Setpoint

This line indicates the current Head Pressure Setpoint.

Line 4 Condenser 1 Signal

This indicates the current percentage signal being sent to the first Condenser Fan or Valve in order to maintain the Head Pressure Setpoint.

Status Screen 31 - Head Pressure 2 Setpoint and Condenser Fan 2 Signal

```
VCB-X    v2.00 ID 101
Head Pr 2: XXX PSI
Cond Sig 2: XXX%
```

Line 2 Head Pressure 2

If a second Head Pressure Transducer is connected to the VCB-X EM1 Module, this line indicates the current Head Pressure Reading.

Line 3 Blank

Line 4 Condenser 2 Signal

This indicates the current percentage signal being sent to the second Condenser Fan or Valve in order to maintain the Head Pressure Setpoint.

VCB-X Status Screens

Status Screen 32 - Leaving Water Temperature, Entering Water Temperature & Suction Pressure

```
VCB-X v2.00 ID 101
Lvg H2O Tmp: XXX.XX
Suction Pr: XXX PSI
```

Line 2 Leaving Water Temperature

If you are using a Water Side Condenser and have a Leaving Water Temperature Sensor connected to the EM1 Module, this line displays the Leaving Water Temperature of the unit.

Line 3 Suction Pressure

This is the current Suction Pressure.

Status Screen 33 - Water Source Heat Pump Module Setpoints - Heating and Cooling

```
VCB-X v2.00 ID 101
WSHP Spts XX% Glycol
Ht Mode Lo Suct: XXX
Cl Mode Lo Suct: XXX
```

If this unit has a Water Source Heat Pump Module, these values are read directly from hard-coded information in that module. The values on Lines 3 and 4 are safety setpoints that will disable compressors. See the *Water Source Heat Pump Module Technical Guide* for further details about these safeties.

Line 2 WSHP Glycol Percentage

This line displays the percentage of glycol that the Water Source Heat Pump module is currently using.

Line 3 Heating Mode Low Suction Setpoint

This is the Heating Mode Low Suction Setpoint.

Line 4 Cooling Mode Low Suction Setpoint

This is the Cooling Mode Low Suction Setpoint.

Status Screen 34 - Water Source Heat Pump Module Setpoints - Unsafe Suction and Leaving Water Temperature

```
VCB-X v2.00 ID 101
WSHP Spts XX% Glycol
Unsafe Suction: XXX
Lo Lvg H2O Tmp: XXX
```

If this unit has a Water Source Heat Pump Module, these values are read directly from hard-coded information in that module. The values on Lines 3 and 4 are safety setpoints that will disable compressors. See the *Water Source Heat Pump Module Technical Guide* for further details about these safeties.

Line 2 WSHP Glycol Percentage

This line displays the percentage of glycol that the Water Source Heat Pump module is currently using.

Line 3 Unsafe Suction Setpoint

This is the Unsafe Suction Setpoint.

Line 4 Low Leaving Water Temperature

This is the Low Leaving Water Temperature Setpoint.

Status Screen 35 - Return Air Damper Signal & Return Air Bypass Damper Signal

```
VCB-X v2.00 ID 101
Return Dmp...: XXX%
Bypass Dmp...: XXX%
[Optional Outputs]
```

Line 2 Current Return Air Damper Signal

If configured for Return Air Bypass Control, this indicates the current Output Signal percentage being sent to the Return Air Damper Actuator. If you haven't configured a Return Air Bypass Damper, [No Return Dmp Cnfg] will be displayed instead.

Line 3 Current Return Air Bypass Damper Signal

Indicates the current Output Signal percentage being sent to the Return Air Bypass Damper Actuator. If you haven't configured a Return Air Bypass Damper, [No Bypass Dmp Cnfg] will be displayed instead.

Line 4 Indicates That These Are Optional Outputs

This output may or may not have live data to display.

Status Screen 36 - Reset Voltage Signal

```
VCB-X v2.00 ID 101
Reset Voltage Signal
0.0VDC
```

Line 2-3 Reset Voltage Signal

If using a Remote Voltage Signal to reset the Supply Air Temperature setpoint and you have an EM2 Expansion Module installed and configured, this screen will display the current Reset Voltage Signal being sent to the controller.

VCB-X Status Screens

Status Screens 37-42 - VCB-X Relays

```
VCB-X    v1.00 ID 101
On Board Rly 1 Stat
          FAN
          ON/OFF
```

Line 2 On Board Relays 1-6 Status

Line 3 Current description of what this Relay is configured for

On screen 37, this line will display FAN.
On screens 38-42, this line will indicate the relay's use.
Possible options are:

Not Used (Default)	Digital Compressor
Cooling Stage	Heating Stage
Condenser #1	Condenser #2
HP Water Valve	HP Compressor
HP Reversing Valve	HP Aux Heat
HP Emergency Heat	Mod Heat Enable
Mod Cool Enable	Warmup / Cooldown
Reheat	Preheat
Low Ambient	Exhaust Fan
Economizer	Heat Wheel
Occupied Mode	Override Mode
Alarm Active	

Line 4 Current Relay Status

This line will display the ON/OFF condition for that relay.
FORCED ON or FORCED OFF will appear if this Relay is in a Force Mode. Possible options are as follows:

ON	OFF
FORCED ON	FORCED OFF

Status Screens 43-47 - EM1 Relays

```
VCB-X    v1.00 ID 101
Main Exp Rly 1
Relay Name
          ON/OFF
```

Line 2 On Board Relays 1-5 Status

Line 3 Current description of what this Relay is configured for

On screens 43-47, this line will indicate the relay's use.
Possible options are:

Not Used (Default)	Digital Compressor
Cooling Stage	Heating Stage
Condenser #1	Condenser #2
HP Water Valve	HP Compressor
HP Reversing Valve	HP Aux Heat
HP Emergency Heat	Mod Heat Enable
Mod Cool Enable	Warmup / Cooldown
Reheat	Preheat
Low Ambient	Exhaust Fan
Economizer	Heat Wheel
Occupied Mode	Override Mode
Alarm Active	

Line 4 Current Relay Status

This line will display the ON/OFF condition for that relay.
FORCED ON or FORCED OFF will appear if this Relay is in a Force Mode. Possible options are as follows:

ON	OFF
FORCED ON	FORCED OFF

VCB-X Status Screens & Alarms

Status Screens 48-59 - 12 Relay Expansion
Module Relays

```
VCB-X    v2.00 ID 101
12 Rly Bd Rly 1
Relay Name
ON/OFF
```

Line 2 On Board Relays 1-12 Status

Line 3 Current description of what this Relay is configured for

On screens 48-59, this line will indicate the relay's use.
Possible options are:

Not Used (Default)	Digital Compressor
Cooling Stage	Heating Stage
Condenser #1	Condenser #2
HP Water Valve	HP Compressor
HP Reversing Valve	HP Aux Heat
HP Emergency Heat	Mod Heat Enable
Mod Cool Enable	Warmup / Cooldown
Reheat	Preheat
Low Ambient	Exhaust Fan
Economizer	Heat Wheel
Occupied Mode	Override Mode
Alarm Active	

Line 4 Current Relay Status

This line will display the ON/OFF condition for that relay.
FORCED ON or FORCED OFF will appear if this Relay is
in a Force Mode. Possible options are as follows:

ON	OFF
FORCED ON	FORCED OFF

Status Screens 60 - 90 - Alarm Status

Press **<ALARMS>**. The *Unit Selection Screen* will be displayed.
Enter the Unit ID of the controller you wish to search and press
<ENTER>. You must type in the number, even if it is "1".
Once communication is established, "No Communication"
will be replaced with "Press Down." Then press **<↓>**.

The System Manager or Service Tool will search for any active
alarms on the unit and one of the following screens will appear:

```
VCB-X    v2.00 ID 101

NO ALARMS
SCROLL DOWN TO VIEW
```

VCB-X v2.00 ID 101

```
ALARMS PRESENT
SCROLL DOWN TO VIEW
```

Line 2 Blank

Line 3 NO ALARMS OR ALARMS PRESENT

If alarms are present, the screens that follow will display
one or more of the following:

Bad SAT Sensor
Bad RAT Sensor
Bad OAT Sensor
Bad Space Sensor
Missing EM1
Bad Coil Sensor
Bad CO₂ Sensor
Bad Compressor Discharge Sensor
Missing Outdoor Airflow Sensor
Missing Exhaust Airflow Sensor
Missing Supply Air Airflow Sensor
Missing Return Air Airflow Sensor
Missing MHGRV-X
Missing MODGAS-X
Missing 12RLY
Missing EM2
Mech Cooling Failure
Mech Heating Failure
Fan Proving Alarm
Dirty Filter Alarm
Emergency Shutdown
High Supply Air Temperature Cutoff
Low Supply Air Temperature Cutoff
High Control Temp
Low Control Temp
Digital Compressor Cutoff
Digital Compressor Lockout
High Head Pressure 1
WSHP Proof of Flow Failure
Low Suction Pressure
High Suction Pressure
WSHP Low Water Temperature
High Head Pressure 2
Preheat Alarm
Missing Head Pressure 1
Missing Head Pressure 2
Title 24 Economizer Air Temp Sensor Fail
Title 24 Economizer Damper Fail
Title 24 Economizer Not Economizing When It
Should
Title 24 Economizer Economizing But Shouldn't
Title 24 Economizer Excess Outdoor Air

Press **<↓>** to scroll through all active alarms.

For Alarm Definitions, see the *VCB-X Controller Field
Technical Guide*.

VAV/ZONE CONFIGURATION

VAV/Zone Configuration Screens

VAV/Zone Configuration

In order to correctly set up the VAV/Zone Controller, you must first configure several parameters in regard to the type of system and operating parameters for the VAV/Zone Controller you have installed. Most of these values and operating parameters are only set once at the initial system setup and are never changed.

Modular Service Tool Instructions

From any *Menu Screen*, press the **<CONFIGURATION>** button. The *Unit Selection Screen*, shown below, will appear requesting that you enter the unit ID number.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the correct unit ID number of the VAV/Zone controller you want to configure, and press **<ENTER>**. Once communication is established, “No Communication” will be replaced with “Press Down.” Then press **<↓>**. You will then see *Unit Configuration Screen #1*. Press **<ENTER>** to save entered data and press **<↓>** to scroll through the screens.

NOTE: If “No Communication” remains, it indicates a communication failure to the controller.

System Manager SD Instructions

From any Main screen, press **<SETPOINTS>**. The screen below will appear because this option requires passcode clearance. Only a Level 2 passcode can change setpoints.

THIS ACTION REQUIRES
PASSCODE CLEARANCE
Enter Passcode: XXXX

If the correct passcode was entered, the *Unit Selection Screen* will be displayed.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the Unit ID of the controller you wish to change schedules for and press **<ENTER>**. Once communication is established, “No Communication” will be replaced with “Press Down.” Then press **<↓>**.

NOTE: If “No Communication” remains, it indicates a communication failure to the controller.

The following screen will be displayed:

Change Setpoints
Configure Unit
Save/Copy/Restore

Scroll down to the ‘Configure Unit’ option and press **<ENTER>**. This will take you to the first Configuration Screen shown below.

Configuration Screen #1 - Box Configuration

XX Box Cnfg IDXXXX
Box Configuration
COOLING ONLY BOX
Use < Or > To Change

This Box Control Code will operate in one of four possible modes. The box designation will display on the top line of all screens.

- 0 = COOLING ONLY BOX (will display as CO Box)
- 1 = H/C CHANGEOVER BOX (will display as HC Box)
- 2 = SERIES FAN BOX (will display as SF Box)
- 3 = PARALLEL FAN BOX (will display as PF Box)

Configuration Screen #2 - Damper Operation

XX Box Cnfg IDXXXX
Damper Operating
Mode: DIRECT ACTING
Use < Or > To Change

Select Direct Acting or Reverse Acting. If the damper opens in a *clockwise* direction, it is DIRECT ACTING. If the damper opens in a *counter-clockwise* direction, it is REVERSE ACTING.

CAUTION: If you change this setting, you MUST cycle power to the controller to allow it to re-calibrate the damper feedback positions for its new direction of control!

VAV/Zone Configuration Screens**Configuration Screen #3 - Voting Zone**

```
XX Box Cnfg  IDXXXX
Is This Box a
Voting Zone...: YES
Use < Or > To Change
```

If this is a Zoned System, *select* YES so that the box can be included as a voting zone.

Configuration Screen #4 - Pressure Independent Airflow Constant

```
XX Box Cnfg  IDXXXX
Pr Independent Boxes
Airflow @ 1" WG
Constant...: 1200 CFM
```

If this is a Pressure Independent Box, you must enter this airflow constant so that the CFM readings can be correctly calculated. This airflow constant is provided by the box manufacturer and depends on the diameter of the duct.

Configuration Screen #5 - Expansion Relays Heating Stages

```
XX Box Cnfg  IDXXXX
Expansion Relays
[Optional]
Steps of Reheat.: 2
```

If you require the VAV/Zone Controller to control reheat for the zone it is installed in, you must include a relay expansion board and then configure the number of heating stages (1, 2, or 3) that it will be controlling whenever there is a heating demand in the space. *Enter* <0> if you don't require this option.

Configuration Screen #6 - Proportional Heating Signal

```
XX Box Cnfg  IDXXXX
Proportional Heating
Signal...: 0 - 10 VDC
Use < Or > To Change
```

Select 0-10 VDC or 2-10 VDC as the range of the proportional heat output.

Configuration Screen #7 - Box Heat Allow

```
XX Box Cnfg  IDXXXX
Allow Box Heat With
HVAC Heat....: NO
Use < Or > To Change
```

Select YES to allow the Heating Relay's Controlling Box Heat to remain on even when the HVAC unit is in Supply Air Heating Mode. This is used as a method to provide supplemental heat if for some reason the HVAC heat cannot satisfy the heating demand.

Configuration Screen #8 - Main Fan Status

```
XX Box Cnfg  IDXXXX
This Unit Needs Main
Fan Status...: NO
Use < Or > To Change
```

This setting only applies to the unoccupied mode of operation. *Select* YES to activate the heating stages only when the main fan is operating on non-fan terminal units. For series fan terminal units, if this setting is set to YES, the series box fan will only run when the main HVAC unit fan is running or when a space heating demand is made. For series fan terminal units, if this setting is set to NO, the series box fan will only run when a space heating demand is made. This setting has no effect on the parallel flow fan terminal unit.

Configuration Screen #9 - Push-Button Override

```
XX Box Cnfg  IDXXXX
Push-Button Override
Group ID #: 1
```

During Unoccupied Mode, all zones with a corresponding Group ID # will resume Occupied operation whenever any of the zones in that group has its push-button depressed to initiate an override condition. This allows you to group zones in various areas of the building. For example, individual tenants with several offices could restore occupied mode for just their zones and not affect other zones in the building.

The default group ID number for all VAV/Zone Controllers is set at the factory to 1. If you don't want a specific zone(s) to be part of that group, you must give each one a distinct Group ID number between 2 and 16. Setting a zone's Group ID number to 0 will disable the Space Sensor Override Button function.

If you don't want a specific zone to be a part of any group, *enter* <0> for its Group ID #.

VAV/ZONE CONFIGURATION

VAV/Zone Configuration Screens

Configuration Screen #10 - Dump Zone

```
XX Box Cnfg IDXXXX
Is This A Dump Zone
(No Actuator): NO
Use < Or > To Change
```

A “Dump Zone” is used when you want to control a duct heater or baseboard heater independently. A VAV/Zone Controller board with a relay expansion board is used for this purpose. No damper or actuator is used. If you need to control an auxiliary heater, *select* YES; otherwise, be sure it is set to NO.

Configuration Screen #11 - HVAC Unit is on Separate Loop

```
XX Box Cnfg IDXXXX
HVAC Unit is on
Separate Loop: NO
Use < Or > To Change
```

If this system has 1 HVAC unit controlling boxes on multiple loops and the HVAC unit is on a different loop than this box, *select* YES; otherwise, be sure it is set to NO.

VAV/Zone Controller Setpoints

Modular Service Tool Instructions

From any menu screen, *press* **<SETPOINTS>**. The *Unit Selection Screen*, shown below, will appear requesting that you enter the unit ID number.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the correct unit ID number of the Controller you want to change Setpoints for and *press* **<ENTER>**. Once communication is established, "No Communication" will be replaced with "Press Down." Then *press* **<↓>**. You will then see Setpoint Screen #1. *Press* **<ENTER>** to save entered data and *press* **<↓>** to scroll through the screens.

NOTE: If "No Communication" remains, it indicates a communication failure to the controller.

System Manager SD Instructions

From any Main screen, *press* **<SETPOINTS>**. The screen below will appear because this option requires passcode clearance. Only a Level 2 passcode can change setpoints.

THIS ACTION REQUIRES
PASSCODE CLEARANCE
Enter Passcode: XXXX

If the correct passcode was entered, the *Unit Selection Screen* will be displayed.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the Unit ID of the controller you wish to change schedules for and *press* **<ENTER>**. Once communication is established, "No Communication" will be replaced with "Press Down." Then *press* **<↓>**.

NOTE: If "No Communication" remains, it indicates a communication failure to the controller.

The following screen will be displayed:

Change Setpoints
Configure Unit
Save/Copy/Restore

Scroll to the 'Change Setpoints' option and *press* **<ENTER>**. This will take you to the first Setpoints Screen shown below.

Setpoint Screen #1 - Occupied Setpoints

XX Box Spts IDXXXX
Occupied Setpoints
Cooling.....: XX°F
Heating.....: XX°F

Enter the **Occupied Cooling Setpoint** as the maximum temperature you would like the zone to reach before modulating the damper open to bring in more cold air to cool the space. Enter the **Occupied Heating Setpoint** as the minimum temperature you would like the zone to reach before activating the Reheat Stages on the optional Expansion Relay board. If this is a Cooling Only box that doesn't contain reheat, this setpoint will be ignored.

Description	Minimum	Default	Maximum
Cooling Setpoint	50°F	74°F	90°F
Heating Setpoint	50°F	70°F	90°F

Setpoint Screen #2 - Unoccupied Setbacks

XX Box Spts IDXXXX
Unoccupied Setbacks
Cooling SetUp: XX°F
Heating SetBk: XX°F

During unoccupied hours, the Occupied Cooling Setpoint is adjusted up by the amount entered for the Cooling SetUp. The Occupied Heating Setpoint is adjusted down by the amount entered for the Heating SetBk.

Description	Minimum	Default	Maximum
Cooling SetUp	0°F	+10°F	+30°F
Heating SetBk	0°F	-10°F	-30°F

VAV/ZONE CONFIGURATION

VAV/Zone Setpoint Screens

Setpoint Screen #3 - AHU Heat Call Space Temp

XX Box Spts IDXXXX
AHU Heat Call
Space Temp...: XX°F

This setpoint allows you to set a Space Temperature that will cause the VAV/Zone Controller to send a call for heat to the HVAC unit. This only occurs in the Unoccupied Mode.

Description	Minimum	Default	Maximum
AHU Heat Call Space Temp	50°F	70°F	90°F

Setpoint Screen #4 - Auxiliary Heat Setpoint

XX Box Spts IDXXXX
Auxiliary Heat
Setpoint...: XX°F

This setpoint allows you to set a Space Temperature that will enable the Auxiliary Heat Relay (Relay 4) on the VAV/Zone Controller Re-heat Expansion Board for heating options other than box heat, such as baseboard heat or an external duct heater. This could control a stage of electric heat or an on/off hot water valve. The Auxiliary Heat Relay will energize at .5°F below this setpoint and will de-energize at .5°F above this setpoint. The Auxiliary Heat will continue to function regardless of the HVAC Mode the unit is in and at any airflow condition.

Description	Minimum	Default	Maximum
Auxiliary Heat Setpoint	50°F	70°F	90°F

Setpoint Screen #5 - Damper Airflow Integral

XX Box Spts IDXXXX
Damper/Airflow Spt
Integral [Ki]...: XXX

The VAV/Zone Controller normally opens its damper based on a Proportional Error from Setpoint. That means if the zone temperature is 4°F from setpoint, the damper would be 100% open, or it would be modulating to provide the Maximum CFM on Pressure Independent boxes. If the error is less than 4°F, the damper may stagnate at that position and never satisfy the zone. If you add **Integral** into the damper calculation process, this will cause the damper or airflow calculations to continue to increase as long as the zone temperature is still above the setpoint. That means it can provide 100% or Maximum CFM before the 4°F error is achieved, bringing the zone under control faster than it normally would. Start with a small (5 or 10) value, if you use this, and monitor

the effect it has. If you enter too large a value, you can create “hunting” situations that can cause the damper actuator to prematurely wear out.

Description	Minimum	Default	Maximum
Integral	0	0	100

Setpoint Screen #6 - Damper Airflow Max & Vent Min

XX Box Spts IDXXXX
Damper/Airflow Spt
Maximum...: XXX %
Vent Min...: XXX %

The VAV/Zone Controller will not allow the damper or airflow calculation to exceed the Maximum setpoint while it is allowing the damper to modulate. During Vent mode when there is no heating or cooling demand, the damper or airflow will maintain at least the Vent Min amount of airflow into the zone for ventilation.

Description	Minimum	Default	Maximum
Maximum	0% or 0 CFM	100% or 1000 CFM	100% or 30000 CFM
Vent Min	0% or 0 CFM	25% or 250 CFM	100% or 30000 CFM

Setpoint Screen #7 - Damper Airflow Cool/Heat Minimum

XX Box Spts IDXXXX
Damper/Airflow Spt
Cool Min...: XXX %
Heat Min...: XXX %

During Supply Air Cooling Mode, if the space being served by this damper is satisfied and has no cooling demand, the damper will close to this Cool Min setting. This provides a minimum amount of airflow into the space for ventilation, even if the space does not require additional cooling. During Supply Air Heating Mode, if the space being served by this damper is satisfied and has no heating demand, the damper will close to this Heat Min setting. This provides a minimum amount of airflow into the space for ventilation, even if the space does not require additional heating.

Description	Minimum	Default	Maximum
Cool Min	0% or 0 CFM	10% or 1000 CFM	100% or 30000 CFM
Heat Min	0% or 0 CFM	10% or 100 CFM	100% or 30000 CFM

VAV/Zone Setpoint Screens

Setpoint Screen #8 - Damper Airflow Night Min and Fan On Min

```

XX Box Spts IDXXXX
Damper/Airflow Spt
Night Min.:      XXX %
Fan On Min.:     XXX %
  
```

The Night Min position is the position the damper will move to when the system is in Pushbutton Override Mode and this particular damper is not part of that Override Group. When not in Pushbutton Override, pressure independent boxes will only go to the Night Min CFM setpoint position if it is set to 0. Pressure dependent boxes will always stay at the Night Min position. This Night Min position only affects non fan powered boxes. The Fan On Min is the minimum damper or airflow setting used to activate the parallel fan if installed. Pressure Independent = CFM. Pressure Dependent = %.

Description	Minimum	Default	Maximum
Night Min	0% or 0 CFM	0% or 0 CFM	100% or 9999 CFM
Fan On Min	0% or 0 CFM	25% or 250 CFM	100% or 9999 CFM

Setpoint Screen #9 - Damper Airflow Reheat Min

```

XX Box Spts IDXXXX
Damper/Airflow Spt
Reheat Min.:      XXX %
  
```

The Reheat Min is the damper or airflow setting used during the Space Reheat Mode of operation.

Description	Minimum	Default	Maximum
Reheat Min	0% or 0 CFM	0% or 0 CFM	100% or 30000 CFM

Setpoint Screen #10 - Damper Airflow Fixed Position

```

XX Box Spts IDXXXX
Damper/Airflow Spt
Fixed Pos:        XXX %
  
```

Many times while troubleshooting a system, it is useful to have the zone damper set to a specific damper position or airflow setting. This setpoint can be used to determine where the damper/airflow will remain when the VAV/Zone Controller receives a *Force to Fixed Position* command.

Description	Minimum	Default	Maximum
Fixed Pos	0% or 0 CFM	0% or 0 CFM	100% or 9999 CFM

Setpoint Screen #11 - SAT HVAC Mode Deadband

```

XX Box Spts IDXXXX
SAT HVAC Mode
Deadband.:      XX°F
  
```

If the supply air temperature is above the space temperature by this amount, the VAV/Zone controller enters the Supply Air Heating Mode. It will remain in the Supply Air Heating Mode until the supply air drops to 2°F above the space temperature. At that point the unit enters the Supply Air Vent Mode and remains there until the supply air drops this deadband below the space temperature. At that point the VAV/Zone Controller enters the Supply Air Cooling Mode and will remain there until the supply air temperature rises to 2°F below the space temperature.

Description	Minimum	Default	Maximum
SAT HVAC Mode Deadband	0°F	10°F	20°F

Setpoint Screen #12 - Zone Alarm Offsets

```

XX Box Spts IDXXXX
Zone Alarm Offsets
Hi Zone.....:  XX°F
Lo Zone.....:  XX°F
  
```

The VAV/Zone Controller can be setup to generate an alarm anytime the box goes into the Occupied Mode and the Zone Temperature exceeds the user-defined alarm limits for a user-defined period of time. A *High Temperature Alarm Setpoint* is created by adding the **Hi Zone Alarm** offset to the current *Cooling Setpoint*. The *Low Temperature Alarm Setpoint* is created by adding the **Lo Zone Alarm** offset to the current *Heating Setpoint*. If the zone temperature exceeds either of these limits for a period defined by the **Alarm Delay** setpoint, the controller can generate an alarm callout if all the optional hardware components required for this to occur are installed.

Description	Minimum	Default	Maximum
Hi Zone Alarm	+1°F	+30°F	+50°F
Lo Zone Alarm	-1°F	-30°F	-50°F

VAV/ZONE CONFIGURATION

VAV/Zone Setpoint Screens

Setpoint Screen #13 - Zone Alarm Delay

```
XX Box Spts IDXXXX
Zone Alarm Delay
Must Be Out Of
Limits For.: XXX Min
```

As mentioned above, if you configure the controller to generate zone temperature alarms, this is the amount of time after the box goes into the Occupied Mode that the temperature must be outside the alarm limits before an alarm is generated.

Description	Minimum	Default	Maximum
Out of Limits	1 Min	30 Min	300 Min

Setpoint Screen #14 - Day/Night Schedule

```
XX Box Spts IDXXXX
Day/Night Schedule
Control #: X
0=AHU 1-5=Scheduler
```

This screen allows you to set the VAV/Zone controller to operate on a remote schedule instead of the schedule that is contained in the VCB-X controller. Enter <0> to operate on the AHU schedule. Enter <1-5> to use an external schedule. A GPC Plus is required for schedules 1-5.

Description	Minimum	Default	Maximum
Schedule Control Number	0	0	1 to 5

Setpoint Screen #15 - Maximum Slide Offset

```
XX Box Spts IDXXXX
Maximum Slide Offset
Effect on Spt.: X°F
```

If the Flush Mount Wall Sensor has the optional Setpoint Slide Adjust, this is the maximum amount you can adjust the heating and cooling setpoints up or down as the slide is moved from the center position to its full up or down position.

Description	Minimum	Default	Maximum
Effect on SP	0°F	0°F	6°F

Setpoint Screen #16 - Push-Button Override Duration

```
XX Box Spts IDXXXX
Push-Button Override
Duration : X.X Hr
```

If the Flush Mount Wall Sensor has the optional Push-Button Override, this is the amount of the VAV/Zone Controller will resume using its Occupied Setpoints during unoccupied mode. This will generate a call for the Air Handler to start its fan and provide heating or cooling, depending on how you configure the Air Handler.

Description	Minimum	Default	Maximum
Duration	0.0 Hr	0.0 Hr	8.0 Hr

Setpoint Screen #17 - Maximum EMS Offset

```
XX Box Spts IDXXXX
Maximum EMS Setpoint
Offset...: XX°F
```

If the Energy Management System (EMS) is activated, the heat and cool setpoints can be spread apart by this amount.

Description	Minimum	Default	Maximum
Maximum EMS Setpoint Offset	0°F	0°F	30°F

Setpoint Screen #18 - Sensor Calibration for Space Temp and Supply Air Temp

```
Sensor Calibration
SPC: XXX.X° XXX.X°
SAT: XXX.X° XXX.X°
[SAT Only if Sensor]
```

The Thermistor Type III sensor readings can be calibrated. Enter a Positive value to increase a reading and a Negative value to decrease a reading.

Note: The Supply Air Temperature calibration offset only operates on the reading when the VAV/Zone Controller has its own Supply Air Temperature sensor installed on the AUX2 input. If the supply temperature is received from a global broadcast, you will need to go to the air handler to calibrate the temperature reading.

Description	Minimum	Default	Maximum
SPC (Space Temp)	-100°F	0°F	+100°F
SAT (Supply Air)	-100°F	0°F	+100°F

VAV/Zone Status

Status Screen #1 - Mode of Operation

```
XX Box v4.01 IDXXXX
Occupied Mode
Vent Mode
Belongs to Group # 1
```

Line 2 Unoccupied Mode
Occupied Mode
Override Mode
Override Pending*
Damper Calibration
Group Override

Line 3 OFF Mode
Vent Mode
Cooling Mode
Heating Mode
Sensor Fail Mode**

Line 4 Belongs to Group # xx
No Group Affiliation

* Not displayed when using a Digital Room Sensor.

** Displays for either a temperature sensor failure or an airflow sensor failure.

Status Screen #2 - Zone Temperature and Cooling/Heating Setpoints

```
XX Box v4.01 IDXXXX
Zone Temp.: XX.X°F
Cooling Spt: XX.X°F
Heating Spt: XX.X°F
```

Line 2 Current Zone Temperature

Line 3 Currently active Cooling Setpoint based on the current Occupied / Unoccupied mode of operation.

Line 4 Currently active Heating Setpoint based on the current Occupied / Unoccupied mode of operation.

Status Screen #3 - Slide Offset & H/C Demand

```
XX Box v4.01 IDXXXX
Slide Offset: XX°F
H/C Demand.: XX.X°F
```

Line 2 If the optional Setpoint Slide Adjust is installed on the Flush Mount Wall Sensor, this line will display the current amount the **Slide Offset** is affecting the Heating and Cooling Setpoints.

Line 3 Current **Heating or Cooling Demand** in the Zone based on the current Heating and Cooling Setpoints when compared to the current Zone Temperature.

Line 4 Blank

Status Screen #4 - Supply Air Temperature & Box Air Temperature

```
XX Box v4.01 IDXXXX
Supply Air: XX.X°F
Box Air.: XX.X°F
```

Line 2 **Current Supply Air Temperature** received via broadcast from the DX Air Handler or from the Box Controller's own installed Box Air Temperature Sensor connected to the AUX input of the VAV/Zone controller board.

Line 3 **Current Box Air Temperature**
If you have configured the VCB-X controller to broadcast the Supply Air Temperature to the VAV/Zone controller and don't have a Box Air Temperature Sensor attached to the AUX input on the VAV/Zone controller board, this line will display the Supply Air Temperature the same as line 2.

If you have a Box Air Temperature Sensor attached to the AUX input on the VAV/Zone controller board, this line will display the Box Air Temperature at the location where the Box Air Temperature Sensor is installed.

Line 4 Blank

VAV/ZONE STATUS

VAV/Zone Status Screens

Status Screen #5 - Zone Damper Position, Airflow, and Desired CFM

```
XX Box v4.01 IDXXXX
Damper FRC:   XXX %
Airflow   :   XXXX CFM
Desired    :   XXXX CFM
```

- Line 2** Current Zone Damper Position
If you entered a FORCE command, the letters FRC will appear. If this is normal damper operation, the FRC will not be displayed.
- Line 3** If this is a Pressure Independent box, the current Airflow will be displayed. If not, this line will display the desired damper position.
- Line 4** If this is a Pressure Independent box, this line will display the Desired CFM the box would like to provide to the zone. If not, this line will display [Controls to +/- 3%] to indicate how accurately the damper will maintain the desired position.

Status Screen #6 - Fan Status & Reheat Stages

```
XX Box v1.04 IDXXXX
Fan Status      : OFF
Heating Relay#1 : OFF
Heating Relay#2 : OFF
```

- Line 2** If this is a Fan Powered box, this line will display the Fan On/Off Status. On non-fan powered boxes, this line will display [Exp Relay 1 Not Used].
- Line 3** If your VAV/Zone Controller has been configured to control reheat stages, this line reflects the On/Off Status of the first stage of Reheat. If you have 3 stages of reheat, this line will display the total number of active heating stages.

Examples:

“1 Reheat Stages On” or

“2 Reheat Stages On” or

“3 Reheat Stages On”

If proportional heating is used (you have no relays configured for heat), this line will display “Heating Signal: xxx %”.

- Line 4** If your VAV/Zone Controller has been configured to control reheat stages, this line reflects the On/Off Status of the second stage of Reheat. If you have 3 stages of reheat as explained on line 2, this line will be blank.

Status Screen #7 - Alarm Status

```
XX Box v1.04 IDXXXX
```

NO ALARMS!

```
XX Box v.104 IDXXXX
```

ALARMS PRESENT
SCROLL DOWN TO VIEW

- Line 2** Blank
- Line 3** NO ALARMS! OR ALARMS PRESENT
If there are one or more alarms active, the possible messages are shown below:
- SPACE SENSOR FAILURE
CFM SENSOR FAILURE
DAMPER OPENING ALARM
DAMPER CLOSING ALARM
HI SPACE TEMP ALARM
LO SPACE TEMP ALARM
DPR FEEDBACK FAILURE

Press <↓> to scroll through all active alarms.

For Alarm Definitions, see the *VCB-X Controller Field Technical Guide*.

Damper Force Modes

Damper Force Modes are available for testing or balancing the system. These Force Modes can be accessed and programmed from the Modular Service Tool.

Modular Service Tool Instructions

When using the Modular Service Tool, simply *press* the **<BALANCE - TEST>** key. You will then see the *Unit ID Screen*. Enter the unit ID of the controller you wish to access and *press* **<ENTER>**. Once communication is established, “No Communication” will be replaced with “Press Down.” Then *press* **<↓>**.

NOTE: If “No Communication” remains, it indicates a communication failure to the controller.

The following screen will be displayed:

```
Damper Force
Para Blocks
Load / Save / Copy
```

With the cursor on Damper Force, *press* **<ENTER>** to access the *Damper Force Mode Screen*.

Dampers Force Mode Screen

If the unit ID you entered is for a VCB-X Controller that has VAV/Zone Controllers connected to its communication loop, the Damper Force Mode will act as a “Global” Damper Force Mode. That is, all VAV/Zone Controllers on that VCB-X Controller’s communication loop will be forced to the same Damper Force Mode setting. If the unit ID you entered is for a VAV/Zone Controller, the Damper Force Mode setting will only apply to that VAV/Zone Controller.

```
Damper Force
Enter Force Mode: 0
0=Auto 1=Open 2=Clsd
3=Max 4=Min 5=Fixed
```

Set the appropriate Damper Force Mode by entering numbers 0 through 5. Following is a list of the force modes and their meaning:

0 = Auto This is the default setpoint. With this setting, the damper will operate normally and modulate according to the controller setpoints.

1 = Open This setting will force the dampers to their fully-open position.

2 = Clsd This setting will force the damper to its fully-closed position.

3 = Max This setting will force the damper to its Maximum Position Setpoint. See *VAV/Zone Controller Setpoint Screen #5* on **page 70** for complete setpoint information.

4 = Min This setting will force the damper to its Minimum Position Setpoint. See *VAV/Zone Controller Setpoint Screen #5* on **page 70** for complete setpoint information.

5 = Fixed This setting will force the damper to a fixed position based on the Fixed Position Setpoint. See *VAV/Zone Controller Setpoint Screen #8* on **page 71** for complete setpoint information.

CAUTION: The Damper Force Modes should only be used by qualified service personnel. Serious damage to the ductwork could result if the dampers are all forced closed and the HVAC unit fan is operating.

MINILINK PD CONFIGURATION

MiniLink PD Configuration Screens

MiniLink PD Configuration

NOTE: If this is not a voting system, the only screens you need to configure are Screens 6 through 65 if alarm polling pertains to your system.

In order to correctly setup the MiniLink PD, you must first configure several parameters in regard to the type of system and operating parameters for the system it is installed on. Most of these values and operating parameters are only set once at the initial system setup and are never changed.

Modular Service Tool Instructions

From any menu screen, press **<SETPOINTS>**. The *Unit Selection Screen*, shown below, will appear requesting that you enter the unit ID number.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

All MiniLink PDs are set at address 60. Enter the correct unit loop number for the loop the MiniLink Polling Device is connected to (for Loop 1 you would enter **<160>**) and press **<ENTER>**. Once communication is established, "No Communication" will be replaced with "Press Down." Then press **<↓>**.

NOTE: If "No Communication" remains, it indicates a communication failure to the controller.

You will then see Setpoint Screen #1. Press **<ENTER>** to save entered data and press **<↓>** to scroll through the screens.

System Manager SD Instructions

From any Main screen, press **<SETPOINTS>**. The screen below will appear because this option requires passcode clearance. Only a Level 2 passcode can change setpoints.

THIS ACTION REQUIRES
PASSCODE CLEARANCE
Enter Passcode: XXXX

If the correct passcode was entered, the *Unit Selection Screen* will be displayed.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the Unit ID of the controller you wish to change schedules for and press **<ENTER>**. Once communication is established, "No Communication" will be replaced with "Press Down." Then press **<↓>**.

NOTE: If "No Communication" remains, it indicates a communication failure to the controller.

The following screen will be displayed:

Change Setpoints
Configure Unit
Save/Copy/Restore

Scroll to the 'Change Setpoints' option and press **<ENTER>**. This will take you to the first Setpoints Screen shown below.

Configuration Screen #1 - System Type

Polling Unit Config
System Type
Selection: ZONING
Use < Or > To Change

This screen allows you to select whether you want the system to behave as a VAV system or a Zoning System. If you select VAV, this will allow tenant logging for your VAV system.

Configuration Screen #2 - Last Polled Zone

Polling Unit Config
Last Polled Zone
Address: XX
[Enter Last Zone]

This zone is the last zone on the local loop of your zoning system that is to be included in zone voting.

Configuration Screen #3 - Mode Changeover Time

Polling Unit Config
Mode Changeover Time
Minutes: XX
[Enter Period Time]

This is the amount of time that you want to allow between changeover from heating to cooling modes.

MiniLink PD Configuration and Status Screens

Configuration Screen #4 - Optimal Start Target Zone

```
Polling Unit Config
Optimal Start
Target Zone.: XXX
[Enter Target Zone]
```

This is the unit ID of the Zone that you want to be satisfied by the normally scheduled start time. If you enter “-1” into this box, it will average all zones instead of picking a specific zone. If you do not require Optimal Start, enter “0”.

Configuration Screen #5 - Maverick Testing

```
Polling Unit Config
Maverick Testing
Disabled: YES
Use < Or > To Change
```

Disabling the Maverick Testing allows known troubled zone(s) to continue voting without causing a Maverick alarm. In other words, all zones are included in the voting regardless of whether they are more than four degrees from setpoint.

Configuration Screens #6-65 - Alarm Polling

```
Polling Unit Config
Enable Alarm Polling
Unit XX : YES
Use < Or > To Change
```

Enabling Alarm Polling allows any alarm from the loop to be polled. You must set this for each controller on the loop.

MiniLink PD Status

Status Screen #1 - Schedule Mode, System Status, and Minutes Left

```
Polling Device
System Occupied
Venting Mode
XXX Min Left in Mode
```

- Line 2 Current Schedule Mode**
Can be System Occupied or System Unoccupied.
- Line 3 Currently System Status**
Can be Vent Mode, Cooling Mode, or Heat Mode.
- Line 4 Minutes Left In Mode**
The number of minutes left in the current mode of operation before it can switch modes. This value is user-adjustable. See Configuration Screen #3.

Status Screen #2 - Mode Priority, Cool Total, and Heat Total

```
Polling Device
No Mode Priority
Cool Total.: XX.X°F
Heat Total.: XX.X°F
```

- Line 2 Mode Priority**
Can be Heat Priority or Cool Priority. This is based on the voting zones and their demand.
- Line 3 Cool Total**
Total cooling temperature demand from all zones.
- Line 4 Heat Total**
Total heating temperature demand from all zones.

VCB-X Outputs Force

Outputs Force

Outputs Force settings are available for testing or troubleshooting the system. These Force settings can only be accessed and programmed from the Modular Service Tool.

CAUTION: The Outputs Force settings should only be applied by qualified service personnel. Serious damage to the HVAC unit could result from improper use of these Outputs Force settings.

To access the Outputs Force settings, simply *press* the **<BALANCE - TEST>** button on the Modular Service Tool. You will then see the *Unit ID Screen*.

Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication

Enter the unit ID of the VCB-X Controller you wish to access and *press* **<ENTER>**. Once communication is established, “No Communication” will be replaced with “Press Down.” Then *press* **<↓>**. You will then see the screen shown below. *Press* **<ENTER>** to save entered data and *press* **<↓>** to scroll through the screens.

NOTE: If “No Communication” remains, it indicates a communication failure to the controller.

NOTE: The Outputs Force settings are only available for the VCB-X Controller. They are not supported for the VAV/ Zone Controllers or other Add-on controllers.

Outputs Force
Para Blocks
Save / Load / Copy

Place the cursor on Outputs Force and *press* **<ENTER>** to access the *Outputs Force Screen*.

Supply Fan Override
Auto

Use < Or > To Change

The first *Outputs Force Screen* allows the AHU fan relay to be set for Auto, Force On, or Force Off. The default setting is Auto. After you complete all troubleshooting or testing procedures, all relays should be changed back to this setting. The Force On setting will force the relay to the ON (energized) position. The Force Off selection will force the relay to the OFF (de-energized) position.

The next screen displays the Relay Overrides for Relay 2. After *pressing* **<ENTER>** to save any changes, *press* **<↓>** to have the next relay displayed. All 23 *Relay Override Screens* (including the AHU fan relay) are available by *pressing* **<↓>** after each setting is saved by *pressing* **<ENTER>**.

Relay Overrides
Relay 2 Override
Auto
Use < Or > To Change

After the screen for relay 23 is displayed, the first *Analog Output Override Screen* will be displayed.

Analog Output 1 Screen

Main Fan VFD
Override Volts: -1.0

[-1.0 = Auto]

The default setting for normal operation is -1.0 volts. Voltages between 0 to 10.0 are valid entries. *Press* **<ENTER>** after making a setting change and then *press* **<↓>** and the next *Analog Output Override Screen* will be displayed.

Analog Output 2 Screen

Economizer
Override Volts: -1.0

[-1.0=Auto]

The default setting for normal operation is -1.0 volts. Voltages between 0 to 10.0 are valid entries. *Press* **<ENTER>** after making a setting change and then *press* **<↓>** and the next *Analog Output Override Screen* will be displayed.

Analog Output 3 Screen

Modulating Heat
Override %...: -10%

[-10 = Auto]

The default setting for normal operation is -10 %. Percentages between 0 to 100 are valid entries. *Press* **<ENTER>** after making a setting change and then *press* **<↓>** and the next *Analog Output Override Screen* will be displayed.

Analog Output 4 Screen

```
Exhaust Fan Signal
Override Volts: -1.0

[-1.0 = Auto]
```

The default setting for normal operation is -1.0 volts. Voltages between 0 to 10.0 are valid entries. Press **<ENTER>** after making a setting change and then press **<↓>** and the next *Analog Output Override Screen* will be displayed.

Analog Output 6 Screen

```
Mod Condenser
Override Volts: -1.0

[-1.0 = Auto]
```

The default setting for normal operation is -1.0 volts. Voltages between 0 to 10.0 are valid entries. Press **<ENTER>** after making a setting change.

Analog Output 5 Screen

```
Modulating Cool
Override %...: -10%

[-10 = Auto]
```

The default setting for normal operation is -10%. Percentages between 0 to 100 are valid entries. Press **<ENTER>** after making a setting change and then press **<↓>** and the next *Analog Output Override Screen* will be displayed.

APPENDIX A - SAVE, LOAD, COPY SETPOINTS

Saving & Copying Setpoints

Modular Service Tool Instructions

From any menu screen, press **<BALANCE-TEST>**. The *Unit Selection Screen* will appear requesting that you enter the unit ID number.

```
Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication
```

Enter the network unit ID for the controller you want to save the setpoints from. Example, '102' for Loop 1 / Unit 2. Then press **<ENTER>**. Once communication is established, "No Communication" will be replaced with "Press Down." After a brief pause, press **<↓>** to get to the *Balance - Test Screen* shown below.

```
Outputs Force
Para Blocks
Save/Copy/Restore
```

Scroll down to the 'Save/Copy/Restore' option and press **<ENTER>**. This will take you to the Save Setpoints screen.

System Manager SD Instructions

From any Main screen, press **<SETPOINTS>**. The screen below will appear because this option requires passcode clearance. Only a Level 2 passcode can change setpoints.

```
THIS ACTION REQUIRES
PASSCODE CLEARANCE
Enter Passcode: XXXX
```

If the correct passcode was entered, the *Unit Selection Screen* will be displayed.

```
Enter Unit Address
Then Press Enter
Selected Unit#: XXXX
No Communication
```

Enter the Unit ID of the controller you wish to change schedules for and press **<ENTER>**. Once communication is established, "No Communication" will be replaced with "Press Down." Then press **<↓>**.

NOTE: If "No Communication" remains, it indicates a communication failure to the controller.

The following screen will be displayed:

```
Change Setpoints
Configure Unit
Save/Copy/Restore
```

Scroll down to the 'Save/Copy/Restore' option and press **<ENTER>**. This will take you to the Save Setpoints screen.

Save Setpoints - Network Mode

From the *Save Setpoints Screen* shown below:

```
Save Setpoints
Press Enter To Save
```

Press **<ENTER>** and a setpoint file will be saved to the SD card. You will receive a message that the save was successful. This file is specific to this controller on this loop.

Copying & Restoring Previously Saved Setpoints

Copy Setpoints - Network Mode

To copy a saved setpoints file to other controllers on the network do the following:

From the *Save Setpoints Screen* shown below:

```
Save Setpoints
Press Enter To Save
```

Press **<↓>** once to access the *Copy Setpoints Screen* shown below.

```
Copy Setpoints
From Loop  1
From Unit  2
Press Enter to Copy
```

In the 'From Loop' field, enter the Loop of the controller you want to copy the setpoints from. In this example it is '1'. Then press **<ENTER>**.

In the 'From Unit' field, enter the Unit ID of the controller you want to copy the setpoints from. In this example it is '2'. Then press **<ENTER>**.

Now your cursor will be on the last line, and you can press **<ENTER>** once more to copy the setpoint file from unit 102 to unit 103.

You will receive a confirmation that the copy was successful.

Save & Copy Setpoints - Stand-Alone Mode

The instructions for Stand-Alone Mode are exactly the same as Network Mode, except that there is no need to enter a Loop number in the Unit ID number field and in the *Copy Setpoints Screen*, enter a zero in the 'From Loop' field.

Restore Setpoints - Network or Stand-Alone Mode

The Restore Setpoints feature is used to reload a saved setpoints file from one controller back to itself. This could be useful if setpoints or configurations were changed and need to be reset.

You can perform this function on a networked system; however, the Modular Service Tool needs to be directly connected to the controller you wish to restore previously saved setpoints to.

From the *Save Setpoints Screen* shown below:

```
Save Setpoints
Press Enter To Save
```

Press **<↓>** four times to access the *Restore Setpoints Screen* shown below.

```
Restore Setpoints
Press Enter to Load
```

Press **<ENTER>**. This will reload the setpoints from the saved file. You will receive confirmation that the setpoints were loaded successfully.

APPENDIX B - UPDATING THE SD CARD


SD Memory Card Update

Updating Your SD Memory Card

You may need to update your SD memory card from time to time, either for a new release or to add data for another Controller.


Follow the instructions below to download the update file from our tech support webpage:

1. Insert the SD memory card in your computer's SD drive and open the drive's window.
2. Open your browser and type in the address: <http://wattmaster.com/techsupport>.
3. On the Tech Support webpage, locate the file `Modular_HH_Screens.zip` and *double-click* on it.
4. Click **<Save File>** when asked to save or open the file and then *click* **<OK>**. This option will save the file to the "Downloads" folder on your PC.



5. *Open* the "Downloads" folder in Windows Explorer. You will find a folder labeled, "Modular_HH_Screens.zip." *Right-click* on this folder and choose "Extract All" from the options list. **NOTE:** Any compression software can be used to extract the zip folder's contents, for example, Winzip.

6. Once you unzip the file, you will see a window similar to the one below.



7. Press **<CTRL> <A>** to highlight the folders in the window—App, Manuals & Scr. Press **<CTRL> <C>** to copy the folders.
8. Paste the files into the SD memory card drive's window by *pressing* **<CTRL> <V>**.
9. Remove the SD Memory Card from your computer and reinsert it in the Modular Hand Held Service Tool or Modular System Manager.

Updating Controller & E-BUS Module Software Using the Modular Service Tool SD

To update the software for various WattMaster controllers and E-BUS modules, follow these simple steps.

1. Update your SD memory card with the new software file for the controller or module you need to update. Follow the steps on **page 82** for Updating the SD memory card.
2. Connect the Modular Service Tool to the device you wish to update using the mini DIN communication cable or EBC E-BUS cable provided.
3. Power up the controller or E-BUS module you wish to update.
4. Apply power to the Modular Service Tool SD and press the **<ON>** button.
5. After initialization of the Modular Service Tool SD, press **<NEXT>** at the first Setup Screen and **<4>** at the second Setup Screen shown below.

```
1) Set Time & Date
2) Communications
NEXT) More Options
ESC) Exit Menu
```

```
3) Energy Saving
4) Update Software
NEXT) More Options
ESC) Exit Menu
```

6. The *Update Software Screen* will appear as shown below:

```
Select Communication
1) WattMaster Comm
2) E-BUS Module
ESC) Exit Menu
```

7. Follow the instructions for WattMaster Controllers or E-BUS Modules.

WattMaster Controllers

1. Press **<1>** to update a WattMaster Controller. The following screen will appear:

```
Enter Board Address
0
Esc) Exit Menu
```

2. Enter the address of the controller you are updating and then press **<ENTER>**.
3. The *Software Version Screen* will appear as shown below. Enter **<0>** for the latest software version or enter the number of an older version given to you by Technical Support. Then press **<ENTER>**.

```
Software Version
Enter 0 for Latest
0
Esc) Exit Menu
```

4. The screen will display the following messages:
"Resetting Unit"
"Load Sys Info"
5. If communications are successful, the screen will display, the name of the HEX file on the top line, "Flash Memory Erased" on the second line, and the progress percentage on the third line.

NOTE: If communications are not successful, the screen will display, "Press Any Key to Continue. Cannot Load Sys Info." Make sure you have the right address and the right software version on your SD card. If these two items are correct and you still experience a problem, contact Technical Support.

6. When updating is complete, the screen will display, "Finish Download."

Updating Controller & E-BUS Module Software

E-BUS Modules

1. Press **<2>** to update an E-BUS Module.
The following screen will appear:

```
Enter Board Address
      0
Esc) Exit Menu
```

2. Enter the address of the E-BUS module you are updating and then press **<ENTER>**. The following is the list of Module addresses:

WSHP-X - address 17
MHGRV-X - address 132
MODGAS-X - address 138

3. The *Software Version Screen* will appear as shown below. Enter **<0>** for the latest software version or enter the number of an older version if given to you by Technical Support. Then press **<ENTER>**.

```
Software Version
Enter 0 for Latest
      0
Esc) Exit Menu
```

4. The screen will display the following messages:
“Resetting Unit”
“Load Sys Info”

5. If communications are successful, the screen will display, the name of the HEX file on the top line, “Flash Memory Erased” on the second line, and the progress percentage on the third line.

NOTE: If communications are not successful, the screen will display, “Press Any Key to Continue. Cannot Load Sys Info.” Make sure you have the right address and the right software version on your SD card. If these two items are correct and you still experience a problem, contact Technical Support.

6. When updating is complete, the screen will display, “Finish Download.”

12 Relay Expansion Module Installed.....26
 12 Relay - Relay Status.....65
 24-Hour Military Format.....14,22
 1111.....19
 2222.....19
 2359.....14,22

A

Adaptive Defrost Interval
 Adjustment.....53
 AHU Heat Call Space Temperature
 VAV/Zone.....70
 AHU Uses Schedule Number.....35
 Air/Air Fail to Cool.....32
 Air/Air Fail to Heat.....32
 Airflow, VAV/Zone Status.....74
 Alarm Active Relay Configuration.....38
 Alarm Active Relay Description.....39
 Alarm Conditions.....65
 Alarm Offset.....43
 Alarms
 Button.....10,16
 Clearing.....13,21
 MiniLink Polling.....20,77
 Modular Service Tool.....13
 VAV/Zone Status.....74
 Alarms for VCB-X.....64,65
 Alarm Status.....65
 Analog Output Override Screen.....78
 Application Type.....57
 Arrow Keys, Defined.....10,12,16,18
 Auto Damper Force Mode.....75
 Automatic Power Down.....12
 Aux Heat - Heat Pump Delays.....37
 Aux Heat Relay Configuration.....38,39
 Aux Heat Relay Description.....39
 Aux Heat Type Value.....32

B

Balance-Test Button Defined.....10
 Box Air Temperature
 VAV/Zone Status.....73
 Box Configuration, VAV/Zone.....66
 Boxes Broadcast To.....36
 Box Heat Allow, VAV/Zone.....67
 Broadcast Building Pressure.....36
 Broadcasting.....35
 Broadcast Outdoor Air RH Screen.....36
 Broadcast to Boxes.....36
 Building Pressure.....25,26
 Deadband Setpoint.....51
 Output %.....62
 Setpoint.....51
 VCB-X Status.....62
 Building Pressure Broadcast.....36
 Building Pressure Control
 OA Damper.....31
 Supply Fan.....31

Building Pressure Control Rate Screen.....31
 Building Pressure Control Screen.....31
 Building Pressure Exhaust Fan Status.....62
 Building Pressure Output Signal Percentage
 Status.....62
 Building Pressure Setpoint Status.....62
 Building Pressure Status.....62
 Buttons, Status.....57
 Bypass Damper.....27
 Bypass Damper Signal.....63

C

Calibration, Space Sensor Calibration.....53
 Change Passcodes.....19
 Clear Alarms.....13,21
 Clear Key, Defined.....10,16
 Closed, Damper Force Mode.....75
 CO₂ Altitude Setpoint.....51
 CO₂ Level.....61
 CO₂ Level Status.....61
 CO₂ Protection Limit Max Level.....50
 CO₂ Sensor Calibration -
 Current and Offset.....54
 CO₂ Sensor Configuration Screen.....31
 CO₂ Sensor Installed.....31
 CO₂ Setpoints Min/Max.....50
 CO₂ Setpoints Status.....61
 Coil Sensor Calibration.....54
 Coil Temperature.....59
 Coil Temperature Sensor.....54
 Coil Temperature Setpoint.....44,59
 Coil Temperature Setpoint Status.....59
 Coil Temperature Status.....59
 Coil Temperature Switch.....33
 Communications Screen.....12,18
 Compressor Discharge Temperature.....58
 Condenser Control.....25
 Condenser Fan Speed.....62
 Condenser Relay, Description.....39
 Condenser Relay Configuration.....38,39
 Condenser Signal Status.....62
 Configuration.....66
 12 Relay Expansion Module.....26
 Button.....10
 EM1 Expansion Module.....25
 EM2 Expansion Module.....26
 Fan Voltage Output.....28
 MHGRV-X.....26
 MODGAS-X.....26
 Screen Index.....24
 Connection Diagram
 Modular Service Tool.....5
 Continuous OFF Mode.....14,22
 Continuous ON Mode.....14,22
 Controller Temperature, Cooling & Heating
 Setpoints.....57
 Controlling Sensor High Alarm Offset.....43
 Controlling Sensor Low Alarm Offset.....43
 Controlling Temperature Status.....57

Control Outdoor Air CFM.....34
 Cool/Heat Stage Delays.....37
 Cooling Active Stages Status.....58
 Cooling Enabled Status.....58
 Cooling Min Off Time.....37
 Cooling Min Run Time.....37
 Cooling Only Box, VAV/Zone.....66
 Cooling Setpoints, VAV/Zone Status.....73
 Cooling Setpoints Status.....57
 Cooling Stage Relay, Description.....39
 Cooling Unoccupied Offsets.....42
 Cool Reset Source Setpoints - High Space/
 SAT.....46
 Cool Reset Source Setpoints - Low Space/
 High Reset.....46
 Cool Stage Relay.....38,39,64,65
 Cool Total, MiniLink PD Status.....77
 Cool Type Screen.....29
 Copy Setpoints.....81
 Current Active Supply Air Setpoint.....58
 Current CO₂ Level.....61
 Current Economizer Open
 Percentage.....60,61
 Current Outdoor Air Temperature.....60
 Current Supply Air Temperature.....58
 Current Wetbulb Temperature.....60

D

Damper Airflow
 Cool/Heat Minimum.....70
 Fan On Min.....71
 Fixed Position.....71
 Integral.....70
 Maximum.....70
 Night Minimum.....71
 Reheat Minimum.....71
 Vent Minimum.....70
 Damper Force Modes.....75
 Damper Operation, VAV/Zone.....66
 Dampers Forced Closed.....75
 Data Entry Keys, Described.....10,16
 Date, Programming.....11,17
 Date and Time.....57
 Daylight Savings Adjustment.....35
 Day/Night Schedule, VAV/Zone.....72
 DEC Key, Defined.....10,16
 Defrost Coil Switch Screen.....33
 Defrost Heat Wheel Setpoint.....53
 Dehumidification Control Screen
 Control Screen.....32
 Desired CFM, VAV/Zone Status.....74
 Dewpoint.....30
 Dewpoint Setpoint.....43
 Digital Compressor for Modulating
 Cooling.....29
 Digital Compressor Relay
 Description.....39
 Digital Compressor Relay
 Configuration.....38,39

D-L

Digital Scroll Compressor(s).....29
Dimensions
 Modular Service Tool.....4
 System Manager.....6
Direct Acting Building Pressure
 Control.....31
Direct Acting Control.....51
Dirty Filter Screen.....36
Display Screen, Described.....10,16
Drybulb.....30
Duct Static Pressure Output Signal
 Percentage Status.....62
Duct Static Pressure Setpoint Status.....62
Duct Static Pressure Status.....62
Dump Zone, VAV/Zone.....68

E

E-BUS Outdoor Air/RH Sensor Screen.....30
E-BUS Space and Humidity Sensor
 Installed Screen.....33
Economizer Maximum Position if
 High CO₂ Level Setpoint.....50
Economizer %.....60,61
Economizer Active Relay
 Description.....39
Economizer Active Relay
 Configuration.....38,39
Economizer Control Loop Rate.....30
Economizer Control Type.....30
Economizer Enabled.....60,61
Economizer Enabled Status.....60
Economizer Enable Setpoint.....49
Economizer Enable Source Screen.....30
Economizer in IAQ Mode Status.....61
Economizer in Unoccupied Mode.....30
Economizer Minimum Damper
 Position.....49
Economizer Minimum Percentage
 Status.....61
Economizer Open Percentage Status.....60
Economizer Override.....78
Economizer Voltage Output.....31
EM1 Installed.....25
EM1 Relay Status.....64
EM2 Installed.....26
Emergency Heat Relay
 Configuration.....38,39
Emergency Heat Relay Description.....39
Emergency Shutdown.....36
Energy Saving Timer.....12
Enter Key.....10,16
 New Passcode.....19
ESC Key Defined.....10,16
Exhaust Air CFM Status.....61
Exhaust Airflow Duct Size.....35
Exhaust Airflow Monitoring.....35
Exhaust Fan Output Screen.....31
Exhaust Fan Relay Configuration.....38,39
Exhaust Fan Relay Description.....39

Exhaust Fan Status.....62
Exhaust Fan VFD.....51
Exhaust VFD Override.....79
Expansion Relays Heating Stages
 VAV/Zone.....67

F

Fan Cycle Mode Screen.....28
Fan On Min.....71
Fan Proving Screen.....28
Fan Starting Delay Screen.....28
Fan Status.....74
Fan VFD Signal Configuration.....27
Fan Voltage Output Screen.....28
Fixed Damper Force Mode.....75
Fixed Position Damper Airflow.....71
Fixed Stage(s) of Heat.....28

H

H/C Changeover Box, VAV/Zone.....66
Head Pressure Control.....25
Head Pressure Control Screen.....33
Head Pressure Setpoints -
 Cooling and Reheat.....49
Head Pressure Setpoint Status.....62
Head Pressure Status.....62
Heat/Cool Changeover Delay.....37
Heating
 Min Off Time.....37
 Min Run Time.....37
 Setpoints.....73
 Stage Down.....37
 Stage Up.....37
Heating Active Stages Status.....59
Heating/Cooling Demand
 VAV/Zone Status.....73
Heating Enabled.....58
Heating Enabled Status.....58
Heating Outputs.....59
Heating Setpoints Status.....57
Heating Stage Relay Description.....39
Heating Unoccupied Offsets.....42
Heat Pump Aux Enabled Status.....58
Heat Pump Compressor Relay
 Description.....39
Heat Pump Compressor Relay
 Configuration.....38,39
Heat Pump Configuration Screen.....32
Heat Pump Defrost Interval.....52
Heat Pump Delays - Aux Heat.....37
Heat Pump Emergency Heat Status.....58
Heat Pump Heat Enabled Status.....58
Heat Reset Source Setpoints -
 High Space/SAT.....47
Heat Reset Source Setpoints - Low Space/
 High Reset.....48
Heat Stage Relay Configuration.....38,39

Heat Total, MiniLink PD Status.....77
Heat Type Screen.....28
Heat Wheel Defrost Temperature
 Setpoint.....53
Heat Wheel Relay Configuration.....38,39
Heat Wheel Relay Description.....39
Hi SAT Cutoff.....52
Holidays
 Programming.....14
 Start/Stop Times.....15,23
Hood On HVAC Setpoints.....41
Hood On/Off.....25,26
Humidity Control Sensor Type.....32
HVAC Cool/Heat Setpoints.....41
HVAC Hood On Setpoints.....41
HVAC Mode.....57
 Cooling Setpoints.....41,42
 Heating Setpoints.....41,42
 Unoccupied Offsets.....42
HVAC Mode Deadband.....42
HVAC Mode Set By Remote Contact.....26
HVAC Source Screen.....26

I

IAQ Economizer.....30
IAQ Mode Status.....61
Indoor RH Setpoint.....59
Indoor Relative Humidity Percentage
 Status.....59
Indoor Relative Humidity Setpoint
 Percentage Status.....59
Indoor RH Setpoint.....44
Initialization
 Screen.....11,17

K

Keys Described.....10,16

L

Last Polled Zone, MiniLink PD.....76
Leaving Water Temperature.....63
Leaving Water Temperature Sensor
 Calibration - Current and Offset.....55
Level 1 User Defined.....19
Level 2 User Defined.....19
Loop Search Screen.....20
Low Ambient Relay Configuration.....38,39,
 64,65
Low Ambient Relay Description.....39
Low Ambient Setpoint.....52

M

Main Fan Status, VAV/Zone.....67
 Maverick Testing, MiniLink PD.....77
 Maximum
 Damper Force Mode.....75
 EMS Offset VAV/Zone.....72
 Slide Offset VAV/Zone.....72
 Maximum Economizer Position in Heat
 Mode.....50
 Maximum Outdoor Air CFM.....50
 Mechanical Heat/Cool Alarm Delay.....29
 MHGRV-X and MODGAS-X
 Installed.....26
 MHGRV-X Enabled Status.....60
 MHGRV-X Reheat Valve Output Signal
 Percentage Status.....60
 Min Damper Force Mode.....75
 MiniLink PD Configuration.....76
 Alarm Polling.....77
 Last Polled Zone.....76
 Maverick Testing.....77
 Mode Changeover Time.....76
 Optimal Start Target Zone.....77
 System Type.....76
 MiniLink PD Status
 Adding Additional.....20
 Cool Total.....77
 Heat Total.....77
 Minutes Left.....77
 Mode Priority.....77
 Schedule Mode.....77
 System Status.....77
 Minimum Outdoor Air CFM.....50
 Minimum Outdoor Airflow.....50
 Minimum Run Times and Off Times.....37
 Minus Key, Defined.....10,16
 Minutes Left, MiniLink PD Status.....77
 Mod Cooling Override.....79
 Mod Heating Override.....78
 Mod Cool Enable Relay, Description.....39
 Mod Cool Proportional Window and Time
 Period.....49
 Mod Cool Proportional Window and Time
 Period Controlling Sensor High
 Alarm Offset.....43
 Mode
 Changeover Time.....76
 of Operation.....12,18,73
 Priority.....77
 Selection Buttons Defined.....10,16
 VCB-X Status Screen.....57
 MODGAS Output %
 VCB-X Status.....59,60
 MODGAS-X Enabled Status.....59
 MODGAS-X Heating Output Signal
 Status.....59
 Mod Heat.....28
 Mod Heat Enable Relay
 Configuration.....38,39

Mod Heat Enable Relay Description.....39
 Mod Heat Output Position in
 Off Mode.....52
 Mod Heat Proportional Window and Time
 Period.....48
 Mod Heat Then Staged.....29
 Mod Then Staged.....32
 Modular Service Tool
 Alarms Button.....13
 Alarm Search.....13
 Connection Diagram.....5
 Defined.....4
 Dimensions.....4
 Energy Saving Timer.....12
 Initialization Screen.....11,17
 Instructions.....41,56
 Mode Selection Buttons.....10,16
 Override Search.....13
 Overrides Tool.....13
 VCB-X Setpoints.....41
 VCB-X Status.....56
 Modular System Manager
 Connection Diagram.....7
 Defined.....6
 Dimensions.....6
 Network Connection.....7
 Stand-Alone Connection.....9
 Modulating Chilled Water.....25,29
 Modulating Cooling %.....58
 Modulating Cooling Output Signal
 Screens.....29
 Modulating Cooling Output Signal Status
 Percentage.....58
 Modulating Exhaust Damper.....51
 Modulating Gas.....28
 Modulating Gas Heat.....29
 Modulating Heating Output Signal
 Percentage Status.....59
 Modulating Hot Water.....28
 Modulating Only.....32
 Modulating SCR Electric Heat.....28
 Monitor Exhaust Airflow.....35
 Monitor Outdoor Air Airflow.....33
 Monitor Return Air Airflow.....34
 Monitor Supply Air Airflow.....34
 Month.....11,17
 Morning Warm Up.....35
 Max Length.....53
 Target Temp.....53
 Temp Setpoint.....53
 Morning Warm-Up Relay
 Configuration.....39
 Morning Warm-Up (VAV Boxes) Relay
 Description.....39
 Multiple MGRS.....18

N

Network Connection
 Modular System Manager.....7
 Night Minimum, Damper Airflow.....71
 No Aux Heat.....32
 No Economizer.....30
 No Heat.....28
 No Reversing Valve.....32

O

OA Damper Building Pressure
 Control.....31
 OA Dewpoint, VCB-X Status.....60
 OAT Cool Setpoint.....41
 OA Temp Broadcasting.....36
 OAT Heat Setpoint.....41
 OAT Lockouts - Comp Cool/Comp
 Heat.....51
 OAT Lockouts - Heat.....52
 OAT Sensor Calibration.....54
 Occupied
 Mode.....15,23
 Setpoints.....69
 Occupied Active Relay
 Configuration.....38,39
 Occupied Active Relay Description.....39
 Occupied HVAC Cool/Heat
 Setpoints.....41
 Occupied Vent.....32
 OE391-12.....4
 OE392-12.....6
 OFF Mode, Continuous.....14,22
 ON Mode, Continuous.....14,22
 On/Off Exhaust Fan.....51
 On/Off Hot Water.....28
 Open Damper Force Mode.....75
 Optimal Start Target Zone
 MiniLink PD.....77
 Outdoor Air.....26
 Configuration.....27,29
 Outdoor Air Airflow
 Monitoring.....33
 VCB-X Output.....61
 Outdoor Air CFM.....50,61
 Controlling.....34
 Outdoor Air CFM Status.....61
 Outdoor Air Damper.....51
 Outdoor Air Dewpoint
 Temperature Status.....60
 Outdoor Air Drybulb Status.....60
 Outdoor Airflow.....50
 Outdoor Airflow Duct Size.....34
 Outdoor Air Humidity Broadcast.....36
 Outdoor Air Relative Humidity
 Status.....60
 Outdoor Air Sensor Screen.....30
 Outdoor Air Temperature Sensor.....54
 Outdoor Conditions Drybulb.....60

Outdoor Dewpoint Setpoint.....43
 Outdoor Temperature.....59
 Outdoor Temperature
 Configuration.....27
 Outputs Force.....78
 Screen.....78
 Override Active Relay
 Description.....39
 Override Active Relay
 Configuration.....38,39,64,65
 Overrides
 Button.....10,16
 Screen.....13,21
 Search.....13,21

P

Parallel Fan Box, VAV/Zone.....66
 Passcode
 1111.....19
 2222.....19
 Clearance.....18
 Codes.....19
 Enter New.....19
 System Manager.....19
 Power/Comm Board Wiring.....8
 Power Down.....12
 Preheat Relay
 Configuration.....38,39,64,65
 Pre-Heat Relay Description.....39
 Preheat Relay Setpoint.....52
 Pressure Independent Airflow Constant
 VAV/Zone.....67
 Programming
 Date.....11,17
 Day of Week.....11,17
 Holidays.....14
 Holiday Start/Stop Times.....15,23
 Month.....11,17
 Time & Date.....11,17
 Year.....11,17
 Proof of Flow.....25
 Proportional Heating Signal
 VAV/Zone.....67
 Purge Mode Screen.....28
 Push-Button Override
 Duration.....72
 VAV/Zone.....67

R

Real Time Clock.....11,17
 Reheat Minimum Damper Airflow.....71
 Reheat Relay Description.....39
 Reheat Stage Reheat
 Configuration.....38,39
 Reheat Stages.....74
 Reheat Type Screen.....33

Relay
 Alarm Active.....39
 Configuration Screens.....38,39
 Overrides.....78
 Relay Configurations
 Alarm Active.....38
 Aux Heat.....38,39
 Condenser.....38,39
 Cool Stage.....38,39,64,65
 Digital Compressor.....38,39
 Economizer Active.....38,39
 Emergency Heat.....38,39
 Exhaust Fan.....38,39
 Heat Pump Compressor.....38,39
 Heat Stage.....38,39
 Heat Wheel.....38,39
 Low Ambient.....38,39,64,65
 Mod Heat Enable.....38,39
 Occupied Active.....38,39
 Override Active.....38,39,64,65
 Preheat.....38,39,64,65
 Reheat Stage.....38,39
 Reversing Valve.....38,39
 Warm Up Command.....38,39,64,65
 Relay Definitions.....39
 Relays.....64,65
 Aux Heat.....39
 Condenser.....39
 Cooling Stage.....39
 Digital Compressor.....39
 Economizer Active.....39
 Emergency Heat.....39
 Heating Stage.....39
 Heat Pump Compressor.....39
 Low Ambient.....39
 Mod Heat Enable.....39
 Occupied Active.....39
 Override Active.....39
 Pre-Heat.....39
 Reversing Valve.....39
 Supply Fan.....64
 Relay Status.....64
 Relay Status 12 Relay.....65
 Relay Status EM1.....64
 Remote Forced Cooling.....26
 Remote Forced Dehumidification.....26
 Remote Forced Heating.....26
 Remote Forced Occupied.....25
 Remote SAT Reset.....26
 Remote Signal Contact.....14,22
 Remote Voltage Configuration.....27
 Reset Rate Interval Screen.....27
 Reset Voltage Signal Status.....63
 Restore Setpoints.....81
 Return Air.....26
 Configuration.....27
 Return Air Airflow Monitoring.....34
 Return Air Bypass Control.....26,37
 Return Air Bypass Damper Factor
 Setpoint.....55

Return Air CFM Status.....61
 Return Air Damper Signal.....63
 Return Airflow Duct Size.....34
 Return Air Temperature.....25,57
 Return Air Temperature Sensor.....53
 Calibration.....53
 Return Air Temperature Status.....57
 Return Temperature & Slide Adjust.....57
 Reverse Acting Building Pressure
 Control.....31
 Reverse Acting Control.....51
 Reversing Valve.....32
 Reversing Valve Relay
 Configuration.....38,39
 Reversing Valve Relay Description.....39
 RH Setpoint - Indoor.....44

S

SAT Reset Source Screen.....27
 SAT Sensor Calibration - Current and
 Offset.....54
 Schedule
 Button.....10,16
 Mode.....77
 Override.....14,15,22,23
 Time & Date.....11,17
 Schedule Mode.....57
 Schedule Number.....35
 Scheduling, VCB-X Controller.....14,22
 Screens
 Adaptive Defrost Interval
 Adjustment.....53
 AHU Uses Schedule Number.....35
 Alarm Status.....65
 Analog Output Override Screen.....78
 Application Type, Schedule Mode &
 HVAC Mode.....57
 Aux Heat Type Value.....32
 Broadcast Building Pressure.....36
 Broadcast Outdoor Air RH.....36
 Broadcast to Boxes.....36
 Building Pressure Broadcast.....36
 Building Pressure Control.....31
 Building Pressure Control Rate.....31
 Building Pressure Deadband
 Setpoint.....51
 Building Pressure Exhaust Fan
 Status.....62
 Building Pressure Output Signal
 Percentage Status.....62
 Building Pressure Setpoint.....51
 Building Pressure Setpoint
 Status.....62
 Building Pressure Status.....62
 CO₂ Altitude Setpoint.....51
 CO₂ Level Status.....61
 CO₂ Sensor Calibration - Current and
 Offset.....54

- CO₂ Sensor Installed.....31
- CO₂ Setpoints Min/Max.....50
- CO₂ Setpoints Status.....61
- Coil Sensor Calibration.....54
- Coil Temperature Setpoint.....44
- Coil Temperature Setpoint Status.....59
- Coil Temperature Status.....59
- Communications Screen.....12,18
- Compressor Discharge Temperature Status.....58
- Condenser Signal Status.....62
- Configuration Screens.....24
- Controller Temperature, Cooling & Heating Setpoints.....57
- Controlling Sensor High Alarm Offset.....43
- Controlling Sensor Low Alarm Offset.....43
- Controlling Temperature, Cooling & Heating Setpoints.....57
- Control Outdoor Air CFM.....34
- Cool/Heat Stage Delays.....37
- Cooling Active Stages Status.....58
- Cooling Enabled Status.....58
- Cool Reset Source Setpoints - High Space/SAT.....46
- Cool Reset Source Setpoints - High Space/SAT/VFD.....46
- Cool Reset Source Setpoints - Low Space/High Reset.....46
- Cool Type.....29
- Cool Type Screen.....29
- Current Active Supply Air Setpoint Status.....58
- Current Supply Air Temperature Status.....58
- Date and Time.....57
- Daylight Savings Adjustment.....35
- Defrost Coil Switch.....33
- Dehumidification Control Screens.....32
- Digital Compressor for Modulating Cooling Screen.....29
- Dirty Filter Screen.....36
- Duct Static Pressure Output Signal Percentage Screens.....62
- Duct Static Pressure Setpoint Status.....62
- E-BUS Outdoor Air/RH Sensor.....30
- E-BUS Space and Humidity Sensor Installed.....33
- Economizer Control Loop Rate.....30
- Economizer Control Type.....30
- Economizer Enabled Status.....60
- Economizer Enable Setpoint.....49
- Economizer Enable Source.....30
- Economizer in IAQ Mode Status.....61
- Economizer in Unoccupied Mode.....30
- Economizer Maximum Position if High CO₂ Level.....50
- Economizer Minimum Damper Position.....49
- Economizer Minimum Percentage Status.....61
- Economizer Open Percentage Status.....60
- Economizer Overrides.....78
- Economizer Voltage Output.....31
- Emergency Shutdown.....36
- Exhaust Air CFM Status.....61
- Exhaust Airflow Duct Size.....35
- Exhaust Airflow Monitoring.....35
- Exhaust Fan Output.....31
- Exhaust VFD Override.....79
- Fan Cycle Mode Screen.....28
- Fan Proving Screen.....28
- Fan Starting Delay Screen.....28
- Fan Voltage Outputs.....28
- Head Pressure Control.....33
- Head Pressure Setpoints - Cooling and Reheat.....49
- Head Pressure Setpoint Status.....62
- Head Pressure Status.....62
- Heat/Cool Changeover Delay.....37
- Heating Active Stages Status.....59
- Heating Enabled Status.....58
- Heat Pump Configuration.....32
- Heat Pump Defrost Interval.....52
- Heat Pump Delays.....37
- Heat Pump Emergency Heat Status.....58
- Heat Pump Heat Enabled Status.....58
- Heat Reset Source Setpoints - High Space/SAT.....47
- Heat Reset Source Setpoints - Low Space/High Reset.....48
- Heat Type.....28
- Heat Wheel Defrost Temperature Setpoint.....53
- High Alarm Offset.....43
- Holiday Schedule.....15,23
- Hood On HVAC Setpoints.....41
- Hood On HVAC Setpoints - OAT Cool, OAT Heat.....41
- Humidity Control Sensor Type.....32
- HVAC Mode Set By Remote Contact.....26
- HVAC Source Screen.....26
- IAQ Mode Status.....61
- Indoor Relative Humidity Percentage Status.....59
- Indoor Relative Humidity Setpoint Percentage Status.....59
- Indoor RH Setpoint.....44
- Initialization for Modular Service Tool.....11,17
- Leaving Water Temperature Sensor Calibration.....55
- Loop Search Screen.....20
- Low Alarm Offset.....43
- Low Ambient Setpoint.....52
- Maximum Economizer Position in Heat Mode.....50
- Mechanical Heat/Cool Alarm Delay Screen.....29
- MiniLink PD Configuration.....76
- Mod Cooling Override.....79
- Mod Cool Proportional Window and Time Period.....49
- Mode Deadband.....42
- MODGAS-X Enabled Status.....59
- MODGAS-X Heating Output Signal Status.....59
- Mod Heating Override.....78
- Mod Heat Output Position in Off Mode.....52
- Mod Heat Proportional Window and Time Period.....48
- Modulating Cooling Output Signal.....29
- Modulating Cooling Output Signal Percentage Status.....58
- Monitor Outdoor Air Airflow.....33
- Monitor Return Air Airflow.....34
- Monitor Supply Air Airflow.....34
- Morning Warm Up.....35
- Morning Warm Up Temp Setpoint.....53
- OA Temp Broadcast.....36
- OAT Lockouts - Comp Cool/Comp Heat.....51
- OAT Lockouts - Heat.....52
- OAT Sensor Calibration.....54
- Occupied HVAC Cool/Heat Setpoints.....41
- Outdoor Air Airflow Monitoring.....33
- Outdoor Air CFM Control.....34
- Outdoor Air CFM Setpoint.....50
- Outdoor Air CFM Status.....61
- Outdoor Air Dewpoint Temperature Status.....60
- Outdoor Air Drybulb Status.....60
- Outdoor Airflow Duct Size.....34
- Outdoor Air Relative Humidity Status.....60
- Outdoor Air Sensor.....30
- Outdoor Dewpoint Setpoint.....43
- Outputs Force Screen.....78
- Overrides Screen.....13,21
- Preheat Relay Setpoint.....52
- Purge Mode.....28
- Reheat Type.....33
- Relay Configuration Screens.....38,39
- Relay Overrides.....78
- Reset Rate Interval Screen.....27
- Reset Voltage Signal Status.....63
- Return Air Airflow Monitoring.....34
- Return Air Bypass Control.....37

SCREENS, CONTINUED

Return Air Bypass Damper Factor
Setpoint.....55

Return Air CFM Status.....61

Return Airflow Duct Size.....34

Return Air Temperature Sensor
Calibration.....53

Return Air Temperature Status.....57

SAT Reset Source Screen.....27

SAT Sensor Calibration - Current and
Offset.....54

Schedule Number.....35

Schedule Override.....15,23

Sensor Scaling Screen.....25

Set Time & Date Screens.....11,17

Slide Adjust Status.....57

Space Sensor Calibration - Current and
Offset.....53

Space Sensor Overrides Screen.....21

Space Sensor Push-Button Override
Duration.....43

Space Sensor Slide Adjust.....42

Space Sensor Slide Adjust
Setpoint.....42

Space Temperature & Slide Adjust
Status.....57

Space Temperature Status.....57

Stage Off Window - Cooling/
Heating.....48

Static Pressure Control.....27

Static Pressure Control Rate.....27

Static Pressure Setpoint.....44

Suction Pressure Sensor
Installed.....33

Suction Pressure Status.....59

Supply Air Airflow Monitoring.....34

Supply Air CFM Status.....61

Supply Air Cooling Setpoint and High
Reset Limit.....45

Supply Air Cutoffs - Cooling/
Heating.....52

Supply Airflow Duct Size.....34

Supply Air Heating Setpoint and High
Reset Limit.....47

Supply Air Temperature & Active
Setpoint.....58

Supply VFD Override.....78

SZ VAV Integral Constant.....55

Trend Log Rate.....36

Unit Selection Screens.....25,41,56,
66,69,76,78,80

Unoccupied Offsets - Cooling &
Heating.....42

Unoccupied Offsets - Heat/
Cool.....42

VAV/Zone Box Configuration.....66

VAV/Zone Configuration.....66

VAV/Zone Controller Setpoints.....69

VAV/Zone Damper Operation.....66

VAV/Zone Status.....73

VCB-X Configuration Screens.....25

VCB-X Controller Status
Screens.....57

VFD Speed Limits Min/Cool/
Vent.....45

VFD Speed Limits Min/Max
Heat.....45

VFD Speed Minimums Cool/Vent
Modes.....45

Water Side Condenser.....33

Week Schedules.....14,22

Wetbulb Temperature Status.....60

WSHP Glycol Percentage.....32

Search
For Loops.....20
For Overrides.....21

Selection Buttons
Defined.....10,16

Sensor Calibration
Space Temperature.....72
Supply Air Temperature.....72

Sensor Scaling Screen.....25

Series Fan Box, VAV/Zone.....66

Setting
Date.....11,17
Day of Week.....11,17
Month.....11,17
Year.....11,17

Single Zone VAV.....26

Slide Adjust Status.....57

Slide Offset, VAV/Zone Status.....73

Space and Humidity Sensor Installed.....33

Space Sensor Calibration - Current
and Offset.....53

Space Sensor Overrides Screen.....21

Space Sensor Slide Adjust.....42

Space Temperature.....26,57
Configuration.....26,27,29

Space Temperature & Slide Adjust.....57

Space Temperature Status.....57

Staged Only.....28,32

Stage Off Window - Cooling/Heating.....48

Staging Up and Down Delay Periods.....37

Stand-Alone, Connection.....9

Standard Economizer.....30

Start and Stop Times
2359.....14,22
ZERO.....14,22

Static Pressure
Output % VCB-X Status.....62

Static Pressure Control Rate Screen.....27

Static Pressure Control Screen.....27

Static Pressure Setpoint.....44

Steam Heat.....28

Suction Pressure Sensor Installed
Screen.....33

Suction Pressure Status.....59

Supply Air.....26
Temperature.....73

Supply Air Airflow Monitoring.....34

Supply Air CFM.....61

Supply Air CFM Status.....61

Supply Air Cooling Setpoint and High Reset
Limit.....45

Supply Air Cutoffs - Cooling/Heating.....52

Supply Airflow Duct Size.....34

Supply Air Heating Setpoint and High
Reset Limit.....47

Supply Air Temperature Sensor.....54

Supply Air Temperature & Setpoint.....58

Supply Fan
Building Pressure Control.....31

Supply Fan VFD.....27,51

Supply VFD Override.....78

System
Status.....77
Type.....76

System Manager
Dimensions.....6
Override Search.....21
Passcodes.....19

System Manager TS.....10,16

SZ VAV Integral Constant.....55

T

Testing the System
Outputs Force.....78

Time.....57
24-Hour Military Format.....14,22

Time & Date.....11,17

Touch Screen System Manager.....10,16

Trend Log Rate.....36

Troubleshooting the System
Outputs Force.....78

U

Unit Selection Screen.....25,41,56,
66,69,76,78,80

Unoccupied
Mode.....15,23
Setbacks.....69

V

VAV Capabilities.....	25,26
VAV/Zone	
AHU Heat Call Space	
Temperature.....	70
Box Heat Allow.....	67
Configuration.....	66
Controllers.....	66,75
Cooling Only Box.....	66
Damper Airflow	
Cool/Heat Minimum.....	70
Integral.....	70
Maximum.....	70
Vent Minimum.....	70
Damper Airflow Fixed Position.....	71
Damper Airflow Night	
Minimum.....	71
Damper Airflow Reheat	
Minimum.....	71
Day/Night Schedule.....	72
Dump Zone.....	68
Expansion Relays Heating	
Stages.....	67
H/C Changeover Box.....	66
Main Fan Status.....	67
Maximum EMS Offset.....	72
Maximum Slide Offset.....	72
Occupied Setpoints.....	69
Parallel Fan Box.....	66
Pressure Independent Airflow	
Constant.....	67
Proportional Heating Signal.....	67
Push-Button Override.....	67
Push-Button Override Duration.....	72
Sensor Calibration for Space	
Temperature.....	72
Sensor Calibration for Supply Air	
Temperature.....	72
Series Fan Box.....	66
Unoccupied Setbacks.....	69
Voting Zone.....	67
Zone Alarm Delay.....	72
Zone Alarm Offsets.....	71
VAV/Zone Configuration	
Damper Operation.....	66
VAV/Zone Setpoints	
AHU Heat Call Space	
Temperature.....	70
Damper Airflow	
Cool Minimum.....	70
Heat Minimum.....	70
Integral.....	70
Maximum.....	70
Vent Minimum.....	70
Damper Airflow Fixed Position.....	71
Damper Airflow Night	
Minimum.....	71

Damper Airflow Reheat	
Minimum.....	71
Day/Night Schedule.....	72
Fan On Min.....	71
Maximum EMS Offset.....	72
Maximum Slide Offset.....	72
Occupied Setpoints.....	69
Push-Button Override Duration.....	72
Sensor Calibration for Space	
Temperature.....	72
Sensor Calibration for Supply Air	
Temperature.....	72
Unoccupied Setbacks.....	69
Zone Alarm Delay.....	72
Zone Alarm Offsets.....	71
VAV/Zone Status	
Airflow.....	74
Alarm Status.....	74
Box Air Temperature.....	73
Cooling Setpoints.....	73
Desired CFM.....	74
Fan Status.....	74
Heating/Cooling Demand.....	73
Heating Setpoints.....	73
Mode of Operation.....	73
Reheat Stages.....	74
Screens.....	73
Slide Offset.....	73
Supply Air Temperature.....	73
Zone Damper Position.....	74
Zone Temperature.....	73
VCB-X Controller.....	57
Alarm Conditions.....	64,65
Building Pressure Output %.....	62
CO ₂ Level.....	61
Coil Temperature.....	59
Compressor Discharge	
Temperature.....	58
Configuration Screens.....	25
Controller Temperature Status.....	57
Cooling Enabled Status.....	58
Cooling Outputs.....	58
Current Outdoor Air	
Temperature.....	60
Economizer Enabled.....	60,61
Heating Enabled.....	58
Heating Outputs.....	59
Indoor RH Setpoint.....	59
Leaving Water Temperature.....	63
Mode.....	57
MODGAS Output %.....	59,60
OA Dewpoint.....	60
Static Pressure Output %.....	62
Status Screens.....	57
Supply Air CFM.....	61
Supply Air Temperature & Set-	
point.....	58
Supply Fan Relay.....	64

VCB-X Status Screen Index.....	56
VCB-X Schedule Holidays.....	14,22
VFD Speed Limits Min/Cool/Vent.....	45
VFD Speed Limits Min/Max Heat.....	45
Voting Zone Configuration.....	67

W

Warm Up Command Relay	
Configuration.....	38,39,64,65
Water Side Condenser.....	33
Water Source Heat Pump Monitoring.....	25
Water Temperature.....	25,26
Week Schedules	
VCB-X Controller.....	14,22
Wetbulb.....	30
Wetbulb Temperature.....	60
Wetbulb Temperature Status.....	60
Wiring	
Power/Comm Board.....	8
WSHP Fail to Cool.....	32
WSHP Fail to Heat.....	32
WSHP Glycol Percentage Screen.....	32

Y

Year.....	11,17
-----------	-------

Z

Zone Alarm	
Delay.....	72
Offsets.....	71
Zone Damper Position	
VAV/Zone Status.....	74
Zone Temperature	
VAV/Zone Status.....	73



www.aaon.com

2425 So. Yukon Ave • Tulsa, OK 74107-2728

Ph: (918) 583-2266 • Fax: (918) 583-6094

AAON® Manual Part No: V28170

WattMaster Manual Form No: AA-VCBXOISD-TGD-01Q
